Potential External Contamination with Bisphenol A and Other Ubiquitous Organic Environmental Chemicals during Biomonitoring Analysis: An Elusive Laboratory Challenge

Xiaoyun Ye, Xiaoliu Zhou, Ryan Hennings, Joshua Kramer, and Antonia M. Calafat

Division of Laboratory Sciences, National Center for Environmental Health, Centers for Disease Control and Prevention, Atlanta, Georgia, USA

BACKGROUND: Biomonitoring studies are conducted to assess internal dose (i.e., body burden) to environmental chemicals. However, because of the ubiquitous presence in the environment of some of these chemicals, such as bisphenol A (BPA), external contamination during handling and analysis of the biospecimens collected for biomonitoring evaluations could compromise the reported concentrations of such chemicals.

OBJECTIVES: We examined the contamination with the target analytes during analysis of biological specimens in biomonitoring laboratories equipped with state-of-the-art analytical instrumentation.

DISCUSSIONS: We present several case studies using the quantitative determination of BPA and other organic chemicals (i.e., benzophenone-3, triclosan, parabens) in human urine, milk, and serum to identify potential contamination sources when the biomarkers measured are ubiquitous environmental contaminants.

CONCLUSIONS: Contamination with target analytes during biomonitoring analysis could result from solvents and reagents, the experimental apparatus used, the laboratory environment, and/or even the analyst. For biomonotoring data to be valid—even when obtained from high-quality analytical methods and good laboratory practices—the following practices must be followed to identify and track unintended contamination with the target analytes during analysis of the biological specimens: strict quality control measures including use of laboratory blanks; replicate analyses; engineering controls (e.g., clean rooms, biosafety cabinets) as needed; and homogeneous matrix-based quality control materials within the expected concentration ranges of the study samples.

KEY WORDS: benzophenone-3, biomonitoring, bisphenol A, exposure assessment, parabens, reagent blank, triclosan. *Environ Health Perspect* 121:283–286 (2013). http://dx.doi.org/10.1289/ehp.1206093 [Online 16 January 2013]

Humans are exposed to environmental chemicals through industrial and indoor air pollution, diet, and use of personal care and consumer products. Biomonitoring (i.e., measurement of the environmental chemicals or their metabolites in biological speciments) is widely used to assess human internal exposure (i.e., body burden) to these chemicals [Centers for Disease Control and Prevention (CDC) 2012; Den Hond et al. 2011; Frery et al. 2012; Health Canada 2010; Kim et al. 2011; National Research Council 2006; Suzuki et al. 2010].

Proper biomonitoring practices take into account the selection of the relevant biomarker and biomonitoring matrix, the potential impact of the collection protocol on the biomarker levels in the sample, as well as the integrity of the sample during its collection, handling, storage, and analysis (Calafat and Needham 2009). Furthermore, accurate and precise highly sensitive and selective multianalyte analytical methods for extraction, separation, and detection of the environmental chemicals are required to obtain valid biomonitoring data (Angerer et al. 2007). Participation in external quality assessment programs [e.g., Arctic Monitoring and Assessment Program (Institut National de Santé Publique du Québec 2012), German External Quality Assessment Scheme (G-EQUAS; Social and Environmental Medicine of the University Erlangen-Nuremberg 2012)] and the use of standard reference materials (SRMs) from the National Institute of Standards and Technology (Keller et al. 2010; Schantz et al. 2013) are very useful tools to evaluate method accuracy.

However, even with the application of sophisticated and accurate methods, external contamination with some ubiquitous environmental organic chemicals, such as bisphenol A (BPA), polybrominated diphenyl ethers (PBDEs), and polychlorinated biphenyls (PCBs), during sample analysis can compromise the analytical determination of these compounds [Alcock et al. 1994; Sjödin et al. 2004; World Health Organization (WHO) 2011]. External contamination can even preclude accurate analyses of phthalate diesters, which are detected in the cleanest laboratory reagents, sampling equipment, and analytical apparatus. Therefore, assessing human exposure to phthalates is routinely done by measuring biomarkers that cannot be formed in the environment (e.g., oxidized metabolites of phthalates) instead of the phthalate diesters themselves (Koch and Calafat 2009).

Field blanks have been used to assess potential contamination during collection, processing, and/or transport of environmental samples (National Institute for Occupational Safety and Health 1994) and the importance

of using field blanks in biomonitoring studies has been presented (National Research Council 2006; WHO 2011). Furthermore, it is well recognized that reagent or quality control blank (QCB) and quality control (QC) samples, when used and evaluated properly, are invaluable to monitoring potential contamination during analysis and the accuracy/precision of the measurements (Taylor 1987).

Several reports have investigated potential sources of contamination with ubiquitous organic chemicals during sample analysis and how to mimimize contamination in a typical biomonitoring laboratory setup (Alcock et al. 1994; Markham et al. 2010; Sjödin et al. 2004; Xie et al. 2006). Here we present several case studies using the measurement of BPA and other ubiquitous environmental organic chemicals (e.g., benzophenone-3, triclosan, parabens) in human urine, milk, and serum by on-line solid phase extraction coupled to isotope dilution-high performance liquid chromatography-tandem mass spectrometry (on-line SPE-HPLC-MS/MS) to discuss potential contamination scenarios during analysis, including the reagents and apparatus used, the laboratory environment, and the analyst.

Discussion

Contamination from solvents and reagents. During analysis, contamination from solvents (including water) or reagents is monitored through the calculated concentration and the signal/noise (S/N) ratio of the reagent blank or QCB peak (Taylor 1987). However, the QCB calculated concentration per se might not reveal systematic contamination during analysis

Address correspondence to A. Calafat, Division of Laboratory Sciences, National Center for Environmental Health, Centers for Disease Control and Prevention, 4770 Buford Hwy., Mailstop F17, Atlanta, GA 30341 USA. Telephone: (770) 488-7891. E-mail: aic7@cdc.gov

This work was supported in part by appointments (R.H. and J.K.) to the Research Participation Program at the Centers for Disease Control and Prevention (CDC), administered by the Oak Ridge Institute for Science and Education through an interagency agreement between the U.S. Department of Energy and the CDC.

The authors complied with all needed research requirements regarding human subjects. The findings and conclusions in this report are those of the authors and do not necessarily represent the views of the CDC.

The authors declare they have no actual or potential competing financial interests.

Received 3 October 2012; accepted 15 January 2013.

(e.g., as when the same reagents/solvents are used to prepare both QCB and standards). Concentrations of samples, including the QCB, are calculated from a calibration curve constructed by plotting the instrument response of analytical standards versus their known concentrations after automatically subtracting the y-intercept—the instrument response at a zero concentration—from the response of the samples (Taylor 1987). If the y-intercept includes a contribution from the contamination of reagents/solvents present in both the analytical standards and the QCB, the calculated concentration of the QCB will be around zero or below the limit of detection (LOD) of the method. Therefore, reagent or solvent contamination can not be revealed by the calculated QCB concentration, but only through the higher than expected S/N ratio of the QCB (i.e., S/N > 3).

To measure BPA in urine, we have used methanol and water as mobile phases of an on-line SPE-HPLC-MS/MS system (Ye et al. 2005, 2006). In one instance, right after the laboratory water purification system had been serviced during its regular preventative maintenance, we observed a high S/N ratio (19.6) of the BPA peak for the QCBs (Figure 1A). However, the calculated BPA concentration of the QCB was below the LOD, suggesting that we had a systematic contamination. Further investigation confirmed that the contamination was in the water and resulted from BPA leaching from a polyethersulfone filter installed during the preventative maintenance of the water purification system. After replacing this filter with another brand of polyethersulfone filter, the QCB S/N ratio went back to its normal levels (Figure 1B), suggesting that the latter filter, albeit made from the same material as the first, did not leach BPA.


To minimize the impact of low-level contamination of HPLC and SPE mobile phases with the target compounds (in this case, BPA), we modified our experimental configuration by adding guard cartridges to both mobile phase lines, similar to the approach we used before for filtering out an interference of


perfluorooctanoate (Kuklenyik et al. 2009). Specifically, we added two C18 guard cartridges, one right after the SPE pump and another right after the HPLC pump (Figure 2). The SPE guard cartridge retains BPA during the loading of the sample on the SPE column with a relatively low organic content [e.g., 20% methanol in water (Ye et al. 2005)], so the interference of BPA from the SPE mobile phase will not be loaded onto the SPE column. The BPA interference trapped in the SPE guard cartridge is flushed to waste during the SPE column regeneration step. When the BPA contaminant from the HPLC mobile phase retained on the HPLC guard cartridge elutes onto the HPLC analytical column with the HPLC gradient, the additional length of the guard cartridge delays the elution of the BPA contaminant compared with that of the "true" BPA peak from standards, QCs, and study samples. Figure 1C shows the extracted ion chromatograms of BPA from QCBs with BPA interference obtained when using contaminated water in both SPE and HPLC mobile phases, but adding guard cartridges after the SPE and HPLC pumps. Compared with Figure 1A, the BPA contamination from the SPE solvent is completely removed. Noteworthy, the absence of another BPA peak at the expected longer retention time suggests that the BPA interference from the water in the HPLC mobile phase is negligible compared with the BPA in the water of the SPE mobile phase, an interference that had been preconcentrated on the SPE cartridge.

When contamination affecting standards, QC materials, and study samples cannot be avoided completely, the concentration of study samples is adjusted by subtracting the contribution from the QCB. However, a high QCB contribution will increase the variability of measurements at low-concentration ranges. In the example above, contamination with BPA of the water purification system increased the frequency of out of control values of the low-concentration QC materials (~ 2.5 µg/L), which, unfortunately, is also around the median urinary concentration of

BPA for the general population in various countries (CDC 2012; Health Canada 2010; Koch et al. 2012). Together, these findings show that careful evaluation of the concentration and S/N ratio patterns of the QCBs, as well as having homogeneous matrix-based QC materials at the relevant concentrations (e.g., general population median), were instrumental in identifying the contamination of BPA from the deionized water.

Contamination of experimental apparatus. The experimental apparatus (e.g., septum-equipped test tubes) could be a contamination source when measuring PBDEs (Sjödin et al. 2004). Similarly, because BPA can leach from plastic [National Toxicology Program (NTP) 2008], contamination of BPA from plasticware is also possible. On one occasion, while analyzing breast milk for BPA by on-line SPE-HPLC-MS/MS (Ye et al. 2008), we observed not only a high S/N ratio (S/N = 18.6) of the QCB signal, but also that its calculated BPA concentration was consistently 1–2 μ g/L above the LOD of 0.3 μ g/L (Figure 3A). These combined results indicated that the contamination of BPA was not systematic (i.e., at least not in the standards). The sample pretreatment included precipitation of milk proteins by methanol, followed by centrifugation of the milk in a disposable microcentrifuge plastic tube. We added the same solvents to standards, QCBs, and milk samples, but prepared the solvent-based standards directly in silanized autosampler glass vials without the centrifugation step. We confirmed that the BPA contamination in the QCBs came from the leaching of BPA from a specific lot of microcentrifuge tubes, even though the tubes were presented as made of polypropylene, which is not known to contain BPA. When we prepared the QCBs in silanized glass autosampler vials, the BPA contamination dissapeared (Figure 3B). To avoid future contamination, we modified our procedure and prepared the milk samples in conical silanized glass vials instead of plastic microcentrifuge tubes; we also reduced the spin speed to avoid breaking the glass vials during








Figure 1. HPLC-MS/MS-extracted ion chromatograms of BPA (m/z ion transition 227/133) of QCBs using a method for the analysis of urine. (A) QCB with BPA interference in the water used in the SPE and HPLC mobile phases (QCB signal is equivalent to a concentration of 1.5 μ g/L); (B) QCB without BPA interference; (C) QCB with BPA interference in the mobile phase, but adding guard cartridges after SPE and HPLC pumps.

centrifugation. Our findings above reiterate the importance not only of including QCBs in each analytical batch, but that the QCBs have to go through the exact same processing protocols, including using the same apparatus, as the study samples.

Contamination in the laboratory environment. Indoor air is a known source of PCBs, particularly the low molecular weight congeners (Alcock et al. 1994). Similarly, because BPA, triclosan, and parabens have been detected in indoor dust (Fan et al. 2010; Geens et al. 2009; Liao et al. 2012), contamination with these ubiquitous chemicals could also come from the laboratory environment. In another situation, we measured the concentrations of free and total (free + conjugated) BPA in serum as part of an exposure study. We followed strict QC protocols, namely having at least two QCBs, two low-concentration QCs, and two highconcentration QCs in each analytical batch with 50 study samples, and including replicate analysis of at least 10% of study samples. Even with these cautionary measures, we observed random contamination of BPA in about 2% of the replicate analyses (Teeguarden et al. 2011). We first ruled out the potential contamination with BPA from solvents and reagents. Because BPA can be used in the manufacture of certain plastics (NTP 2008) and can be present in paper products (Geens et al. 2012; Liao and Kannan 2011), we systematically evaluated the

experimental apparatus used and the materials present in our laboratory. We identified the absorbent underpad used to cover the workspace in the laboratory benches as the source of the contamination. We speculate that the random contamination originated when underpad fibers got into the autosampler vials during preparation of the serum for analysis. We eliminated this contamination after we replaced the absorbent underpad with other bench top protection sheets that did not contain BPA.

In a similar situation, we detected random contamination of triclosan in the QCBs and QCs while analyzing urine (Ye et al. 2005). After ruling out contamination from reagents, solvents, and experimental apparatus, we discovered that shortly before we noticed the contamination, the hand soap in the restrooms dispensers had been replaced with hand soap containing triclosan, a broad-spectrum antimicrobial agent widely used in soaps in the U.S. market (Perencevich et al. 2001). Despite using proper personal protection equipment for sample preparation in the laboratory, including changing gloves often as needed during sample preparation, the analysts, after washing their hands with the antibacterial soap, randomly contaminated some of the samples. The triclosan contamination disappeared after replacing triclosan-containing hand soap in the restroom dispensers with triclosan-free soap.




Figure 2. On-line SPE-HPLC-MS/MS configuration, adapted from a previous publication (Ye et al. 2008), with guard cartridges after SPE and HPLC pumps. The 10-port switching valve configuration shown corresponds to the time period when the sample is loaded onto the SPE cartridge.




Figure 3. HPLC-MS/MS extracted ion chromatograms of BPA (m/z ion transition 227/133) of QCBs using a method for the analysis of milk. (A) QCB prepared in a plastic microcentrifuge tube; (B) QCB prepared in conical silanized glass autosampler vials.

These findings confirm that the general laboratory environment and its immediate surroundings can also be a potential contamination source. Noteworthy, because of its random pattern, this contamination is usually difficult to identify and track down even by experienced researchers adhering to a comprehensive QC protocol. One approach for identifying the potential contamination from laboratory environment involves running replicate analysis, particularly when the number of study samples is small. If replicate analysis is not possible (e.g., limited sample volume), another alternative is including additional QCBs and QCs within the analytical batch.

The analyst can also be the contamination source, especially for chemicals present in consumer or personal care products. In another example, we noticed random, yet often repeated contamination with triclosan in some QCBs and QCs included in the batches prepared by one analyst, but not others. After ruling out the potential contamination sources discussed above and confirming that this person followed the required standard operating procedures, we inventoried all of the situations, both in and outside the workplace, where the analyst could come in contact with triclosan-containing products (Department of Health and Human Services 2007; Perencevich et al. 2001). At the end of an investigation that took several weeks, we determined that the contamination started after the analyst changed the toothpaste at home to one that contained triclosan. In another instance, we encountered a similar random contamination with benzophenone-3 and parabens. In this case, the contamination sources were the analyst's sunscreen lotion and underarm deodorant which contained benzophenone-3 and parabens (Department of Health and Human Services 2007). In both cases, we realized the occurence of contamination through the abnormal results of the QCBs and QCs. After we identified the sources of contamination, and although the analysts did not have to change their habits related to personal care products use, we managed to reduce the potential contamination to negligible levels by conducting all sample preparation procedures in a biological safety cabinet.

Conclusions

Unintended contamination with ubiquitous environmental chemicals, such as BPA and other organic compounds (e.g., benzophenone-3, triclosan, parabens), during biomonitoring analyses is possible, even with state-of-the-art analytical methods and laboratory facilities. Unfortunately, until all of the environmental sources of these chemicals are known, totally eliminating external contamination is practically impossible. However, judicious application of the measures below

will allow the identification of contamination scenarios, thus facilitating the implementation of measures to isolate and track external contamination and minimize as much as possible its recurrence and impact.

- Evaluate the QCB (i.e., reagent blank) by checking both the calculated concentration and the S/N ratio of the QCB peak to assess any systematic or non-systematic contamination.
- Prepare the QCBs using the same procedure and apparatus as the unknown study samples to avoid missing labware and apparatus potential contamination.
- Use guard columns to filter out potential interference contaminants from the SPE mobile phases or separate the chromatograhic peak of the target analyte in the study samples from its interference peak in the HPLC mobile phases.
- Conduct replicate analyses (e.g., 5%) of study samples to identify random contamination from the laboratory environment and/or analyst, especially when the number of study samples is small. When limited sample volume precludes replicate analyses, include additional blanks randomly placed within the analytical batch.
- Prepare the samples for analysis in a controlled environment (i.e., biological safety cabinet, clean room) if contamination from the analyst or the environment (e.g., air, dust) is suspected.
- Use homogeneous matrix-matched QC materials at concentrations within the expected concentration ranges of the study samples.
- When possible, participate in external quality assessment programs or use SRMs to evaluate the accuracy of the measurement. Unfortunately, for nonpersistent environmental organic chemicals (e.g., BPA, benzophenone-3, triclosan, parabens) commercially available SRMs do not exist and only BPA is routinely included in G-EQUAS. Expanding such quality assessment programs and characterizing SRMs to include these chemicals are critical to improve the accuracy of biomonitoring methods.

In summary, valid biomonotoring data require integrating numerous preanalytical and analytical steps. First, adequate selection of the most relevant biomarkers and biomonotoring matrices as well as collection, handling, shipping, and storage procedures to preserve the integrity of the specimen and the target analytes are needed before starting sample analyses. Second, use of sensitive, selective, and accurate analytical methods and state-of-theart laboratory facilities. Third, use of highly trained laboratory personnel not only to operate sophisticated instrumentation, but also to recognize situations that may compromise

both the integrity of the biological specimen and the validity of its analysis. Last, use of good laboratory practices and implementation of measures as discussed above to minimize unintended contamination of the biological specimens with the target analytes during analysis. We strongly believe that biomonitoring studies that maximize the harmonization of the various disciplines and expertises (e.g., field investigation, laboratory analysis) will considerably strengthen the exposure assessment.

REFERENCES

- Alcock RE, Halsall CJ, Harris CA, Johnston AE, Lead WA, Sanders G, et al. 1994. Contamination of environmental samples prepared for PCB analysis. Environ Sci Technol 28:1838–1842.
- Angerer J, Ewers U, Wilhelm M. 2007. Human biomonitoring: state of the art. Int J Hyg Environ Health 210(3–4):201–228.
- Calafat AM, Needham LL. 2009. What additional factors beyond state-of-the-art analytical methods are needed for optimal generation and interpretation of biomonitoring data? Environ Health Perspect 117:1481–1485.
- CDC (Centers for Disease Control and Prevention). 2012. Fourth National Report on Human Exposure to Environmental Chemicals. Updated Tables, September 2012. Atlanta, GA:CDC. Available: http://www.cdc.gov/exposurereport/pdf/FourthReport_UpdatedTables_Sep2012.pdf [accessed 26 September 2012].
- Den Hond E, Dhooge W, Bruckers L, Schoeters G, Nelen V, van de Mieroop E, et al. 2011. Internal exposure to pollutants and sexual maturation in Flemish adolescents. J Expo Sci Environ Epidemiol 21:224–233.
- Department of Health and Human Services. 2007. Household Products Database. Available: http://hpd.nlm.nih.gov/index. htm [accessed 4 June 2012].
- Fan XH, Kubwabo C, Rasmussen P, Jones-Otazo H. 2010. Simultaneous quantitation of parabens, triclosan, and methyl triclosan in indoor house dust using solid phase extraction and gas chromatography-mass spectrometry. J Environ Monit 12:1891–1897.
- Frery N, Vandentorren S, Etchevers A, Fillol C. 2012. Highlights of recent studies and future plans for the French human biomonitoring (HBM) programme. Int J Hyg Environ Health 215:127–132.
- Geens T, Goeyens L, Kannan K, Neels H, Covaci A. 2012. Levels of bisphenol-A in thermal paper receipts from Belgium and estimation of human exposure. Sci Total Environ 435–436:30–33.
- Geens T, Roosens L, Neels H, Covaci A. 2009. Assessment of human exposure to bisphenol-A, triclosan and tetrabromobisphenol-A through indoor dust intake in Belgium. Chemosphere 76:755–760.
- Health Canada. 2010. Report on Human Biomonitoring of Environmental Chemicals in Canada. Results of the Canadian Health Measures Survey Cycle 1 (2007–2009). Ottawa, Ontario:Health Canada. Available: http://www. hc-sc.gc.ca/ewh-semt/pubs/contaminants/chms-ecms/ index-eng.php [accessed 16 August 2012].
- Institut National de Santé Publique du Québec. 2012. Arctic Monitoring and Assessment Program. Québec, Canada: Institut National de Santé Publique du Québec.
- Keller JM, Calafat AM, Kato K, Ellefson ME, Reagen WK, Strynar M, et al. 2010. Determination of perfluorinated alkyl acid concentrations in human serum and milk standard reference materials. Anal Bioanal Chem 397:439–451.
- Kim Y, Ha EH, Kim EJ, Park H, Ha M, Kim JH, et al. 2011. Prenatal exposure to phthalates and infant development at 6 months: Prospective Mothers and Children's Environmental Health (MOCEH) study. Environ Health Perspect 119:1495–1500.
- Koch HM, Calafat AM. 2009. Human body burdens of chemicals used in plastic manufacture. Philos Trans R Soc Lond B Biol Sci 364:2063–2078.
- Koch HM, Kolossa-Gehring M, Schroeter-Kermani C, Angerer J, Bruening T. 2012. Bisphenol A in 24 h urine and plasma samples of the German Environmental Specimen Bank from

- 1995 to 2009: a retrospective exposure evaluation. J Expo Sci Environ Epidemiol 22:610–616.
- Kuklenyik Z, Ye XY, Needham LL, Calafat AM. 2009. Automated solid-phase extraction approaches for large scale biomonitoring studies. J Chromatogr Sci 47:12–18.
- Liao CY, Kannan K. 2011. Widespread occurrence of bisphenol A in paper and paper products: implications for human exposure. Environ Sci Technol 45:9372–9379.
- Liao CY, Liu F, Guo Y, Moon HB, Nakata H, Wu Q, et al. 2012. Occurrence of eight bisphenol analogues in indoor dust from the United States and several Asian countries: implications for human exposure. Environ Sci Technol 46:9138–9145.
- Markham DA, Waechter JM, Wimber M, Rao N, Connolly P, Chuang JC, et al. 2010. Development of a method for the determination of bisphenol A at trace concentrations in human blood and urine and elucidation of factors influencing method accuracy and sensitivity. J Anal Toxicol 34:293–303.
- National Institute for Occupational Safety and Health. 1994. NIOSH Manual of Analytical Methods, 4th ed. Atlanta, GA:CDC.
- National Research Council, Committee on Human Biomonitoring for Environmental Toxicants. 2006. Human Biomonitoring for Environmental Chemicals. New York:National Academy of Sciences.
- NTP (National Toxicology Program). 2008. NTP Brief on Bisphenol A [CAS NO. 80–05–07]. Available: http://ntp. niehs.nih.gov/ntp/ohat/bisphenol/bisphenol.pdf [accessed 3 September 2012].
- Perencevich EN, Wong MT, Harris AD. 2001. National and regional assessment of the antibacterial soap market: a step toward determining the impact of prevalent antibacterial soaps. Am J Infect Control 29:281–283.
- Schantz MM, Eppe G, Focant JF, Hamilton C, Heckert NA, Heltsley RM, et al. 2013. Milk and serum standard reference materials for monitoring organic contaminants in human samples. Anal Bioanal Chem 405(4):1203–1211.
- Sjödin A, Jones RS, Lapeza CR, Focant JF, McGahee EE, Patterson DG. 2004. Semiautomated high-throughput extraction and cleanup method for the measurement of polybrominated diphenyl ethers, polybrominated biphenyls, and polychlorinated biphenyls in human serum. Anal Chem 76:1921–1927.
- Social and Environmental Medicine of the University Erlangen-Nuremberg. 2012. German External Quality Assessment Scheme. Available: http://www.g-equas.de/ [accessed 6 December 2012].
- Suzuki Y, Niwa M, Yoshinaga J, Mizumoto Y, Serizawa S, Shiraishi H. 2010. Prenatal exposure to phthalate esters and PAHs and birth outcomes. Env Int 36:699–704.
- Taylor JK. 1987. Quality Assurance of Chemical Measurements. Chelsea, MI:Lewis Publishers.
- Teeguarden JG, Calafat AM, Ye XY, Doerge DR, Churchwell MI, Gunawan R, et al. 2011. Twenty-four hour human urine and serum profiles of bisphenol A during high-dietary exposure. Toxicol Sci 123:48–57.
- WHO (World Health Organization). 2011. Toxicological and Health Aspects of Bisphenol A. Report of Joint FAO/WHO Expert Meeting, 2–5 November 2010, and Report of Stakeholder Meeting on Bisphenol A, 1 November 2010. Available: http://whqlibdoc.who.int/publications/2011/97892141564274_eng.pdf [accessed 23 July 2012].
- Xie ZY, Selzer J, Ebinghaus R, Caba A, Ruck W. 2006. Development and validation of a method for the determination of trace alkylphenols and phthalates in the atmosphere. Anal Chim Acta 565:198–207.
- Ye XY, Bishop AM, Needham LL, Calafat AM. 2008. Automated on-line column-switching HPLC-MS/MS method with peak focusing for measuring parabens, triclosan, and other environmental phenols in human milk. Anal Chim Acta 622:150–156.
- Ye XY, Kuklenyik Z, Bishop AM, Needham LL, Calafat AM. 2006. Quantification of the urinary concentrations of parabens in humans by on-line solid phase extraction-high performance liquid chromatography—isotope dilution tandem mass spectrometry. J Chromatogr B Analyt Technol Biomed Life Sci 844:53–59.
- Ye XY, Kuklenyik Z, Needham LL, Calafat AM. 2005. Automated on-line column-switching HPLC-MS/MS method with peak focusing for the determination of nine environmental phenols in urine. Anal Chem 77:5407–5413.