


Protocol

Protocol to Fabricate Engineered Illumination Devices for Optogenetic Control of Cellular Signaling Dynamics



Nicole A. Repina,
Hunter J. Johnson,
Thomas McClave,
Ravi S. Kane, David
V. Schaffer

hunter.johnson@berkeley.
edu (H.J.J.)
schaffer@berkeley.edu
(D.V.S.)

HIGHLIGHTS

Fabrication of
illumination devices
for light activation at
variable amplitudes
(LAVA)

Spatiotemporal
control of light
illumination in
multiwell cell culture
plates

Overview of
optogenetic
photostimulation and
analysis in LAVA
devices

Optogenetic modulation of protein interactions enables spatiotemporal control of cellular signaling dynamics in a variety of biological systems. However, light patterning by standard microscopes is limited by their complexity, sample throughput, and cost. To address the need for low-cost, user-friendly, and high-throughput photopatterning, we have engineered devices for light activation at variable amplitudes (LAVA). This protocol describes the assembly of LAVA devices, which enable spatial and temporal control of optogenetic stimulation and cellular signaling dynamics in multiwell cell culture plates.

Repina et al., STAR Protocols
1, 100141
December 18, 2020 © 2020
The Authors.
[https://doi.org/10.1016/
j.xpro.2020.100141](https://doi.org/10.1016/j.xpro.2020.100141)



Protocol

Protocol to Fabricate Engineered Illumination Devices for Optogenetic Control of Cellular Signaling Dynamics

Nicole A. Repina,^{1,2,8} Hunter J. Johnson,^{1,2,8,9,*} Thomas McClave,³ Ravi S. Kane,⁴ and David V. Schaffer^{1,5,6,7,10,*}

¹Department of Bioengineering, University of California, Berkeley, Berkeley, CA 94720, USA

²Graduate Program in Bioengineering, University of California, San Francisco and University of California, Berkeley, Berkeley, CA 94720, USA

³Department of Physics, University of California, Berkeley, Berkeley, CA 92720, USA

⁴School of Chemical and Biomolecular Engineering, Georgia Institute of Technology, Atlanta, GA 30332, USA

⁵Department of Chemical and Biomolecular Engineering, University of California, Berkeley, Berkeley, CA 94720, USA

⁶Department of Molecular and Cell Biology, University of California, Berkeley, Berkeley, CA 94720, USA

⁷Helen Wills Neuroscience Institute, University of California, Berkeley, Berkeley, CA 94720, USA

⁸These authors contributed equally

⁹Technical Contact

¹⁰Lead Contact

*Correspondence: hunter.johnson@berkeley.edu (H.J.J.), schaffer@berkeley.edu (D.V.S.)
<https://doi.org/10.1016/j.xpro.2020.100141>

SUMMARY

Optogenetic modulation of protein interactions enables spatiotemporal control of cellular signaling dynamics in a variety of biological systems. However, light patterning by standard microscopes is limited by their complexity, sample throughput, and cost. To address the need for low-cost, user-friendly, and high-throughput photopatterning, we have engineered devices for light activation at variable amplitudes (LAVA). This protocol describes the assembly of LAVA devices, which enable spatial and temporal control of optogenetic stimulation and cellular signaling dynamics in multiwell cell culture plates. For complete details on the use and execution of this protocol, please refer to Repina et al. (2020).


BEFORE YOU BEGIN

This protocol will provide the step-by-step instructions to fabricate the default blue-light LAVA board described in Repina et al, 2020. All design files, custom parts, and operating software are provided, and no electrical or coding experience is required for fabrication. Before starting LAVA board fabrication, you must first assemble all of the necessary materials, equipment, and custom ordered parts. Custom orders include the printed circuit boards, 3D-printed light guides, laser-cut components, and photomasks. Figure 1 outlines the major components of the 24-well LAVA board. 96-well LAVA boards share all of the same components, excluding custom parts 1, 3, 5, and 6.

Order Custom Materials

1. Printed circuit boards PCB-1 and PCB-2 (Figure 1, parts 6 & 12)
 - a. EAGLE and Gerber files for all printed circuit boards (PCBs) are provided here: <https://github.com/LAVABoard/LAVA/tree/master/CircuitBoard>
 - b. Parts can be ordered from any PCB manufacturer. We recommend OSH Park, www.oshpark.com





Note: the 24-well and 96-well LAVA boards are identical EXCEPT for parts ③, ⑤, and ⑥

Figure 1. Major Components of LAVA Board Device Fabrication

24-well LAVA board depicted. All parts are identical between the 24-well and 96-well LAVA boards, excluding parts 1, 3, 5, and 6.

- i. Silk screen stencils are very helpful during reflow soldering. We recommend ordering a silk screen mask for PCB-1 from your preferred PCB manufacturer or OSH Stencils, www.oshstencils.com
2. 3D-printed light guides (Figure 1, part 3 & 5)
 - a. STL files for all light guides are provided here: <https://github.com/LAVAbord/LAVA/tree/master/LightGuides>
 - b. Components can be printed on any extrusion-based 3D printer (ex. Ultimaker 3, uPrint, etc) out of black PLA or ABS. No support material is required during printing.
3. Laser-cut components (Figure 1, parts 9, 15, & 17)
 - a. AI files for all laser-cut components are provided here: <https://github.com/LAVAbord/LAVA/tree/master/LaserCut>
 - b. Components should be cut out of 0.118" (3 mm) thick acrylic.
4. Photomasks
 - a. Custom photomasks can be cut from adhesive vinyl using a dye cutter.
 - b. Custom photomasks can be laser-plotted from mylar using a photomask print service such as www.fineline-imaging.com.
 - c. Custom photomasks can be printed onto transparency film using a standard inkjet printer. Note, you may need to stack multiple transparencies for high opacity.
5. Power supply (PSU)
 - a. Choice of correct power supply is critical for proper LAVA board operation. Please see the [Key Resources Table](#) for the suggested power source to use with blue CLM1B Cree Light Emitting Diodes (LEDs). For use with other LEDs, perform the following calculation to determine the power supply unit (PSU) voltage, note V_f is the forward voltage of a single LED (usually 2–5 V). Please note that PSUs that exceed this calculated voltage by greater than 1–2 V will cause overheating of the TLC5947 chip.
 - i. PSU voltage (24-well board) = $5 \times V_f$
 - ii. PSU voltage (96-well board) = $4 \times V_f$
 - b. For the default design, each LAVA board LED receives a 15 mA current and voltage equal to V_f for the respective format. Thus, the power supply for each board is
 - i. 24-well board: 18-Watt 18V 1200 mV AC-DC Wall Adapter ([Key Resources Table](#))
 - ii. 96-well board: 18-Watt 15V 1500 mA AC-DC Wall Adapter ([Key Resources Table](#))

6. Assemble all other materials and equipment
 - a. See the [Key Resources Table](#) and [Materials and Equipment](#) sections below.

△ **CRITICAL:** Be sure to choose the correct power supply for either the 24-well board or the 96-well board. Beware, if PSU output voltage is more than 1–2 V greater than the calculated voltage above, the TLC5947 may overheat. Always test the PSU by running the LAVA board with the selected PSU for >10 min and check that the TLC5847 chip does not become hot.

KEY RESOURCES TABLE

REAGENT or RESOURCE	SOURCE	IDENTIFIER
Software and Algorithms		
JarJarBlinks GUI	GitHub	https://github.com/LAVABoard/LAVA
LED calibration code	GitHub	https://github.com/LAVABoard/LAVA
Other		
Circuit board (PCB1)	Circuit board manufacturer	https://github.com/LAVABoard/LAVA/tree/master/CircuitBoard
Circuit board (PCB2)	Circuit board manufacturer	https://github.com/LAVABoard/LAVA/tree/master/CircuitBoard
Raspberry Pi Zero W	Adafruit	Cat#3400
Adafruit 24-Channel 12-bit PWM LED Driver TLC5947	Adafruit	Cat#1429
SanDisk 8GB microSD High	Amazon	N/A
Arctic Silver 7 g Thermal Cooling Adhesive Set	Amazon	Cat#ASTA-7G
Cree SMD Blue 470 nm LED	Mouser	Cat#CLM1B-BKW-CTBVA353CT-ND
Fan Axial 40 × 10.5 mm 12 V DC wire	Digikey	Cat#1053-1206-ND
Bracket universal 0.628 × 0.628 inch	Digikey	Cat#36-618-ND
Terminal block RCPT 2POS VERT 0.100	Digikey	Cat#A121350-ND
Non-Isolated POL DC/DC Converter, 1 Output, 12 W, 12 V, 1 A, Fixed, Through Hole	Mouser	Cat#495-TSR-1-24120
Non-Isolated POL DC/DC Converter, 1 Output, 5 W, 5 V, 1 A, Fixed, Through Hole	Mouser	Cat#495-TSR-1-2450
Slide Switch, On-None-On SPDT	Mouser	Cat#612-500SSP1S4M6QEA
Rubber Push-in Bumper, Tight-Grip Ridged Stem, 1/4 inch Hole Size, 9/16 inch Diameter	McMaster Carr	Cat#9309K16
Nylon 6/6 Plastic Hex Standoff, 3/16 inch Hex, 7/16 inch Long, 2-56 Female Thread	McMaster Carr	Cat#92319A255
Nylon Pan Head Screws, Phillips, 2-56 Thread, 3/16 inch Long	McMaster Carr	Cat#94735A706 off-white
Vibration-Damping Sandwich Mount with Insert Neoprene, 8-32 Thread, 7 lb Capacity, 1/2 inch High	McMaster Carr	Cat#94955K21
Female Threaded Round Standoff, 18-8 Stainless Steel, 1/4 inch OD, 1-1/4 inch Long, 8-32 Thread Size	McMaster Carr	Cat#91125A454

(Continued on next page)

Continued

REAGENT or RESOURCE	SOURCE	IDENTIFIER
18-8 Stainless Steel Cup-Point Set Screw, 8-32 Thread, 1/2 inch Long	McMaster Carr	Cat#92311A194
Black-Oxide 18-8 Stainless Steel Pan Head Phillips Screws, 6-32 Thread, 5/8 inch Long	McMaster Carr	Cat#91249A151
Black-Oxide 18-8 Stainless Steel Pan Head Phillips Screws, 8-32 Thread, 1/4 inch Long	McMaster Carr	Cat#91249A189
18-8 Stainless Steel Hex Nut, 6-32 Thread Size	McMaster Carr	Cat#91841A007
18-8 Stainless Steel Hex Nut, 8-32 Thread Size	McMaster Carr	Cat#91841A009
70 mm × 130 mm Rectangular Heat Sink - 1.4°C/W	Luxeon Star	Cat#N13070-40B
18 W, 18 V AC-DC High Reliability Industrial Wall Adapter 2.1 mm Plug Level VI (24-well device)	Jameco	Cat#2225625
18 W, 15 V AC-DC High Reliability Industrial Wall Adapter 2.1 mm Plug Level VI (96-well device)	Jameco	Cat#2225617
DC Barrel Power Jack/Connector (5.5 mm jack, 2.1 mm center pole diameter)	Sparkfun	Cat#00119
Break Away Headers - Straight, 40-pin, 0.1 inch spacing	Sparkfun	Cat#00116
Female headers - 40-pin, 0.1 inch spacing	Sparkfun	Cat#00115
Acrylic Sheets, 14 × 14 inch, 0.118 inch thick	Any plastics supplier (ex. TAP Plastics)	N/A
80° Light Shaping Diffuser on 0.010 inch Polycarbonate, 24 × 24 inch	Luminit	Cat#L80P1-24
Recommended Cell Culture Plates		
CELLSTAR™ 96 Well µClear Black Flat-Bottomed Microplates	Greiner Bio-One	Cat#688089
Cell imaging plate, 24-well Black Plate with 170 µm glass bottom	Eppendorf	Cat#30741021
VisiPlate-24 Black, Black 24-well Microplate with Clear Bottom	Perkin Elmer	Cat#1450-605

Note: Other 24-well and 96-well cell culture plates can be used with the default LAVA board devices. We recommend glass bottom or thin plastic. We also recommend black-walled imaging plates to minimize any light contamination between adjacent wells. You may need to modify the 3D-printed light guide design if the plate does not fit the current dimensions.

MATERIALS AND EQUIPMENT

Tool	Note
Standard soldering toolkit	For standard through-hole soldering
Wire cutter	For fan attachment
Wire striper	For fan attachment

(Continued on next page)

Continued

Tool	Note
Phillips head screwdriver	Various applications
Mini flathead screwdriver	For fan attachment
Tweezers	For LED placement
Scissors	For diffuser preparation
Super glue	For LED driver cover
Squeegee	For reflow soldering and epoxy application
Hot plate or reflow oven	For reflow soldering. A reflow oven can also be used.
Laser cutter	Any laser cutter capable of cutting 12 x 12 x 1/4" acrylic sheets is sufficient. Parts can also be outsourced to a laser cutting service.
3D printer	Any 3D printer capable of printing black PLA or ABS parts with at least 6 x 6 x 6" bed size is sufficient. No support material required. Parts can also be outsourced to a 3D printing service
Compact Power Meter Console	For LED calibration and periodic evaluation of device performance. We recommend Thorlabs Cat#PM100D
Standard Photodiode Power Sensor	For LED calibration and periodic evaluation of device performance. We recommend Thorlabs Cat#S120C

STEP-BY-STEP METHOD DETAILS

Step 1: Solder LEDs onto PCB-1 Using Reflow Soldering

⌚ Timing: 1 h

In this step, you will attach all of the LEDs onto PCB-1 via reflow soldering. Reflow soldering is a fast and simple way to attach surface-mount components to a circuit board. In brief, reflow solder paste is applied to the copper pads on PCB-1. The LEDs are placed on top of the paste and the board is heated on a hot plate to melt and solidify the solder. We recommend the following guide as a reference: <https://www.build-electronic-circuits.com/reflow-soldering/>.

1. Using the soldering mask, apply reflow solder paste only to the grid pattern of the copper pads on PCB-1 (Figure 2A). Make sure paste application is clean and there is no runoff connecting any pads. Clean up overflow with a paper towel if necessary.
2. With tweezers, place surface-mount LEDs onto the pads in the correct orientation (angled notch indicating anode must be on top left) (Figures 2B–2D).
3. Place PCB-1 onto the hot plate and heat on maximum temperature for 2–5 min. Inspect LED alignment and adjust with tweezers if necessary. Once you notice the solder paste turn a metallic color, wait an additional 1–2 min. Carefully and safely remove board from the hot plate and let cool at room temperature for 5–10 min.
4. Clean the solder mask with a paper towel and save for future use.

⚠ CRITICAL: Make sure to place the LEDs onto the pads in the correct orientation (anode left, cathode right).

Note: If using LEDs other than the blue-light LEDs specified in the [Key Resources Table](#), they must be package PLCC-4 or PLCC-2. Note that the notch indicator standards may vary between manufacturers, so be sure to place the LED onto the pads in the correct orientation.




Figure 2. Workflow to Reflow Solder LEDs onto PCB-1 for the 24-Well LAVA Board Format

(A) Representative image of soldering paste application to PCB-1.

(B) Representative image of LED placement onto PCB-1.

(C) Example of correct CLM1B Cree LED placement. Anode marking must face top left. For 24-well LAVA board, each well is illuminated with a cluster of five LEDs connected in series. Single LED circled in red.

(D) Schematic of a single LED denoting proper orientation.

(E) Schematic of solder pad placement on PCB-1. All dimensions are in inches.

We highly recommend testing a single LED prior to soldering the entire PCB-1 to ensure proper orientation.

Step 2: Solder Through-Hole Components Using Standard Soldering

⌚ Timing: 1 h

In this step, you will attach all of the through-hole components to PCB-1 and PCB-2 via standard soldering techniques. The placement for all remaining through-hole components is marked on PCB-1 and PCB-2. The component outline indicates the side (PCB top vs. bottom) onto which the component should be physically placed. The leads of the component pass through the matching holes, and the component is soldered on the opposite side from that on which it is physically placed. While soldering, make sure that each component is flush with the PCB.

If a component is accidentally soldered in the wrong orientation, it should be removed with de-soldering braid or a solder sucker and re-soldered correctly. We recommend this Sparkfun guide as a reference for soldering techniques: <https://learn.sparkfun.com/tutorials/how-to-solder-through-hole-soldering/all>

5. Solder the following electrical components onto PCB-1, ensuring proper orientation:
 - a. Fan terminal blocks (×3).
 - i. Solder with the wire opening facing outward (as indicated in Figures 3A and 3B).
 - b. LED driver (TLC5947).
 - i. First, solder female headers onto PCB-1. You will need ×4 15-pin headers and ×1 6-pin header. To match the hole pattern, you will need to gently pull out every 4th pin from the headers with pliers (Figure 3C).




Figure 3. Representative Images for the Step-by-Step Attachment of Each Electrical Component to PCB-1 via Standard Soldering Techniques

(A and B) (A) Fan terminal block insertion and (B) orientation.
 (C) Female headers cut to the insert dimensions and every 4th pin removed.
 (D) Male headers with every 4th pin removed and inserted into female headers.
 (E–G) (E) LED Driver orientation with (F) top soldering, and (G) bottom soldering.
 (H) Male power and data transfer header orientation.

- ii. Next, prepare the male headers with every 4th pin similarly removed (Figure 3D). Insert male headers (side with longer pins) into female header (Figure 3E).
 - iii. Place the TLC5947 LED driver through these male headers. Take care to ensure proper orientation of TLC5947 chip (Figure 3E). Solder the headers (Figure 3F).
 - iv. Flip PCB-1 and solder the bottom leads (Figure 3G). Be sure not to short any of the connections.
- c. Power and data transfer headers (×2 4-pin male headers). Ensure correct placement of these headers and solder (Figure 3H).
6. Solder the following electrical components onto PCB-2, ensuring proper orientation:
 - a. Power and data transfer headers (×2 4-pin female headers, as indicated in Figure 4A).
 - b. DC barrel plug connector (Figures 4B and 4C).
 - c. 5V and 12V voltage regulators (TRACO power). Ensure polarity indicator (dot) lines up with indicator dot on PCB-2 (Figures 4D and 4E).
 - d. SPDT power switch (location marked on PCB-2).




Figure 4. Representative Images for the Step-by-Step Attachment of Each Electrical Component to PCB-2 via Standard Soldering Techniques

- (A) Female power and data transfer headers.
 (B and C) (B) DC barrel plug connector orientation and (C) attachment.
 (D) TRACO TSR 1-2450 power voltage regulator.
 (E) TRACO TSR 1-24120 power voltage regulator.
 (F) Female header orientation on bottom of PCB-2.
 (G) Raspberry Pi Zero W orientation at bottom of PCB-2 and attached via male headers.

- e. Raspberry Pi Zero W
 - i. First, solder female headers onto PCB-2 (×2 20-pin female headers, as indicated in [Figure 4F](#)).
 - ii. Then, place male headers into the soldered female headers. Place Raspberry Pi Zero W through these male headers (ensure proper orientation, as indicated in [Figure 4G](#)) and solder the leads.
 - iii. Lastly, secure the Raspberry Pi to PCB-2, and secure PCB-2 to PCB-1, using the hexagonal plastic standoffs (×8) and 2–56 screws (×16). Ensure that the corresponding headers mate together between PCB-1 and PCB-2.

△ **CRITICAL:** Ensure the correct orientation of each component before soldering. Take care not to short any connections while soldering leads with close proximity.

Step 3: Attach Heat Sink to PCB-1

⌚ Timing: 1–1.5 h




Figure 5. Representative Images to Attach Heat Sink to PCB-1
(A and B) Activated epoxy addition to (A) heat block and (B) copper region of PCB-1.
(C) Depiction of attachment orientation

In this step, you will attach a heat sink to bottom of PCB-1. The heat sink acts to draw away and disseminate the heat generated by the LEDs. This is necessary for long-term use, to prevent overheating and increase device lifespan.

7. Attach heat sink to the bottom of PCB-1 using Arctic Silver thermal epoxy.
 - a. Mix the two epoxy components together (1:1) and quickly apply a thin layer to heat sink (Figure 5A) and bare copper region of PCB-1 (Figure 5B).
 - b. Sandwich the head sink and PCB-1 surfaces (Figure 5C).
 - c. Make sure heat sink is centered and wait 1 h or more to solidify.

⚠ **CRITICAL:** Ensure no epoxy seeps through the vias onto the top surface of PCB-1. If it does, gently wipe away before epoxy solidifies.

Step 4: Assemble Laser-Cut and 3D-Printed Components

⌚ Timing: 1 h

In this step, you will begin to assemble the non-electrical components of the LAVA board. A schematic of the laser-cut base (Figure 1, part 9) is represented in Figure 6A. Note that this part is not symmetric, and the square orientation indicator marks the left side of the base, as viewed by looking at the top of the LAVA device. A schematic of the laser-cut fan holder (Figure 1, part 15) is depicted in Figure 6B. These custom laser-cut components are designed to compactly and efficiently house the electrical components and heat block.

8. Assemble LAVA board base
 - a. Orient base (Figure 1, part 9) so that the indicator square faces left. Insert rubber foot pegs (×4) into base from the bottom, through the four larger holes (Figures 7A and 7B).




Figure 6. Schematics of Laser-Cut Components for LAVA Board Base Structure

(A) Schematic of laser-cut base with color-coded depiction of each hole component.
(B) Schematic of laser-cut fan holder with color-coded depiction of each hole component.

- b. Screw vibration-damping mounts (×4) onto the base (part 9) using 8–32 screws, through the four smaller holes (Figure 7C). Then, screw round metal standoffs (×4, Figure 1, part 10) into each vibration-damping mount with an 8–32 setscrew (Figures 7D and 7E).
9. Assemble and attach fan components
 - a. Screw the individual fans (×3, Figure 1, part 16) into the laser-cut fan holder (Figure 1, part 15) using 6–32 screws and nuts (Figure 7F). Make sure the fan airflow arrow points in the correct direction and that wires face upwards (Figure 7G).
 - b. Trim fan wires to ~ 0.5" (1.5 cm) in length and use right-angle brackets and 8–32 screws and nut to attach fan holder (Figure 1, part 15) onto the base (Figure 1, part 9). With wire strippers, strip the end (~ 3 mm) of each fan wire (Figure 7I).
10. Assemble the walls of the LED driver cover (Figure 1, part 17) using superglue. The cover will be placed on top of the LED driver to prevent accidental shortage.
11. Cut the 80° LSD diffuser sheet to match the 3D-printed light guides. Cut one diffuser to fit between the two light guides (Figure 1, part 4, 4.5 × 3.0 inch) and one for the top light guide (Figure 1, part 2, 4.8 × 3.3 inch).

Step 5: Attach the LAVA Electronics to the Remaining Hardware Components

⌚ Timing: 0.5 h

In this step, you will attach all of the remaining electrical components to the LAVA board base and complete the hardware fabrication portion of the design.

12. Attach PCB-1 and light guide to LAVA board base.
 - a. Place PCB-1 onto the ×4 metal standoffs (Figure 1, part 10).
 - b. Place bottom light guide (Figure 1, part 5) onto PCB-1, taking care to center it on the wells.
 - c. Place ×4 8-32 screws through the light guide screw holes and screw into standoff, thereby sandwiching PCB-1 in between.
13. Insert fan wires into the corresponding terminal block, ensuring correct orientation, and tighten set screw with small flathead screwdriver.
14. Add the intermediate diffuser (Figure 1, part 4) on top of the bottom light guide (Figure 1, part 5) and sandwich between the top light guide (Figure 1, part 3). Place the final diffuser (Figure 1, part 2) onto the top light guide. 3D-printed light guides should click together, though you may need to apply some force.




Figure 7. Representative Images for Step-by-Step Assembly of LAVA Board Base Components

- (A and B) Rubber foot peg (A) part and (B) orientation from the bottom.
- (C) Vibration-damping mount orientation.
- (D) 8-32 set screw orientation.
- (E) Round metal standoff orientation.
- (F) Attachment of fans to laser-cut holder.
- (G) Fan orientation, arrow corresponding to air flow.
- (H) Attachment of fan block to base.
- (I) Fan block and base orientation with optimal wire cut length and exposure.

⏸ Pause Point: At this point, the LAVA board hardware components should all be assembled, and the hardware components of the device are complete. Step 6 can be completed at any time after device fabrication.

Step 6: Software Control of LAVA Board

⌚ Timing: 1.0–2.0 h

In this step, you will upload the device operating software to the LAVA board, calibrate the LED output, and configure the provided GUI for spatiotemporal control of blue-light stimulation. We have provided the general software to initialize the LAVA boards and communicate between the GUI and Pi to upload patterns of continuous light, light pulses, or light functions. If you wish to

customize the light presentation further, you may need to design your own code/GUI to control the LEDs and Pi. There are many resources available for Raspberry Pi programming; however, we anticipate that the provided software and GUI to satisfy most user needs.

15. Flash the operating software (OS) image to micro SD card.
 - a. Download the provided disk image (raspberrypi.dmg, 7.95GB file size) from <https://github.com/LAVAbord/LAVA>
 - b. Insert a blank 8 GB micro SD card into your computer.
 - c. Download a flash software. We recommend Etcher. <https://www.balena.io/etcher/>
 - d. Run Etcher and follow instructions to flash the OS disk image to the SD card. Be sure to select the correct target drive that corresponds to the SD card.
 - e. Insert the micro SD into the Raspberry Pi. Power LAVA board and wait 1 min for the Pi to turn on. The LED light sequence will change (ex. B01 blinks), and you will see APPLE_PI WiFi network appear. If not, the SD card flash was not successful.

Note: Alternatively, you can use the command line to flash the disk image to the SD card. You will need to unmount the SD card and reformat as FAT32. This may take some time. Once complete, eject the card and insert into the Raspberry Pi micro SD slot.

16. LED light output calibration
 - a. In the following steps, the calibration script LED_calibration.py is run on the Raspberry Pi to calibrate the LED output. PWM values are sent to each well (starting with well A1, A2, etc.) and decrease sequentially from 4095 (maximum intensity) to 0 (off): 4095, 4000, 3800, 3600, 3400, 3200, 3000, 2800, 2600, 2400, 2200, 2000, 1800, 1600, 1400, 1200, 1000, 800, 600, 400, 200, 0. For each PWM value and each well, the illumination intensity should be recorded with a power meter. The script is configured to allow the user 20 s to align the power meter and 5 s to record each PWM measurement. These settings can be changed as desired by opening the LED_calibration.py and changing sleep() values.
 - b. Power the LAVA device and connect to APPLE_PI WiFi network (password: raspberry)
 - c. Wirelessly SSH into the Pi. In Mac use Terminal, or in Windows download a BASH terminal (we recommend ubuntu, <https://ubuntu.com/>). Enter the following into the command line:
 - i. `ssh pi@192.168.4.1`
 - ii. `password = raspberry`
 - d. Stop the LED driver process on the Pi. Enter the following into the command line:
 - i. `htop`.
 - ii. record the PID corresponding to the LED driver (see "Command" column"). Execute the following command, and substitute 'PID' with the recorded number.
 - iii. `sudo kill PID`.
 - e. Now run the following python script. Run the internal python calibration code by entering.
 - i. `python LED_calibration.py`
 - ii. To view or modify this file, enter `nano LED_calibration.py`
 - f. Record the light intensity data for each PWM with a power meter. In the terminal, you should see the 12-bit PWM currently being executed.
 - g. Generate the calibration curve where the X-axis is PWM (0-4095) and Y-axis is measured light intensity ($\mu\text{W}/\text{mm}^2$). Convert the light intensity recorded into $\mu\text{W}/\text{mm}^2$ (depending on the area of the measurement probe). An example calibration data is depicted in [Figures 8A](#) and [8B](#).
 - h. Apply a linear trend and record the slope (m) and y-intercept (b) for later use.

△ CRITICAL: The calibration values (m,b) need to re-measured each time the hardware layout of the LAVA board is modified. For example, if LEDs of different colors or




Figure 8. Example CLM1B Blue LED Calibration Curve

(A) Calibration curve for 24-well LAVA board with two different light guide thicknesses.

(B) Calibration curve for a 96-well LAVA board. Light intensity recorded using a PM100D compact power and energy meter console (Thorlabs) with a standard photodiode power sensor (S120C, Thorlabs). Curve slope and y-intercept used in software design to designate individual well intensity.

manufacturers are used or the light guide thickness or diffuser type is changed, the devices need to be re-calibrated.

Optional: Change the name of the WiFi network (default is APPLE_PI).

- a. Power the LED board and connect to APPLE_PI WiFi network (password = raspberry).
- b. Wirelessly SSH into Pi (see step 6.16c).
- c. Configure the access point host software (hostapd) by entering
 - i. `sudo nano/etc/hostapd/hostapd.conf`
 - ii. Change the ssid to desired WiFi name. Do not modify any other lines.
- d. Use the keyboard combination ctrl-O then "enter" to save the file, then ctrl-X to exit the nano text editor.
- e. Reboot the Pi and you will see the new Wifi name appear. Enter
 - i. `sudo reboot`

Note: At this point, the LAVA device fabrication is complete. LAVA device illumination accuracy should be monitored every 3–6 months with a power meter. Re-calibrate if necessary (step 6.16)

Step 7: Optogenetic Cellular Experiments with LAVA Boards

⌚ Timing: variable, user defined

The LAVA boards are versatile, user-friendly devices that are useful for numerous optogenetic experiments in 24- and 96-well plate formats. The provided GUI (JarJarBlinks) offers precise control of LED light intensity and timing over the entire length of an experiment. LAVA boards can be placed directly in any standard incubator and can run for any duration of experiment. Typical LAVA boards last at least 6 months in an incubator environment and are easy to replace. In this step we will outline the GUI control of LAVA boards and generic protocols for continuous, pulsed, and dynamic optogenetic experiments.

17. GUI control and pattern upload
 - a. Turn on LAVA board and wait ~1 min for boot to complete.
 - b. Connect to the LAVA board WiFi network (default = APPLE PI) and set up the wireless SSH connection at least once (see step 6.16c).

- i. You can connect to the LAVA board just by selecting the Pi WiFi network (password = raspberry) from this point forward, no need to SSH.
- c. Download JarJarBlinks.jar here <https://github.com/LAVABoard/LAVA>
- d. Open the JarJarBlinks application, choose the correct plate format, and enter the slope (m) and y-intercept (b) from the LED calibration (step 19b). Be sure to use the calibration values for the corresponding LAVA board format and light guide thickness.
- e. Configure the pattern to be uploaded.
 - i. Continuous illumination: Choose the “Const” designation for each well of interest. Enter the light intensity I in the open column (default device rang from 0.0 – 20.0 $\mu\text{W}/\text{mm}^2$).

Note: continuous intensity above 2.0 $\mu\text{W}/\text{mm}^2$ may exhibit cellular toxicity.

- ii. Pulsed illumination: Choose the “Blink” designation for each well of interest. Enter the I_{min} (typically 0.0) and I_{max} (experiment dependent). Enter the duty cycle (percentage of time “on” per period) and period (in seconds).

Note: for CRY2 applications, the signal can be pulsed every 10 min, corresponding to the twice the half-life of cluster dissociation. If using another optogenetic system, make sure to characterize the association kinetics for your system to determine the minimum period necessary for your application. In comparison to continuous illumination, higher I_{max} intensities can be used for pulsed illumination while avoiding phototoxicity.

- iii. Complex illumination patterns: Choose the “Func” designation for each well of interest. Enter the linear or sinusoidal function parameters of interest and for desired time interval. When complete, select “add” function. Multiple functions can be combined to generate complex temporal light patterns.
- f. Upload experiment pattern to LAVA board device by selecting the “Submit and Upload” button at the bottom of the screen.
 - i. If successful, the pattern should upload and appear within 5 s.
- g. Begin cellular experiment with optogenetic pattern. After seeding the cells on the recommended imaging plates ([Key Resources Table](#)), place the plate directly on the LAVA board when you want to begin illumination and place the device in the incubator for long-term culture.
- h. After illumination, end-point analysis, such as immunostaining, flow cytometry, or transcriptomics analysis, can be performed.

Note: Java 8 or above must be installed on your computer to open the JarJarBlinks application. Additionally, we recommend storing the LAVA board outside of the incubator when not in use, although continuous storage inside the incubator is also possible.

EXPECTED OUTCOMES

Successful execution of this fabrication protocol will produce a fully functional LAVA board illumination device ([Figure 1](#)). The default LAVA devices are capable of controlling blue-light intensity and timing for a multitude of potential applications in optogenetic experiments. The addition of user-defined photomasks allows for spatial control of blue-light activation. LAVA boards can operate in any standard incubator or benchtop environment. LAVA boards are easily incorporated into standard cell culture formats or protocols to enable high-throughput optogenetic experimental design without the need for a conventional microscope. Broader applications of LAVA board devices include spatiotemporal control of protein activation, localization, presentation, channel manipulation, gene expression, and other novel optogenetic toolkits. For a complete investigation into device design, characterization, and utilization, please refer to [Repina et al., 2020](#).

LIMITATIONS

This protocol describes assembly of the default LAVA devices to control blue-light photopatterning of Cryptochrome-2 (Cry2) (Repina, et al., 2020). For application to other optogenetic systems, the blue LEDs can be readily substituted with other wavelengths, such as UV, green, red, or far-red. Depending on the physical dimensions and forward voltage of the LED, PCB-1 and power supply choice may need to be modified. In addition, default LAVA devices are only capable of controlling a single LED color but can be extended to multicolor applications by using multiple TLC5947 chips. Additionally, we have only provided design materials for 24-well and 96-well LAVA board devices. Any other plate format will require modifications to the PCB-1 layout and the 3D-printed light guides. Also, due to the 24-channel limit of the TLC5947 chip, the current 96-well LAVA device cannot control each individual well, but instead four wells that are connected in series (2 sets of 4 for each column, 24 variable well formats per plate). Lastly, the LAVA board is most compatible with end-point measurements, such as fixation and immunostaining, or harvesting of cells for flow cytometry or transcriptomic analysis. The device could be used for live real-time imaging with an upright microscope, however the microscope sample stage or optical configuration may need to be adapted to accommodate the LAVA board.

TROUBLESHOOTING

Problem

Light guides do not snap together or fit to desired TC plate

Potential Solution

We tried to design the light guides to accommodate most 3D printers and TC plate formats. However, due to variabilities between 3D printers, parts may not fit together properly. We provide the SolidWorks files for the 3D printed components that can be modified to fit different 3D printers and use cases.

Problem

I assembled the LAVA device, plugged it in, and nothing turns on!

Potential Solution

The things that should initially turn on are: the fans, LED indicators on TLC5947 board, and the LEDs. If nothing turns on, make sure the power supply is plugged in and power switch is in the 'on' orientation. If the LEDs do not turn on, verify that they are soldered in the correct orientation and, using a volt meter, that power is being delivered to them.

If the LEDs turn on but fans do not, verify that you are using the correct power supply. The fans are powered with 12V through a DC voltage regulator (TSR-1-24120). For them to power on, the power supply must be at least 15V. If you are using LEDs with a low forward voltage and your power supply is lower than this value, then you can either (1) power the fans directly from the power supply if the power supply provides 12V or lower, or (2) use a different DC voltage regulator that takes a lower input voltage, such as TSR 1-2490. For option (1), solder a wire from the positive terminal of the barrel plug connector to the positive fan terminal. For option (2), replace the TSR-1-24120 with TSR 1-2490. This will provide 9V to the fans, driving them at a slower speed but will still be sufficient for cooling.

For the Raspberry Pi to turn on, the user must proceed with the software configuration and installing the Raspberry Pi SD card.

Problem

I downloaded JarJarBlinks.jar but it does not open

Potential Solution

Ensure that Java and Java SE Development Kit (JDK) 8 or higher is installed on your computer

Problem

The LED output is not bright enough for activating my optogenetic system

Potential Solution

The TLC5947 chip delivers 15 mA to each of the 24 channels. The output can be increased to 30 mA by soldering an additional 3.3 kOhm through-hole resistor onto the TL5947 chip (see the TLC5947 datasheet and Adafruit page for more details: <https://www.ti.com/lit/ds/symlink/tlc5947.pdf>, <https://www.adafruit.com/product/1429>). This will approximately double the light output. Furthermore, the lightguide thickness and number of diffusers can be reduced at the expense of illumination uniformity. Lastly, the light guides can be spray-painted with reflective paint to reduce light absorption by the black plastic.

Problem

I accidentally plugged in the wrong PSU, what should I do?

Potential Solution

If the LAVA device still turns on and patterns are able to be uploaded, then the device is fully operational. If the device overheated, the TLC5947 chip likely needs to be replaced. The chip is easily removable as it is secured to the board with removable headers. Detach the damaged TLC5947 chip and insert a new chip with soldered headers (Figures 3E and 3F). To verify board functionality, the accuracy of the light output should be verified with a power meter, and re-calibrated if necessary (step 6.16).

Problem

After long-term use, LAVA device stops displaying uploaded patterns

Potential Solution

After months of use in a 37°C humidified incubator, the TLC5947 chip or Raspberry Pi microcontroller may stop functioning properly. Verify that LED indicators are functioning as normal. If not, we recommend replacing both components. They are connected to PCB-1 and PCB-2 via headers to enable quick replacement.

Problem

I smell a burning smell, what is happening?

Potential Solution

Likely an electrical component was shorted because it was soldered in the wrong orientation, or a piece of metal or aluminum foil touched the electrical components and caused a short. If this occurs, we recommend replacing the TLC5947 chip and Raspberry Pi as described above.

RESOURCE AVAILABILITY

Lead Contact

Further information and requests for resources and reagents should be directed to and will be fulfilled by the Lead Contact, David V. Schaffer (schaffer@berkeley.edu).

Materials Availability

All custom design files and necessary materials can be found at <https://github.com/LAVABoard/LAVA>

Data and Code Availability

All custom code and device operating software can be found at <https://github.com/LAVABoard/LAVA>

ACKNOWLEDGMENTS

We thank Christopher Myers, Mitchell Karchemsky, and Rundong Tian at the UC Berkeley CITRIS Invention Lab for assistance and discussions of rapid prototyping design and techniques. We also thank Danqing Zu and Xiaoping Bao for help with device fabrication and photographs. Funding supporting this work was provided by the U.S. National Institutes of Health (R01NS087253 to D.V.S.), the U.S. National Science Foundation (to N.A.R. and H.J.J.), and the Siebel Scholars Foundation (to N.A.R.).

AUTHOR CONTRIBUTIONS

N.A.R. conceived the study, designed devices and performed experiments, performed analysis, and wrote the manuscript. H.J.J. performed experiments and wrote the manuscript. T.M. designed software control and the graphical user interface. R.S.K. conceived the study. D.V.S. conceived the study and wrote the manuscript.

DECLARATION OF INTERESTS

N.A.R., T.M., and D.V.S. are co-inventors on related intellectual property.

REFERENCES

Repina, N.A., McClave, T., Johnson, H.J., Bao, X., Kane, R.S., and Schaffer, D.V. (2020). Engineered illumination devices for optogenetic control of cellular signaling dynamics. *Cell Reports* 37, 107737.