

Multiplication and Growth Inhibition Activity Assays for the Zoonotic Malaria Parasite, Plasmodium knowlesi

Franziska Mohring¹, Thomas A. Rawlinson², Simon J. Draper² and Robert W. Moon¹*

¹Faculty of Infectious and Tropical Diseases, London School of Hygiene & Tropical Medicine, London WC1E 7HT, United Kingdom; ²The Jenner Institute, University of Oxford, OX5 7DQ, United Kingdom

*For correspondence: Rob.Moon@lshtm.ac.uk

[Abstract] Malaria remains a major cause of morbidity and mortality globally. Clinical symptoms of the disease arise from the growth and multiplication of *Plasmodium* parasites within the blood of the host. Thus *in vitro* assays to determine how drug, antibody and genetic perturbations affect the growth rate of *Plasmodium* parasites are essential for the development of new therapeutics and improving our understanding of parasite biology. As both *P. falciparum* and *P. knowlesi* can be maintained in culture with human red blood cells, the effect of antimalarial drugs and inhibitory antibodies that target the invasion capacity of *Plasmodium* parasites are routinely investigated by using multiplication assays or growth inhibition assays against these two species. This protocol gives detailed step-by-step procedures to carry out flow cytometry-based multiplication assays and growth inhibition activity assays to test neutralizing antibodies based on the activity of the parasite enzyme lactate dehydrogenase of *Plasmodium knowlesi* adapted to human red blood cell culture. Whilst similar assays are well established for *P. falciparum*, *P. knowlesi* is more closely related to all other human infective species (Pacheco *et al.*, 2018) and so can be used as a surrogate for testing drugs and vaccines for other malaria species such as *P. vivax*, which is the most widespread cause of malaria outside of Africa, but cannot yet be cultured under laboratory conditions.

Keywords: *Plasmodium knowlesi*, Malaria, Multiplication assay, Growth inhibition activity assay, Drug screening, Invasion

[Background] *Plasmodium* blood stage parasites are responsible for the clinical symptoms of malaria, including high periodic fever and anemia. *Plasmodium* merozoites invade red blood cells, grow and multiply intracellularly until the blood cells burst and daughter merozoites are released to infect new red blood cells. The merozoite is briefly extracellular between egress and invasion of red blood cells, and this is a key target for blood stage vaccines as it is directly exposed to antibodies in the blood. Several invasion proteins are in the focus of vaccine development including *Plasmodium falciparum* merozoite surface protein 1 (MSP1), MSP2, apical membrane antigen 1, reticulocyte binding homologue 5, erythrocyte binding antigen (EBA-175) and *Plasmodium vivax* Duffy binding protein (Genton *et al.*, 2003; Thera *et al.*, 2011; Koram *et al.*, 2016; Payne *et al.*, 2017a and 2017b).

Investigation of antimalarial drugs or inhibitory antibodies that target the blood stages of *Plasmodium* parasites are carried out by using multiplication or growth inhibition activity assays. Flow

cytometry-based invasion/multiplication rate assays have previously been described for various *Plasmodium* species (Basco *et al.*, 1995; Bhakdi *et al.*, 2007; Xie *et al.*, 2007; Izumiyama *et al.*, 2009; Bei *et al.*, 2010; Moon *et al.*, 2013). The advantage of flow cytometry-based assays is that they provide absolute measurements of parasite numbers, so are particularly good for examining changes in parasitemia between different parasite lines. As parasitemia increase only occurs after the release of merozoites from schizonts resulting in invasion and formation of new ring stage parasites—the flow cytometry-based assays are particularly useful for examining this transition. They can be expressed either as % of control, or as an absolute value like fold-growth or parasite multiplication rate.

The activity of the enzyme lactate dehydrogenase (LDH) was first measured as a means to detect the presence of *Plasmodium falciparum* as a fast alternative to microscopy screening (Makler and Hinrichs, 1993). The LDH assay is based on the fact that *Plasmodium* LDH can rapidly convert lactate to pyruvate by employing the NAD analog 3-acetylpyridine NAD (APAD) as a coenzyme, whereas human erythrocyte LDH uses APAD instead of NAD at a much smaller rate (200-fold slower). Measuring the malarial LDH activity in the presence of APAD is a specific and sensitive method for the detection of *Plasmodium* parasites (Basco *et al.*, 1995).

Growth inhibition activity assays based on the LDH activity are used as standard to investigate vaccine candidate antigen activity (Kennedy *et al.*, 2002). LDH activity assays are often simpler than flow cytometry-based assays, but measure the presence of parasite derived LDH rather than directly measuring the number of infected cells. As such they can only provide relative growth rate values, so are best suited for comparison of multiple treatments of specific parasite lines e.g. for drug or antibody inhibition assays. Relative growth rates are normally expressed as a % of an untreated control.

This protocol describes the methodology for both multiplication assays based on flow cytometry and growth inhibition assays based on LDH activity of *Plasmodium* blood stage parasites (Figure 1). Here, the focus is on the simian malaria parasite *Plasmodium knowlesi*, but they can easily be adapted to other *Plasmodium* species by adjusting incubation times based on the life cycle length and specific culture conditions. *P. knowlesi* has recently been adapted to grow in human Duffy positive blood (Moon *et al.*, 2013) and is therefore the second human malaria parasite with a long-term *in vitro* culture system, next to *P. falciparum*. Due to its close ancestry and biology, it is a suitable model to study invasion genes of *P. vivax*, which lacks a long-term *in vitro* culture system.






Figure 1. Schematic showing the procedures of multiplication and growth inhibition assays for *Plasmodium knowlesi*

Materials and Reagents

- 1. 1.5 ml micro centrifuge tube (Eppendorf, catalog number: 0030120086)
- 2. 15 ml centrifuge tube (Falcon, Corning, catalog number: 352196)
- 3. 24-well plates (CytoOne, Starlab, catalog number: CC7672-7524)
- 4. 96 flat-bottom plates (CytoOne, Starlab, catalog number: CC7672-7596)
- 5. 96-well flat/half area tissue culture cluster plates (Corning, catalog number: 3697)
- 6. Aluminium foil
- 7. *Plasmodium knowlesi* A1-H.1 wild type (Mike Blackman, Francis Crick Institute London) (Moon *et al.*, 2013)
- 8. Duffy positive (Fy+) human red blood cells
- 9. RPMI-1640 Media (Sigma-Aldrich, catalog number: R5886)
- 10. L-glutamine (Sigma, catalog number: G7513-100ML), -20 °C
- 11. Sodium bicarbonate (Sigma-Aldrich, catalog number: S5761)
- 12. Dextrose (Sigma, catalog number: G7021)
- 13. Hypoxanthine (Sigma-Aldrich, catalog number: H9636)
- 14. Albumax II (Gibco, catalog number: 11560376)
- 15. Horse serum (PAN BIOTECH, catalog number: P30-0711), -20 °C
- 16. Nycodenz (Progen, catalog number: 1002424), room temperature
- 17. Paraformaldehyde (Pierce 16% Formaldehyde [w/v]) (Thermo Fisher, catalog number: 28906) room temperature
- 18. PBS tablets (MP Biomedicals[™], catalog number: MP2810305), room temperature

- 19. Glutaraldehyde Solution Grade I, 25% in water (Sigma-Aldrich, catalog number: G5882-10X1ML)
- 20. Triton X-100 (Roche, Sigma, catalog number: 11332481001)
- 21. Ribonuclease A (MP Biomedicals[™], catalog number: 0219398050)
- 22. SYBR[®] Green I nucleic acid gel stain (Life Technologies, Sigma-Aldrich, catalog number: S9430-5ML)
- 23. Tris HCl, Trizma[®] hydrochloride solution 1 M, pH 8.0, (Sigma-Aldrich, catalog number T3038-1L)
- 24. Sodium L-lactate (Sigma-Aldrich, catalog number: 71718)
- 25. 3-acetylpyridine adenine dinucleotide (APAD) (Sigma-Aldrich, catalog number: A5251)
- 26. Phenazine ethosulfate (Sigma-Aldrich, catalog number: P4544)
- 27. Nitro Blue Tetrazolium tablets (Sigma-Aldrich, catalog number: N5514)
- 28. 4-[7-[(dimethylamino)methyl]-2-(4-fluorphenyl)imidazo[1,2-a]pyridin-3-yl]pyrimidin-2-amine; compound 2 (Michael Blackman, Francis Crick Institute, London, UK)
- 29. Diaphorase from Clostridium klyveri (Sigma-Aldrich, catalog number: D5540-1.5KU)
- 30. Custom Modified RPMI media w/o glutamine (Life Technology Brand, see Recipes), 4 °C
- 31. Fixative: 4% paraformaldehyde with 0.4% glutaraldehyde (see Recipes)
- 32. LDH substrate buffer, pH 7.5 (see Recipes)
- 33. Nitro Blue Tetrazolium (NBT) solution (see Recipes)
- 34. 3-Acetylpyridine Adenine Dinucleotide (APAD) stock solution (10 mg/ml) (see Recipes)
- 35. Diaphorase stock solution 50 units/ml (see Recipes)

Equipment

- 1. Becton Dickenson LSR-II Flow Cytometer or equivalent
- 2. Upright binocular compound light microscope with 100x oil objective
- 3. Multichannel pipette (8-Channel Pipette, 30-300 µl) (ErgoOne®, catalog number: S7108-3300)
- 4. Plate centrifuge (Eppendorf, model: 5810R, catalog number: 5811000660)
- 5. Titramax 100 Flatbed shaker (Heidolph Instruments, catalog number: 544-11200-00)
- 6. Microplate Spectrophotometer Spectra Max 340P
- 7. Class II Microbiological Safety Cabinet
- 8. -20 °C freezer
- 9. -70 °C freezer

Software

- 1. FACSDiva 6.1.3 software
- 2. FlowJo, https://www.flowjo.com/
- 3. Flowing software, <u>http://flowingsoftware.btk.fi/</u>

© Copyright Mohring et al. This article is distributed under the terms of the <u>Creative Commons Attribution License</u> (CC BY 4.0).

Procedure

The protocol of thawing *Plasmodium knowlesi* A1-H.1 parasite depends on the source of parasites and needs to be checked with the person that froze the sample. Parasites are maintained in a flask gassed with a mixture of 90% N₂, 5% O₂ and 5% CO₂ at 37 °C, monitored by microscopy using Giemsa-stained thin films, and parasitaemia maintained at between 0.5% and 10%. All procedures need to be carried out with sterile equipment, materials and reagents with aseptic techniques. Local safety policies must be followed for all work involving human infectious agents.

A. Parasite multiplication assay

- 1. Synchronize *P. knowlesi* parasites via purification with Nycodenz
 - a. Transfer 5 ml of 55% Nycodenz working solution to a 15 ml conical tube and warm up to room temperature (check Note 1).
 - b. Centrifuge down a high parasitemia (4-10%) *P. knowlesi* 50 ml culture with 2% hematocrit at 900 *x g* for 4 min at high brake/acceleration at room temperature.
 - c. Resuspend parasite pellet at 50% hematocrit in RPMI.
 - d. Carefully lay 2 ml of this culture onto 5 ml Nycodenz in a 15 ml tube.
 - e. Centrifuge at 900 x g for 12 min with low brake/acceleration (check Note 2).
 - f. Transfer the brownish colored top layer schizonts to a new conical tube and wash with RPMI to remove Nycodenz (see Figure 2).
 - g. Incubate schizonts in culture media with 1 µM Compound 2 for 2-3 h (check Note 3).
 - h. Wash off Compound 2 with RPMI (centrifuge at 900 x g for 4 min at high brake/acceleration at room temperature) and transfer schizonts back to culture (with 2% hematocrit red blood cells). The number of harvested schizonts depends on the starting parasitemia and age of the parasites (check Note 4).




Figure 2. Schizont enrichment with Nycodenz

- 2. In the following cycle, when parasites are again reaching the schizont stage, set up the multiplication assay in a 96-well plate (see Figure 3 for the plate layout).
 - a. Fill out all outer wells in the 96-well plate with 100 µl of RPMI or sterile water. This ensures inner wells are not affected by evaporation.
 - b. Plate out 75 µl complete growth media alone (or with vehicle control) or with 2x concentration of drug or antibody to be tested. Plate out 75 µl of the parasite culture per well as indicated in the plate layout. The plate layout can be customized depending on the individual experiment (see Figure 1 for plate layout).
 - c. Prepare a culture with young schizonts at around 1% parasitemia and 4% hematocrit.
 - i. Purify synchronous schizonts with Nycodenz as described in Step A1.
 - ii. Resuspend parasite pellet with 1 pellet-volume complete media to 50% hematocrit.
 - iii. Prepare complete media with 4% red blood cells (*e.g.*, 5 ml media + 200 μl red blood cells).
 - iv. Transfer 1% schizonts to media + 4% red blood cells (around 4-6 μl of 50% schizonts to 5 ml, depending on the parasitemia of enriched schizonts that is usually between 80 and 90%) and mix well.
 - v. Confirm the parasitemia by counting at least 400 cells of a blood smear.
 - d. Add 75 µl of the culture to each well that contains 75 µl media and mix by pipetting.
 - e. Plate out 150 µl of uninfected red blood cells (2% hematocrit) as a control.
 - f. Mix by pipetting up and down and transfer 50 μl of each well to a new 96-well plate. Carry out Step A3. if the parasites can be measured with FACS within the next 30 min or with Step A4. if parasites are fixed and measured up to 1 week later (check Notes 5, 6, 7).
 - g. Incubate the 96-well plate with 100 μl parasite cultures for one growth cycle (24 h) under standard parasite culture conditions (37 °C, 3% O₂ and 3% CO₂ and 94% Nitrogen).
 - h. After 24 h incubation, mix each well and transfer 50 μl of the remaining 100 μl culture to a new 96-well plate. This is plate 2 (final parasitemia). Continue with Step A3. if the parasites can be measured with FACS within the next 30 min or with Step A4. if parasites are fixed and measured up to 1 week later (check Notes 5, 6, 7).




Figure 3. Example of the plate layout

- 3. Prepare samples for flow cytometry for live cell flow cytometry
 - a. Prepare filtered PBS and a 1:5,000 dilution of SYBR Green I in PBS.
 - Add 50 μl of SYBR Green I dilution to the 50 μl of parasite culture and incubate for exactly 30 min at room temperature.
 - c. Dilute stained cultures 1:5 in filtered PBS by adding 40 µl of stained cells to 160 µl of PBS and run on a FACS machine.
- 4. Prepare samples for fixed cell flow cytometry

- a. Prepare all buffers in filtered PBS [0.3% (v/v) Triton X-100, 0.5 mg/ml ribonuclease A, 1:10,000 dilution of SYBR Green I)].
- b. Add 50 µl of fixative to 50 µl of parasite culture and incubate at 4 °C for at least 1 h or overnight.
- c. Centrifuge down plates for 4 min, at 4 $^{\circ}$ C and 763 *x g* in bench top centrifuge for plates with medium brake/acceleration settings.
- d. Remove the supernatant and resuspend the cell pellet with 100 µl PBS and spin down again.
- e. Remove the supernatant and resuspend the cell pellet with 100 μ l of PBS with 0.3% (v/v) Triton X-100 and incubate for 10 min at room temperature.
- f. Wash twice with 100 µl PBS.
- g. Remove the supernatant and resuspend the pellet with 100 μl 0.5 mg/ml ribonuclease A in PBS and incubate for 1 h at 37 °C.
- h. Wash with 100 µl PBS.
- i. Remove as much PBS as possible and resuspend pellet with 100 µl 1:10,000 SYBR Green in PBS and incubate for exactly 30 min at room temperature (always keep SYBR Green tube and stained cells protected from light and keep SYBR GREEN I incubation consistent for all samples).
- j. Resuspend cells again and dilute 1:5 in PBS (Transfer 40 μl to a new 96-well plate with 160 μl PBS. No need to wash off SYBR Green I).
- k. Keep plates at 4 °C and protected from light. Measure parasitemia by FACS on the same day.
- 5. Record events by flow cytometry
 - a. For the Becton Dickenson LSR-II the following Voltages are used:

FSC	170	log
SSC	209	log
Green laser 530/30 488 F	360	log

- b. Record 50,000-100,000 cells/treatment group.
- c. Export data to fsc file format.
- 6. Analyze the flow cytometry data
 - a. Upload the fsc files to FlowJo, Flowing or a comparable flow cytometry software.
 - b. Open Dot Plots for each well of the 96-well plate.

Copyright Mohring et al.

This article is distributed under the terms of the Creative Commons Attribution License (CC BY 4.0).

- c. Within the Dot Plot of the RBC only control, generate a gate for RBCs (R1) that excludes other blood cells or broken red cells. X-axis is FSC-A and y-axis is SSC-A (see Figure 2).
- d. Open a Histogram for R1 and generate a gate for parasites (H-2). X-axis is SYBR-Green signal 530/30 488F-A and y-axis is number of cells. Compare RBC only control with a parasite containing well to find the right areas on the x-axis where RBCs and parasites need to be separated (Figure 4). Use the same gates for all wells.
- e. Save data as xls file and open it with excel.
- f. Calculate ratios (H-2/R1*100) and subtract the ratio of RBC only control. Calculate the ratio of End (24 h incubation, plate 2) and Start (0 h incubation, plate 1) to determine the multiplication rate (Example in Figure 5).




Figure 4. Gating of flow cytometry data. Within the Dot Plot a region (R1, green) defines red blood cells. All cells within that region are analyzed within a Histogram. In the Histogram a region (H-2) is defined to separate parasites from uninfected red blood cells (RBCs). The ratio of Parasite/total RBCs ((H-2/R1)*100) is calculated to give the parasitemia.

					Ratio minus RBC
Start 0 h			# cells	ratio	control
RBC control	Specimen 002 A1 A01.fcs		50000		
	Specimen 002 A1 A01.fcs/rbc		38869		
	Specimen 002 A1 A01.fcs/rbc/parasites		5	0.01	0.00
IRBC	Specimen 002_A2_A02.fcs		50000		
	Specimen_002_A2_A02.fcs/rbc		39075		
	Specimen 002 A2 A02.fcs/rbc/parasites		387	0.99	0.98
drug 1	Specimen 002 A3 A03.fcs		50000		
	Specimen 002 A3 A03.fcs/rbc		38859		
	Specimen_002_A3_A03.fcs/rbc/parasites		378	0.97	0.96
drug 2	Specimen 002 A4 A04.fcs		50000		
	Specimen_002_A4_A04.fcs/rbc		38798		
	Specimen_002_A4_A04.fcs/rbc/parasites		331	0.85	0.84
	opecimen_cost_rin_remes/red/parasites			0.05	0.01
End 24 h					
RBC control	Specimen 002 A5 A05.fcs		50000		
	Specimen_002_A5_A05.fcs/rbc		35233		
	Specimen 002 A5 A05.fcs/rbc/parasites		10		0.00
iRBC	Specimen 002 A6 A06.fcs		50000		0.00
	Specimen_002_A6_A06.fcs/rbc		35553		
	Specimen_002_A6_A06.fcs/rbc/parasites		1315		3.68
drug 1	Specimen_002_A7_A07.fcs		50000		5.00
unde 1	Specimen_002_A7_A07.fcs/rbc		35542		
	Specimen_002_A7_A07.fcs/rbc/parasites		688		1.92
drug 2	Specimen 002 A8 A08.fcs		50000		1.52
ulug 2	Specimen 002_A8_A08.fcs/rbc		35260		
	Specimen_002_A8_A08.fcs/rbc/parasites		500		1.40
	specifien_002_Ao_Abo.ics/fbc/parasites		000	1.42	1.40
	Start	End	Patio (En	d/Start*100	
iRBC	Start	LIIU	Natio (Lii	u/Start 100	-
INDC					
	0.98	3.68	3.76		
drug 1	0.56	5.00	5.70		
ulug 1					-
	0.96	1.92	2.00		-
drug 2	0.96	1.92	2.00		
unug z					
	0.84	1.40	1.67		5 <u></u>
	0.84	1.40	1.07		-
			Fold multi	nlication	
			Fold matu	plication	

Figure 5. Calculation of Multiplication rates

- B. Parasite growth inhibition activity (GIA) assay
 - 1. Synchronize *P. knowlesi* parasites via Nycodenz purification (see Step A1) or by magnetic separation (Ribaut *et al.*, 2008).
 - 2. Set up GIA assay in 96-well plate
 - a. Plates should include:
 - Triplicate wells of each test IgG concentration
 - Triplicate wells of positive control
 - 6 x wells with infected erythrocytes and media only (0% GIA control)
 - 6 x wells with uninfected erythrocytes at 2% hematocrit (100% GIA control/background)
 - 3 x wells with non-malarial human antibody as a negative control
 - b. Plate out 20 µl of culture with 4% hematocrit and 1.5% parasitemia trophozoites or only uninfected RBCs into 96-well flat/half area tissue culture cluster plates.
 - i. Purify synchronous trophozoites with Nycodenz or magnet.

©Copyright Mohring et al.

This article is distributed under the terms of the Creative Commons Attribution License (CC BY 4.0).

- ii. Resuspend parasite pellet with 1 pellet-volume complete media to 50% hematocrit.
- iii. Prepare a 4% red blood cell suspension in complete media (*e.g.*, 5 ml media + 200 μl red blood cells).
- iv. Transfer purified schizonts to media containing 4% red blood cells (6 μ l of 50% schizonts to 5 ml) to obtain 1.5% parasitemia and mix well. 6 μ l of 50% schizonts corresponds to ~3 x 10⁸ cells.
- v. Confirm parasitemia by counting of blood smear.
- c. Add 20 μl of purified IgG in 2x concentration in complete media to wells. Use serial 1:2 dilutions of immune serum or pre-immune serum of around eight final concentrations, depending on the EC₅₀ value (for example 10, 5, 2.5, 1.25, 0.625, 0.312, 0.15 and 0.075 mg/mL). Set up each treatment in triplicate test wells.
- d. Incubate for one cycle (in *P. knowlesi* 26-27 h) in standard culture conditions, together with a tracking culture to check parasitemia and life cycle stage.
- e. Before harvest check parasitemia (~ 4%) and life cycle stage (trophozoites are ideal, young parasites don't have adequate LDH levels) of tracking culture.
- f. Harvest cells.
 - i. Resuspend each culture by pipetting 100 µl of cold PBS to each well.
 - ii. Spin down cultures at 1,300 *x g* for 4 min with medium acceleration/break setting.
 - iii. Aspirate 100 µl of supernatant from all wells. Do not aspirate any RBCs. Tilting the plate away from the RBC pellet will help.
 - iv. Repeat the Steps Bfi to Bfiii once.
 - v. Freeze at -70 °C if the assay is not going to be performed immediately–but this is not necessary otherwise.
- g. Measure parasitemia with the lactate dehydrogenase (LDH) activity assay
 - i. Have NBT solution in LDH buffer ready and warm to room temperature.
 - ii. If plates have been frozen, thaw them at room temperature for at least 30 min. Plates need to be uniformly warmed to room temperature. If the plates have not been frozen, it is important that RBCs are uniformly resuspended prior to assay.
 - iii. Prepare complete LDH substrate by adding 50 µl of 3-Acetylpyridine Adenine Dinucleotide (APAD) stock and 200 µl of Diaphorase stock to every 10 ml of NBT solution. After all reagents are combined, use prepared LDH substrate immediately.
 - iv. Start the timer and add 120 μl of complete LDH substrate to all wells. Avoid bubbles (fully depress the plunger of the multichannel pipette before picking up the first aliquot of substrate, pipette should draw up extra substrate and no air will be ejected. Pipette down at the edge of the wells) and fully resuspend RBCs (shake plate on Titramax at max settings for 1 min and check if RBC pellets have fully disappeared) (check Note 8).
 - v. Incubate in the dark to allow color to develop for 30 to 60 min at room temperature on a flatbed shaker.

- vi. Measure absorbance at 650 nm with a 96-well Microplate Spectrophotometer until OD reaches 0.4-0.6 in iRBC and ICM control (0% GIA).
- h. Calculate percent inhibition: 100 [(A₆₅₀ of immune sample A₆₅₀ of RBCs only)/(A₆₅₀ of pre-immune control A₆₅₀ of RBCs only) x 100].

<u>Notes</u>

- 5 ml Nycodenz tube is required to purify parasites from 1 ml packed red blood cells at 4-10% parasitemia (*e.g.*, 50 ml culture maintained at 2% hematocrit and 4-10% parasitemia will yield 1 ml of packed red blood cells after centrifugation). Add 1 ml of medium to 1 ml of packed red blood cells to make a 2 ml culture with 50% hematocrit.
- 2. Uninfected red cells and ring-stage parasites will sink to the bottom and schizonts form a layer on top of the Nycodenz.
- 3. Compound 2 is a PKG inhibitor that reversibly blocks merozoite egress. This step is optional but will help to maximize yield of late schizonts and also provides the user with some flexibility in timing for subsequent steps. Viability of parasites will dramatically decline for incubations longer than 3 h. As an alternative to Compound 2 a highly specific and potent derivative of Compound 2, referred to as ML10, can be used as well, which is available from LifeArc (Ressurreição *et al.*, 2020).
- 4. To get parasites even more synchronized let them invade red blood cells for 30 to 60 min and purify with Nycodenz again, only this time keep the ring stage parasite pellet and remove the schizonts. You can slow down the aging of the parasites by leaving them at room temperature for several h in order to get them to the schizont stage at a convenient time for the next purification.
- 5. Set up all experiments in three biological replicates (different days, parasite preparations, and RBCs).
 - a. For parasite multiplication assays, setting up with purified schizonts is critical, as this removes residual uninfected RBCs from the parasites and enables us to examine differences in multiplication in different host RBCs (*e.g.*, comparing human and macaque RBC invasion).
 - b. Whilst the initial starting parasitemia should be fixed for all samples, it is still critical to obtain a timepoint 0 for parasitemia (*i.e.*, plate 1 for multiplication assay). This is because small variations in starting parasitemia can have a significant effect on the calculated growth rate–using different RBCs between samples can also alter the precise starting parasitemia.

Whilst here we use a second time point of 24 h, various other timepoints could be used depending on experimental aims. A timepoint of 24 h works well because all parasites would have undergone reinvasion and progressed to schizonts again, which are very easily identified using the flow cytometry assay. The downside of this is that both invasion

[©]Copyright Mohring et al.

This article is distributed under the terms of the <u>Creative Commons Attribution License</u> (CC BY 4.0).

efficiency and viability of developing rings and trophozoites are measured. Shorter timepoints (*e.g.*, 2-6 h) can be used to more specifically look at invasion and early ring formation, but these require very synchronous and late stage schizonts, as any schizonts that have not yet progressed to form new rings at the specified timepoint will affect interpretation of the data.

- 6. Parasites that are fixed become aggregated and settle more quickly to the bottom of the plate, otherwise there are no noticeable effects between fixed and unfixed samples.
- 7. Assays can also be set up in 24-well plates with final volume of 1 ml.
- 8. If necessary, use a pipette to resuspend, but this poses the risk of introducing bubbles. Do not vortex).

Recipes

1

1.	Fixative: 4% paraformaldehyde with 0.4% glutaraldehyde				
	10x PBS	5 ml			
	16% Formaldehyde (w/v) from Pierce	12.5 ml			
	Glutaraldehyde	125 µl			
	H ₂ O	32.5 ml			
	Final volume	50 ml			

- 2. LDH substrate buffer, pH 7.5
 - a. To prepare 500 ml of the buffer, mix 50 ml of 1 M Tris HCI (pH 8.0) and 450 ml H_2O
 - b. Add 2.8 g sodium L-Lactate
 - c. Add 1.25 ml Triton X-100
 - d. Mix on a magnetic stirrer at room temperature for at least 30 min
 - e. Make 50 ml aliquots and freeze at -20 °C
- 3. Nitro Blue Tetrazolium (NBT) solution
 - a. Remove one 50 ml aliquot of LDH buffer from the freezer
 - b. Warm up to room temperature.
 - c. In a 50 ml tube, add 50 ml of LDH buffer to one NBT tablet (10 mg)
 - d. Cover the tube with aluminium foil and let it stand for 15 min
 - e. Do not shake! Mix gently
 - f. Prepared solution can be kept at 4 °C up to 3 weeks in the dark (covered with aluminium foil)
- 4. 3-Acetylpyridine Adenine Dinucleotide (APAD) stock solution (10 mg/ml)
 - a. To prepare 10 ml of APAD stock solution, dissolve 100 mg of APAD in 10 ml of distilled water
 - b. Store the APAD stock solution in 50 µl aliquots in PCR tubes at -20 °C
- 5. Diaphorase stock solution 50 units/ml

To prepare Diaphorase stock solution, dissolve the 1,500 units Diaphorase vial contents in 30



ml of distilled water. Store 200 µl aliquots at -20 °C

6. Complete media

RPMI-1640 (HEPES Modification, 25 mM HEPES, without L-glutamine, Merck) with the following additions:

2.3 g/L sodium bicarbonate (Sigma)

- 2 g/L dextrose (Sigma)
- 0.05 g/L Hypoxanthine (Sigma)
- 5 g/L Albumax II (Gibco)
- 0.3 g/L L-glutamine (10 ml of 200 mM solution pro 1 L media, Merck)
- 10% (vol/vol) horse serum
- Sterile filter and store at 4 °C

Acknowledgments

This work is supported by an MRC Career Development Award (MR/M021157/1) jointly funded by the UK Medical Research Council and Department for International Development (R.W.M, F.M), (Basco *et al.*, 1995; Mohring *et al.*, 2019).

Competing interests

The authors declare no competing financial interests.

Ethics

The project, consent and protocol were approved by the LSHTM Observational Research Ethics Committee under project reference 5520-1.

References

- Basco, L. K., Marquet, F., Makler, M. M. and Le Bras, J. (1995). <u>Plasmodium falciparum and</u> <u>Plasmodium vivax</u>: lactate dehydrogenase activity and its application for *in vitro* drug <u>susceptibility assay</u>. *Exp Parasitol* 80(2): 260-271.
- Bei, A. K., Desimone, T. M., Badiane, A. S., Ahouidi, A. D., Dieye, T., Ndiaye, D., Sarr, O., Ndir, O., Mboup, S. and Duraisingh, M. T. (2010). <u>A flow cytometry-based assay for measuring invasion of red blood cells by *Plasmodium falciparum*. *Am J Hematol* 85(4): 234-237.
 </u>
- Bhakdi, S. C., Sratongno, P., Chimma, P., Rungruang, T., Chuncharunee, A., Neumann, H. P., Malasit, P. and Pattanapanyasat, K. (2007). <u>Re-evaluating acridine orange for rapid flow</u> <u>cytometric enumeration of parasitemia in malaria-infected rodents.</u> *Cytometry A* 71(9): 662-667.

- Genton, B., Al-Yaman, F., Betuela, I., Anders, R. F., Saul, A., Baea, K., Mellombo, M., Taraika, J., Brown, G. V., Pye, D., Irving, D. O., Felger, I., Beck, H. P., Smith, T. A. and Alpers, M. P. (2003). <u>Safety and immunogenicity of a three-component blood-stage malaria vaccine (MSP1, MSP2, RESA) against *Plasmodium falciparum* in Papua New Guinean children. *Vaccine* 22(1): 30-41.
 </u>
- Izumiyama, S., Omura, M., Takasaki, T., Ohmae, H. and Asahi, H. (2009). <u>Plasmodium</u> <u>falciparum</u>: development and validation of a measure of intraerythrocytic growth using SYBR <u>Green I in a flow cytometer</u>. *Exp Parasitol* 121(2): 144-150.
- Kennedy, M. C., Wang, J., Zhang, Y., Miles, A. P., Chitsaz, F., Saul, A., Long, C. A., Miller, L. H. and Stowers, A. W. (2002). *In vitro* studies with recombinant *Plasmodium* falciparum apical membrane antigen 1 (AMA1): production and activity of an AMA1 vaccine and generation of a multiallelic response. *Infect Immun* 70(12): 6948-6960.
- Koram, K. A., Adu, B., Ocran, J., Karikari, Y. S., Adu-Amankwah, S., Ntiri, M., Abuaku, B., Dodoo, D., Gyan, B., Kronmann, K. C. and Nkrumah, F. (2016). <u>Safety and immunogenicity of EBA-175 RII-NG malaria vaccine administered intramuscularly in semi-immune adults: A Phase 1, double-blinded placebo controlled dosage escalation study.</u> *PLoS One* 11(9): e0163066.
- 8. Makler, M. T. and Hinrichs, D. J. (1993). <u>Measurement of the lactate dehydrogenase activity of</u> <u>Plasmodium falciparum as an assessment of parasitemia.</u> *Am J Trop Med Hyg* 48(2): 205-210.
- Mohring, F., Hart, M. N., Rawlinson, T. A., Henrici, R., Charleston, J. A., Diez Benavente, E., Patel, A., Hall, J., Almond, N., Campino, S., Clark, T. G., Sutherland, C. J., Baker, D. A., Draper, S. J. and Moon, R. W. (2019). <u>Rapid and iterative genome editing in the malaria parasite</u> <u>Plasmodium knowlesi provides new tools for P. vivax research.</u> *Elife* 8: 45829.
- Moon, R. W., Hall, J., Rangkuti, F., Ho, Y. S., Almond, N., Mitchell, G. H., Pain, A., Holder, A. A. and Blackman, M. J. (2013). <u>Adaptation of the genetically tractable malaria pathogen</u> <u>Plasmodium knowlesi to continuous culture in human erythrocytes.</u> Proc Natl Acad Sci U S A 110(2): 531-536.
- Pacheco, M. A., Matta, N. E., Valkiunas, G., Parker, P. G., Mello, B., Stanley, C. E., Lentino, M., Garcia-Amado, M. A., Cranfield, M., Kosakovsky Pond, S. L. and Escalante, A. A. (2018). <u>Mode and rate of evolution of haemosporidian mitochondrial genomes: timing the radiation of avian parasites.</u> *Mol Biol Evol* 35(2):383-403.
- Payne, R. O., Silk, S. E., Elias, S. C., Miura, K., Diouf, A., Alanine, D., Jin, J., Labbe, G., Brian, I., Poulton, I., Griffiths, O., Edwards, N., Berrie, E., Siani, L., Douglas, A., Roberts, R., Vekemans, J., Nugent, F., Hill, A. V., Long, C., Lawrie, A. M. and Draper, S. J. (2017a). <u>Safety and immunogenicity of the novel *Plasmodium falciparum* blood-stage vaccine chad63-mva rh5 in a phase ia clinical trial. *Am J Trop Med Hyg* 95(5): 313-313.
 </u>
- Payne, R. O., Silk, S. E., Elias, S. C., Milne, K. H., Rawlinson, T. A., Llewellyn, D., Shakri, A. R., Jin, J., Labbe, G. M., Edwards, N. J., Poulton, I. D., Roberts, R., Farid, R., Jorgensen, T., Alanine, D. G., de Cassan, S. C., Higgins, M. K., Otto, T. D., McCarthy, J. S., de Jongh, W. A.,

Copyright Mohring et al.

This article is distributed under the terms of the Creative Commons Attribution License (CC BY 4.0).

Nicosia, A., Moyle, S., Hill, A. V., Berrie, E., Chitnis, C. E., Lawrie, A. M. and Draper, S. J. (2017b). <u>Human vaccination against *Plasmodium vivax* Duffy-binding protein induces</u> <u>strain-transcending antibodies</u>. *JCI Insight* 2(12): e93683.

- Ressurreição, M., Thomas J.A., Nofal S.D., Flueck, C., Moon, R.W., Baker, D.A., van Ooij, C. (2020). <u>Use of a highly specific kinase inhibitor for rapid, simple and precise synchronization of *Plasmodium falciparum* and *Plasmodium knowlesi* asexual stage parasites. *bioRxiv*. doi.org/10.1101/2020.04.24.059493.
 </u>
- Ribaut, C., Berry, A., Chevalley, S., Reybier, K., Morlais, I., Parzy, D., Nepveu, F., Benoit-Vical,
 F. and Valentin, A. (2008). <u>Concentration and purification by magnetic separation of the</u> erythrocytic stages of all human *Plasmodium* species. *Malar J* 7: 45.
- Thera, M. A., Doumbo, O. K., Coulibaly, D., Laurens, M. B., Ouattara, A., Kone, A. K., Guindo, A. B., Traore, K., Traore, I., Kouriba, B., Diallo, D. A., Diarra, I., Daou, M., Dolo, A., Tolo, Y., Sissoko, M. S., Niangaly, A., Sissoko, M., Takala-Harrison, S., Lyke, K. E., Wu, Y., Blackwelder, W. C., Godeaux, O., Vekemans, J., Dubois, M. C., Ballou, W. R., Cohen, J., Thompson, D., Dube, T., Soisson, L., Diggs, C. L., House, B., Lanar, D. E., Dutta, S., Heppner, D. G., Jr. and Plowe, C. V. (2011). <u>A field trial to assess a blood-stage malaria vaccine.</u> *N Engl J Med* 365(11): 1004-1013.
- 17. Xie, L., Li, Q., Johnson, J., Zhang, J., Milhous, W. and Kyle, D. (2007). <u>Development and</u> validation of flow cytometric measurement for parasitaemia using autofluorescence and <u>YOYO-1 in rodent malaria.</u> *Parasitology* 134(Pt 9): 1151-1162.