
Commentary

Theme: Pharmacokinetics, Biopharmaceutics and Bioequivalence: History and Perspectives
Guest Editors: Marilyn Martinez and Lawrence Yu

Scientific and Regulatory Standards for Assessing Product Performance Using the Similarity Factor, f_2

Ruth E. Stevens,^{1,4} Vivian Gray,² Angelica Dorantes,³ Lynn Gold,¹ and Loan Pham¹

Received 18 June 2014; accepted 27 January 2015; published online 12 February 2015

Abstract. The similarity factor, f_2 , measures the sameness of dissolution profiles. The following commentary is an overview of discussions and presentations from a group of industry and US regulatory experts that have integrated the science and regulatory research and practice for assessing product performance, particularly for modified-release (MR) dosage forms, using f_2 . For a drug development sponsor or applicant with an orally complex dosage formulation, it is critical to understand dissolution methods and the similarity factor and how and/or when to apply it in their NDA, ANDA, or PMA submission. As part of any regulatory submission, it is critical to justify that the product performance has not been impacted by any change in the manufacturing process and/or the delayed and/or prolonged drug release characteristics compared to a similar conventional or another orally complex dosage form. The purposes of this document are (1) to provide a description of appropriate dissolution methods, how is the f_2 calculated and how it can be used to justify product performance similarity, or not; (2) to provide an overview of alternative methods available for dissolution profile comparisons, and (3) to illustrate how applying these concepts in a focused way supports approval of submissions and regulatory dossiers and aligns them with on-going science and regulatory initiatives. A case study will be used as an example to demonstrate how dissolution testing and the f_2 calculation results can impact regulatory outcomes from an NDA (505(b)(1)), NDA (505(b)(2)), ANDA (505(j)), supplemental NDAs/ANDAs, or PMA perspective.

KEY WORDS: f_2 ; similarity factor; 505(b)(2); dissolution; bootstrap.

BACKGROUND INFORMATION

The authors of this paper were selected to present a roundtable presentation entitled, “Scientific and Regulatory Standards for Assessing Product Performance Using the Similarity Factor, f_2 ” at 2013 American Association of Pharmaceutical Scientists (AAPS) Annual Meeting and Exposition which took place November 10–14, 2013 in San Antonio, Texas. The moderators of the roundtable were Lynn Gold, PhD and Loan Pham, PhD. Vivian Gray presented the topic, “Scientific Considerations Using the Similarity Factor, f_2 ”. Ruth Stevens, PhD, MBA presented the topic, “Practical Applications of the Similarity Factor, f_2 ”, followed by Angelica Dorantes, PhD, who presented “Regulatory Applications of f_2 ”. The authors were invited by the Scientific Journal of the AAPS to submit their combined presentations as a commentary to this journal for wider distribution among its community.

There is a growing recognition of the importance of submitting a quality regulatory submission, especially when FDA refuses to file an application under 21 CFR314.101(d)(3) because the application or abbreviated application is incomplete (does not on its face contain information required under section 505(b) and 21 CFR 314.50). This is what happened to Merck & Co when they first submitted their NDA, ezetimibe/atorvastatin tablets. Pertinent to this commentary, two out of the four reasons quoted for the filing deficiency were as follows: (1) “The primary stability batches were manufactured at a Research and Development (R&D) facility. Provide stability data to bridge the R&D manufacturing to the commercial manufacturing (i.e., data for three commercial batches with at least three months of long term and accelerated data) as well as multipoint dissolution profiles.” and (2) “The application did not include any information to bridge the performance of the clinically tested batches to the commercial products (e.g., multipoint *in vitro* dissolution profiles)” (1).

This paper will discuss further how the similarity f_2 statistical comparison was used for the reformulated Asacol® capsule product, not as a point estimator but in combination with a statistical model independent multivariate confidence region procedure (Bootstrap approach), where wide variability was observed in the dissolution profiles. It will also briefly

¹ Camargo Pharmaceutical Services, 9825 Kenwood Road, Cincinnati, OH 45242, USA.

² V.A. Gray Consulting, Hockessin, DE 19707, USA.

³ Food and Drug Administration, White Oak Campus, Silver Spring, MD 20993, USA.

⁴ To whom correspondence should be addressed. (e-mail: rstevens@camargopharma.com)

discuss alternative statistical approaches that may be considered when application of the f_2 metric is not appropriate.

SCIENTIFIC CONSIDERATIONS USING THE SIMILARITY FACTOR, f_2

Information on f_2 can be found in at least three guidances: Guidance for Industry, Dissolution Testing of Immediate Release Solid Oral Dosage Forms (2), Guidance for Industry, Waiver of *In Vivo* Bioavailability and Bioequivalence Studies for Immediate Release Solid Oral Dosage Forms Based on the a Biopharmaceutics Classification System (3), and Guidance for Industry Immediate Release Solid Oral Dosage Forms, Scale-Up and Post-Approval Changes: Chemistry, Manufacturing Controls, *In Vitro* Dissolution Testing and *In Vivo* Bioequivalence Documentation (4). These three guidances have essentially the same information but the most extensive treatment of the subject is from the Guidance for Industry, Dissolution Testing of Immediate Release Solid Oral Dosage Forms (Table I).

Dissolution profile comparisons, in general, refer to the comparison of two dissolution profiles such as that of reference and test batches, pre-change batch and post-change batch, and strengths of product to support a biowaiver for strengths not used in an *in vivo* bioequivalence trial. During method development, there are basic attributes that the method should have to yield appropriate data for f_2 comparisons. These attributes include low variability, an identifiable slope in the percent drug dissolved over time, minimized artifacts that can bias the shape of these slopes, and an ability to detect changes in product critical quality attributes (CQAs). Furthermore, an understanding of the release mechanism(s) and linkage to clinical outcome are imperative for obtaining a meaningful and “clinically relevant” dissolution method.

When developing a dissolution method, the variability of the data should be monitored and minimized as much as possible. Within any given formulation, high between-unit variability will negatively impact the discriminatory power of this test. Variability may be inherent to the dissolution behavior of the formulations or it may be an artifact of the dissolution method, e.g., coning, tablet landing and sticking to an off-center position under the paddle, capsule pellicle formation, spinning of the dosage unit, and a variety of other clearly noticeable dissolution anomalies (5). All six dissolution vessels should be observed to determine if the anomalies are consistent in all six vessels or only observed in 1 or 2 of the vessels.

A practical consideration has been the implementation of variability constrains when conducting a profile comparison using the f_2 metric. The relative standard deviation (RSD) should be not more than (NMT) 20% at time points

less than or equal to 15 min and the RSD should be NMT 10% for all other points. One could argue that these rules on variability are really quite generous. However, when earlier time points are needed for the f_2 calculations, this can be a problem. Five-minute time points are needed when rapid disintegration is taking place, therefore variability is expected.

The f_2 rules dictate that the number of dosage units should be 12 of both of the reference and test or post-change drug products. At least three time points are required, and only one dissolution value above 85% can be used in the calculation (2,6–8). The similarity factor, f_2 is not needed when greater than 85% of the labeled amount of drug in the drug products has been dissolved within 15 min when tested in 0.1 N HCl, pH 4.5 acetate buffer, and pH 6.8 phosphate buffer.

One challenge with existing criteria is that the *in vivo* release may be multiphasic, thereby limiting the ability of the f_2 metric to predict *in vivo* product. For example, if an oral product was developed to be locally acting and is designed to be intact until at least pH 6.8 or greater (reaches the distal GI tract) and then a burst of drug (greater than 80%) is released in 15–30 min after reaching the site, one could argue that this profile would be similar to that of an immediate-release product dissolution and that the f_2 rules would be applicable. It might make sense to set the criteria as >85% dissolved in 60 or 90 min at pH 6.8 phosphate buffer or higher and zero dissolution when tested in 0.1 N HCl and pH 4.5 acetate buffer rather than calculate an f_2 value. With this type of release mechanism, it may be best to employ a risk-based approach when setting the *in vitro* release criteria. However, *in vitro* release tests tend to be completed within 60–90 min. This raises the question of whether or not the existing rules for f_2 remain applicable. Given the significant advances in drug delivery technology and delivery, further discussion is needed around this point.

STATISTICAL APPROACHES WHEN f_2 CANNOT BE APPLIED

When variability exceeds the f_2 rules, other statistical models should be considered. The following is an overview of two alternative approaches that may be considered, model independent or model dependent methods (2).

Model Independent Approaches

One such model is the independent multivariate confidence region procedure (Bootstrap approach) method.

Table I. FDA Guidances for f_2

Time points	Variability	Sample units	Measurements
Three to four or more	RSD NMT 20% for earlier time point (e. g. 15 min) ^a	Same dissolution conditions for both reference and test product	Use mean value of 12 units for each reference and test product
Same for both reference (prechange) and test product	RSD NMT 10% for the other time points	Reference batch should be most recently manufactured	Only one measurement after 85% of both products

^aThe example is 10 min in the Guidance for Industry, Waiver of *In Vivo* Bioavailability and Bioequivalence Studies for Immediate Release Solid Oral Dosage Forms Based on the a Biopharmaceutics Classification System

Bootstrap allows for the use of f_2 , not as a point estimator but as a confidence interval, thus overcoming concerns encountered when f_2 is used solely as a point estimate. Computation of the bias corrected and accelerated (BCA) confidence intervals is suggested. The bootstrap method simulates the distribution of f_2 values to determine whether or not two profiles exhibit comparable *in vitro* behavior. (6,9) This can include the following steps:

1. Generate N bootstrap samples (e.g., $N=1000$) by resampling independently with replacement from dissolution data for the test and reference groups.
2. Calculate f_2 values from N bootstrap samples.
3. Calculate the bias correction statistic to correct for the potential skewed distribution of f_2 derived from the bootstrap samples. This can be achieved by calculating the acceleration statistic (i.e., the rate of change of the standard error of the estimate of the sample statistic) by obtaining n jackknife samples (e.g., $n=24$) derived from original dissolution data.
4. Calculate lower and upper bounds of the confidence interval using type 1 error, f_2 values of N bootstrap samples, bias correction, and acceleration statistics.

To declare similarity between test and reference dissolution profiles, the lower bound of the confidence interval must equal 50 or more. To illustrate, the bootstrap method was applied by the FDA when they evaluated the reformulated 400 mg mesalamine delayed-release (MDR) (DelzicolTM) against the original 400 mg mesalamine modified-release tablets (10). The newly marketed MDR capsule and discontinued tablet (Asacol®) formulations have a pH-dependent release mechanism designed to delay release until the formulation reaches the distal gastrointestinal (GI) tract (pH~6.5), thus, increasing the level of exposure to the colon in patients with ulcerative colitis. The dissolution characteristics and pharmacokinetics of these MDR capsules and tablets are highly variable. As part of the reformulation program to market the capsule formulation, the similarity of dissolution profiles to the original MDR tablet formulation were needed across various pH values to provide the necessary assurance of comparable product performance (10). For modified-release oral dosage forms such as DelzicolTM that are developed for targeted local drug delivery within the GI tract, the dissolution profiles must contain at least three timepoints (11). As stated in the SUPAC MR 1997 guidance, "Adequate sampling should be performed, for example, at 1, 2, and 4 h and every two hours thereafter until either 80% of the drug from the drug product is released or an asymptote is reached." (12) (Fig. 1).

A multipoint dissolution profile comparison was generated between the mesalamine capsules and tablets over a range of pH values (pH 4.5, 6.0, 6.5, 6.8, 7.2, and 7.5). The similarity factors (f_2) values were calculated and provided for each dissolution media. Figure 2 displays the dissolution profiles before and after the formulation

change at pH at 7.2, for which the f_2 value was calculated to be 55.5 by the applicant. The variability (%RSD) in the dissolution data was very high at the 15- (170.1%), 30- (80.9%) and 45- (33.4%) min time points. Because of this, the f_2 test could not be used and the FDA applied the model independent bootstrap approach.

The bootstrap lower confidence interval with a bias correction was equal to 49.8. The FDA accepted this value in demonstrating similarity of the two products. The bootstrap method should not be used to improve an f_2 but rather it should be used as a mechanism for dealing with the issue of data variability. It is noted that there is an open software available for the bootstrap calculation (13).

Model Dependent Approaches

The model dependent approach is recommended for the dissolution data which consist of at least four or more dissolution data points. The approach includes the selection of a suitable mathematical function to describe the dissolution data. Several mathematical models have been described in the literature to fit dissolution profiles (2,14,15) including Probit, Logistic, Weibull, Quadric and Exponential, Hixson-Crowell k , and first-order k . The ultimate choice for the model is made based on the goodness of fit criteria such as the least residual mean square error and Akaike Information Criteria. Ideally, an acceptable fit shows relatively small differences between the fitted and the observed data, presenting no trends in residual error, and includes a small number of model parameters (a model with no more than three parameters is recommended (2)).

Having a selected mathematic model, additional steps are needed to accomplish the model-dependent approaches (2):

1. Define an appropriate similarity region based on intra- and inter-batch variances of the fitted model for test units from the standard approved batches.
2. Estimate the model parameters by fitting individual units (12 units) of the reference and the test to the chosen mathematical function.
3. Calculate the statistical distance between the mean parameters of the test and reference.
4. Calculate a 90% confidence region around the statistical distance is computed.
5. Compare the limits of the confidence region with pre-defined similarity region to declare either similarity or dissimilarity of the profiles.

Bootstrap methods generally make no assumptions about data distribution; hence, they can be a useful approach when there are too few data to test or verify model assumptions. Disadvantage of the use of the model-dependent approach is that there is no single universally accepted method to evaluate the validity of the statistical assumptions of the model. Examples of model-dependent approaches to characterize *in vitro* dissolution profiles are presented elsewhere (14,15).

f₂- Drug Development Process: MR Formulations

MR formulations are specified by 3 time points for the setting of the acceptance criteria for f ₂ comparison:	
1 st time point:	Approx. 20-30% of API is dissolved
	[range ± 10° to be defined*]
	→ proof of no dose-dumping
2 nd time point:	Approx. 50% of API is dissolved
	[range ± 10° to be defined*]
	→ description of profile
3 rd time point:	Generally more than 80% of API is dissolved
	[lower range to be defined]
	→ proof of complete drug release
However, more time points for MR formulations are needed per SUPAC-MR guidance (1997).	


Source: Dr. Alexander Pontius: EUFEBS, Dissolution Testing, Barcelona, 23-24 February 2012.

*The range of ± is not being specified in the pharmacopeia but taken from the EMEA guideline, Note for Guidance on the Quality of Modified Release Products, A: Oral Dosage Forms, B: Transdermal Dosage Forms, 1999.

Fig. 1. Modified-release dissolution time points

The similarity f₂ test should not be used when an approved *in vitro in vivo* correlation (IVIVC) model is available for the drug product. In this case, the IVIVC model should be used to

predict the rate (C_{max}) and extent (AUC) of systemic exposure based on dissolution profile data of the “test” and “reference” products (before and after the specific proposed CMC change).



Batch #	508833				444305 S4			
Time	Amount Dissolved (%LC)			%RSD	Amount Dissolved (%LC)			%RSD
	Mean	Min	Max		Mean	Min	Max	
0	0	0	0	N/A	0	0	0	N/A
15	3	0	15	170.1	1	0	6	172.6
30	23	1	57	80.9	15	1	88	160.5
45	63	24	89	33.4	70	49	98	21.6
60	84	66	97	12.5	97	92	101	2.7
75	94	87	100	4.4	100	96	103	1.7
90	97	90	101	2.8	101	98	103	1.4
f ₂	56							




Fig. 2. Example: bootstrap versus original method for f₂ determination results

REGULATORY APPLICATIONS OF f_2

The Application of f_2 in QbD

Dissolution and f_2 testing can be used to link clinical performance to critical manufacturing and process attributes and therefore used to set clinically relevant manufacturing process controls and product specifications that provide assurance of consistent quality product throughout its life cycle.

Is f_2 Applicable to All Dosage Forms?

When the drug availability is spontaneous (e.g., inhalation), or when the drug release rate is preprogrammed (e.g., implants), statistical tests of the dissolution profile similarity may not adequately characterize *in vivo* product performance. In these cases, other test procedures may be necessary (e.g., aerodynamics, particle size distribution, diffusion cell systems, dose counter).

Dosage forms where f_2 has been shown to be applicable include the following:

- Simple dosage forms: immediate release
- Oral complex dosage forms: modified release (DR, ER) and combination (IR/IR, IR/MR, MR/MR) products
- Non-oral dosage forms, including transdermal drug delivery systems and drug-device combination products

FREQUENTLY ASKED QUESTIONS

1. If dissolution profile is incomplete can f_2 be estimated?
 - Scenario 1—plateau is not reached: no
 - Scenario 2—plateau is reached: yes
2. When is it not necessary to calculate the f_2 value?
 - The product used in pivotal human study is the same as that being commercialized
3. Can the f_2 test be estimated across studies?
 - Yes, in some cases, f_2 can be estimated across studies. It is possible to use f_2 when the study materials being compared are of the same age (shelf-life) and if the same dissolution method (and detection method) is being used for the analysis, for example, comparing batches that have been manufactured after a process change with product batches that were submitted in an approval. The comparison would be the initial data from the approval batches with the initial data from the changed batches. In the case of clinical trial material being compared to a formulation change prior to marketing, the dissolution profiles can be compared if the dissolution method and detection methods are the same and the age of the product when it was tested is the same as the new product being tested.
4. Can f_2 be used to evaluate similarity of *in vitro* drug release profiles of non-oral drug-device combination products?
 - Yes, if the products are evaluated using the same testing conditions and share identical rate controlling factors for the *in vitro* and *in vivo* drug release.

5. If dissolution is complete in less than 15 min, are there additional considerations that are needed before declaring profile comparability?
 - May need additional earlier time points (e.g., 5, 10 min).
 - May need to change dissolution testing conditions (harsh to mild).
6. What factors can potentially contribute to variability in dissolution profiles?
 - Dissolution method related (as previously discussed).
 - Formulation related.
 - Analytical method related.

CONCLUSIONS

When planning the statistical method to be applied for profile comparison, there are several pivotal considerations that need to be integrated into the study design. Model-dependent or independent approaches should be considered to confirm profile similarity. The variability should be minimized and the release profile should contain at least three time points to be eligible for the f_2 calculation. When developing a new drug product, it is prudent to plan for dissolution documentation during all phases of drug development so that if a change is needed in formulation, manufacturing process, equipment, or manufacturing site, dissolution profiles and f_2 data can be used in lieu of the need to conduct PK/clinical trials.

The f_2 test can be invaluable for evaluating the similarity of the dissolution profiles, thereby supporting product manufacturing and development based upon quality by design, supporting the product and process throughout the design space.

Conflict of Interest The authors declare no conflict of interest.

Open Access This article is distributed under the terms of the Creative Commons Attribution License which permits any use, distribution, and reproduction in any medium, provided the original author(s) and the source are credited.

REFERENCES

1. FDA. NDA 200153 Administrative Document(s) & Correspondence Refuse to file 29 Oct 2009 in Summary Basis of Approval (SBA) for Liptruzet (ezetimibe and atorvastatin). 2014.
2. FDA. Guidance for industry: dissolution testing of immediate release solid oral dosage forms. 1997.
3. FDA. Guidance for industry: waiver of *in vivo* bioavailability and bioequivalence studies for immediate release solid oral dosage forms based on a biopharmaceutics classification system. 2000.
4. FDA. Guidance for industry: immediate release solid oral dosage form: scale-up and post-approval changes, chemistry, manufacturing and controls, *in vitro* dissolution testing, and *in vivo* bioequivalence documentation (SUPAC-IR). 1995.
5. Gray VA. Compilational Testing Equipment: Calibration, Qualification, and Sources of Error. In: Dressman J, Kramer J, editors.

- Pharmaceutical Dissolution Testing. Boca Raton, FL: Taylor and Francis Group; 2005. p. 58–63. doi:10.1201/9780849359170.ch2.
6. Shah VP, Tsong Y, Sathe P, Liu JP. *In vitro* dissolution profile comparison—statistics and analysis of the similarity factor, *f*₂. *Pharm Res*. 1998;15(6):889–96.
 7. EMA. Note for Guidance on the Investigation of Bioavailability and Bioequivalence. 2001. <http://faculty.ksu.edu.sa/64448/Documents/EMA%20Guideline%20BE.pdf>. Accessed 8 Jan 2015.
 8. WHO. Who Expert Committee on Specifications for Pharmaceutical Preparations Forty-sixth Report. 2012. WHO Technical Report Series 970. http://www.who.int/medicines/areas/quality_safety/quality_assurance/expert_committee/TRS-970-pdf1.pdf. Accessed 8 Jan 2015.
 9. Ocana J, Frutos G, Sanchez P. Using the similarity factor *f*₂ in practice: a critical revision and suggestions for its standard error estimation. *Chemometr Intell Lab Syst*. 2009;99(1):49–56.
 10. FDA. NDA 204412 Clinical Pharmacology Review in Summary Basis of Approval (SBA) for Delzicol (mesalamine) Capsules. 2013.
 11. Pontius A. Setting Specifications for Dissolution Testing of Modified-release formulations, Barcelona, 23–24. 2011.
 12. FDA. SUPAC-MR: Modified Release Solid Oral Dosage Forms: Scale-Up and Post- Approval Changes: Chemistry, Manufacturing, and Controls, *In Vitro* Dissolution Testing, and *In Vivo* Bioequivalence Documentation Bioavailability and Bioequivalence Studies for Orally Administered Drug Products, General Considerations. 1997.
 13. Mendyk A, Paclawski A, Szlek J, Jachowicz R. PhEq_bootstrap: open-source software for the simulation of *f*₂ distribution in cases of large variability in dissolution profiles. *Dissolution Technol*. 2013;20(1):13–7.
 14. Polli JE, Rekh G, Augsburger LL, Shah VP. Methods to compare dissolution profiles and a rationale for wide dissolution specifications for metoprolol tartrate tablets. *J Pharm Sci*. 1997;86(6):690–700.
 15. Sathe PM, Tsong Y, Shah VP. In-vitro dissolution profile comparison: statistics and analysis, model dependent approach. *Pharm Res*. 1996;13(12):1799–803.