



Published in final edited form as:

*J Mater Chem B Mater Biol Med.* 2016 May 28; 4(20): 3422–3432. doi:10.1039/C5TB02635K.

## Oxygen Delivering Biomaterials for Tissue Engineering

Ashley L. Farris<sup>1,2,\*</sup>, Alexandra N. Rindone<sup>1,2,\*</sup>, and Warren L. Grayson<sup>1,2,3,4,†</sup>

<sup>1</sup>Translational TE Center, Johns Hopkins University School of Medicine, Baltimore MD 21287, USA

<sup>2</sup>Department of Biomedical Engineering, Johns Hopkins University School of Medicine, Baltimore MD, 21205 USA

<sup>3</sup>Department of Materials Science and Engineering, Johns Hopkins University, Baltimore MD 21218, USA

<sup>4</sup>Institute for NanoBioTechnology, Johns Hopkins University, Baltimore, MD 21218, USA

### Abstract

Tissue engineering (TE) has provided promising strategies for regenerating tissue defects, but few TE approaches have been translated for clinical applications. One major barrier in TE is providing adequate oxygen supply to implanted tissue scaffolds, since oxygen diffusion from surrounding vasculature *in vivo* is limited to the periphery of the scaffolds. Moreover, oxygen is also an important signaling molecule for controlling stem cell differentiation within TE scaffolds. Various technologies have been developed to increase oxygen delivery *in vivo* and enhance the effectiveness of TE strategies. Such technologies include hyperbaric oxygen therapy, perfluorocarbon- and hemoglobin-based oxygen carriers, and oxygen-generating, peroxide-based materials. Here, we provide an overview of the underlying mechanisms and how these technologies have been utilized for *in vivo* TE applications. Emerging technologies and future prospects for oxygen delivery in TE are also discussed to evaluate the progress of this field towards clinical translation.

### Introduction

TE approaches have the potential to address the worldwide shortage of donor tissues for transplantation. The TE approach for developing implantable tissues involves incorporating cells onto a scaffolding material for structural support, possibly with the addition of mechanical cues or chemical growth factors to elicit particular cell responses. Engineers have developed clinically tested biomaterials to regenerate tissues such as the trachea, nasal alar lobule cartilage, bladder, and vaginal wall; however these tissues are either largely avascular or less than 3 mm in thickness.<sup>1–5</sup> One reason for the lack of clinical translation of larger implants is that the standard methods of TE rely on diffusion to transport oxygen

<sup>†</sup>Correspondence: Warren L. Grayson, PhD, Johns Hopkins University, Translational Tissue Engineering Center, 400 N. Broadway, Smith 5023, Baltimore MD 21231, U.S.A., wgrayson@jhmi.edu.

\*These authors contributed equally to this work.

throughout the scaffold, which results in higher oxygen concentrations towards scaffold edges and lower concentrations towards the center.

Consistent oxygen supply throughout implantable constructs is of particular importance due to oxygen's crucial role as a metabolic substrate and signaling molecule. In low oxygen environments, mammalian cells must utilize lactic acid fermentation to produce ATP, which requires 15 times more glucose to produce the same amount of ATP as oxidative phosphorylation. When ATP stores are depleted, as in ischemic tissues, cell necrosis will occur.<sup>6</sup> Hypoxia and nutrient deprivation, two hallmarks of ischemic tissue, have also been shown to induce apoptosis in mesenchymal stem cells, further highlighting the need to deliver oxygen along with transplanted cells.<sup>7</sup> Oxygen concentration also serves as an important signaling molecule for differentiation. When cultured under hypoxic conditions, several stem cell lineages including human embryonic stem cells, hematopoietic stem cells, and mesenchymal stem cells exhibit reduced differentiation potential and increased maintenance of stem cell markers.<sup>8</sup> Hypoxia-induced factors (HIFs) thought to be responsible for altering cell functions such as differentiation and proliferation in response to hypoxia.<sup>9</sup> For example, inhibiting HIF-1 $\alpha$  increased adipogenesis and decreased chondrogenesis in mesenchymal stem cells.<sup>10</sup> As low oxygen tensions can lead to necrosis or apoptosis, but also may be necessary to control stem cell differentiation, steps should be taken to limit oxygen concentration within a range that enables stem cells to differentiate into target cell types, without compromising metabolic activity.

Low oxygen diffusion through scaffolds has been a limiting factor in TE scaffolds for both *in vitro* and *in vivo* applications. Within native tissues, oxygen can only diffuse 100–200  $\mu\text{m}$  from capillaries meaning simple diffusion would not be sufficient to maintain cell viability in non-vascularized scaffolds much larger than 1 mm.<sup>11</sup> For bone engineering, mineralized tissue characteristic of bone formation was only observed in the edges of scaffolds *in vitro*, with maximum penetration depths of approximately 200  $\mu\text{m}$ .<sup>12,13</sup> When hepatocytes were transplanted with scaffolds *in vivo* for liver repair, 95–99% of cells died within 7 days; the surviving cells were predominately located near vasculature in the periphery of the scaffolds.<sup>14</sup> Due to the unequal distribution of oxygen, cells near the center of non-vascularized scaffolds tend to die, limiting the current effectiveness of tissue engineered scaffolds for large defect repair *in vivo*.

To overcome oxygen diffusion limitations *in vivo*, blood vessels from host vasculature must infiltrate implanted scaffolds or integrate with preassembled vasculature in the scaffold. Host-mediated angiogenesis alone is not adequate to combat scaffold center necrosis as blood vessel ingrowth occurs slowly, with full vascular penetration of a 3 mm scaffold taking 1–2 weeks and a 5 mm scaffold taking up to 35 days even when implanted near highly vascularized host tissue *in vivo*.<sup>15,16</sup> Pre-vascularization and blood vessel engineering are methods engineers have been exploring to combat this issue; however these systems will have no oxygen or nutrient supply during the time it takes to integrate with the host vascular network. To support cells with enough oxygen to maintain metabolic activity and provide appropriate signals during the period of vessel ingrowth, incorporation of oxygen releasing materials may be necessary.

Despite the necessity of oxygen for cell survival, there is a need for oxygen release to be tightly controlled for four reasons: (1) hyperoxia has been shown to cause oxidative damage to cells by reactive oxygen species (ROS) production<sup>17</sup>, (2) oxygen concentration and ROS generation affects cell differentiation,<sup>18</sup> (3) ROS acts as a mediator in the natural inflammatory process,<sup>19</sup> and (4) moderate hypoxia has been shown to stimulate vascular infiltration<sup>20,21</sup>. It is crucial to understand the oxygen requirements for particular tissues and the rate of vascularization into particular tissues to ensure that there is enough oxygen to preserve cell viability, but to avoid inhibiting either vascularization or differentiation or causing tissue damage from inflammation or releasing an excess of oxygen.

The primary methods of oxygen delivery fall into three categories: hyperbaric oxygen therapy (HBO<sub>2</sub>), oxygen carrying materials, and oxygen generating materials. HBO<sub>2</sub> has been used clinically to treat decompression sickness in divers since the 1920s, but has only recently been investigated for TE applications.<sup>22</sup> Of the oxygen carrying materials, the most heavily investigated methods for TE applications are perfluorocarbon (PFC) technologies and hemoglobin-based oxygen carriers (HbOCs). Oxygen generating materials for TE applications have traditionally been comprised of peroxides and inorganic peroxide salts, taking advantage of the degradation of hydrogen peroxide into water and oxygen. The purpose of this literature review is to review traditional oxygen delivering technologies as well as new emerging technologies that hold promise for *in vivo* TE applications.

## Current Technologies

### Hyperbaric Oxygen (HBO<sub>2</sub>) Therapy

HBO<sub>2</sub> has been investigated for many applications including wound healing and TE (Table 1). Patients undergoing hyperbaric oxygen therapy HBO<sub>2</sub> breathe 100% O<sub>2</sub> while in a chamber at increased atmospheric pressure, increasing oxygen tension in blood and tissues. HBO<sub>2</sub> has been shown to increase cellular oxygen levels, which leads to the generation of ROS. Though ROS can be toxic to individual cells and cause systemic damage to the pulmonary and central nervous systems, this toxicity is dependent upon duration of treatment and concentration of ROS.<sup>23</sup> In some studies, lower concentrations of ROS generated by the HBO<sub>2</sub> have been shown to decrease levels of pro-inflammatory cytokines and increase growth factor and collagen synthesis; however, whether ROS have positive or negative effects on tissues depends on the concentration, intracellular location, and tissue type.<sup>24</sup> These potentially therapeutic effects led to the investigation of HBO<sub>2</sub> for TE applications such as ligament healing<sup>25</sup>, cartilage<sup>26</sup>, bone<sup>27,28</sup>, and oral mucosa<sup>29</sup>.

HBO<sub>2</sub> has been shown to improve TE outcomes *in vivo*. One study investigated whether HBO<sub>2</sub> could improve healing of rat lacerated patellar ligaments. HBO<sub>2</sub> was administered for a total of 10 sessions over two weeks. Histological sections, collagen I gene expression, and gross images showed that in all treatment groups, the lacerated patellar ligament had filled with fibroblasts and collagen II weeks after surgery, but this was not observed in the control.<sup>25</sup> Another study used HBO<sub>2</sub> in conjunction with scaffold implantation to test bone formation and vascularization in a rat calvarial defect model. They reported increased numbers of osteoprogenitor cells and endothelial cells in groups treated with HBO<sub>2</sub>.<sup>27</sup>

Similar results were seen in bone diaphyseal defects in rabbits.<sup>28</sup> These studies show that increased oxygen tension has potential to improve TE outcomes.

Unfortunately, HBO<sub>2</sub> may not be the most effective method for several reasons. As the main method of delivery is through arterial blood, it is unlikely that implanted tissues without any integration into the host vasculature would benefit significantly. Furthermore, HBO<sub>2</sub> does not provide oxygen in a sustained manner and the treatment requires specialized equipment, requiring the patient to return to the hospital consistently for any beneficial effect to be observed. Additionally, HBO<sub>2</sub> is delivered systemically instead of locally and is known to cause rare but dangerous side effects, such as grand mal seizures, in some individuals.<sup>30</sup> Though investigating HBO<sub>2</sub> has shown that increasing oxygen partial pressures is likely beneficial to the tissue healing and remodeling process, a sustained delivery method that is sensitive to local partial pressures of oxygen would be preferred.

**Hemoglobin-based oxygen carriers (HbOCs)**—Hemoglobin-based oxygen carriers (HbOCs) use hemoglobin extract from human or mammalian red blood cells in order to store and deliver oxygen to human tissues. HbOCs work similarly to hemoglobin in red blood cells; changes in chemical conformation of hemoglobin allows for selective binding and releasing of O<sub>2</sub>. Binding of hemoglobin to O<sub>2</sub> occurs when the pO<sub>2</sub> of the environment increases past a given threshold. During this process, the heme molecule within hemoglobin changes its conformation from a “taut” state to a “relaxed” state, allowing it to readily chemically bind to O<sub>2</sub> (Figure 1A). Heme returns to its taut conformation and releases O<sub>2</sub> when the pO<sub>2</sub> decreases below the given threshold. In contrast to the linear relationship of O<sub>2</sub> saturation within PFCs to pO<sub>2</sub>, O<sub>2</sub> saturation in HbOCs exhibits a sigmoidal relationship with pO<sub>2</sub> (Figure 1C). This would result in O<sub>2</sub> release by HbOCs only during hypoxic environments, in which O<sub>2</sub> demand is highest.

Although some HbOCs have been clinically tested, there remains some safety concerns. Reasons for failure of first-generation HbOCs in clinical trials included hypertension, elevation in pancreatic and liver enzymes, renal and neural toxicity, and oxidative stress<sup>31,32</sup>. In particular, hypertension was attributed to nitric oxide (NO) extravasation and premature release of O<sub>2</sub> in the arterioles, both of which cause vasoconstriction.<sup>32,33</sup> NO extravasation also likely contributed to the elevation in liver and pancreatic enzymes in clinical trials.<sup>31</sup> Oxidation of hemoglobin to methemoglobin – which releases reactive ferryl ions and radicals – was the primary cause for oxidative stress and tissue toxicity observed with clinically-tested HbOCs.<sup>31,34</sup>

Due to these safety concerns, new HbOCs are being developed to eliminate the negative side effects of first-generation HbOCs. Several groups have developed HbOCs with specific sizes to minimize cytotoxicity, inflammation, and NO extravasation. In a study performed by Lai et al., cross-linked hemoglobin and albumin microparticles above 9 μm in diameter decreased cellular uptake by macrophages and increased viability of endothelial and liver cells *in vitro*.<sup>35</sup> Moreover, the microparticles – regardless of size – had a higher oxygen retention (P<sub>50</sub> = 9.3–9.7 mmHg O<sub>2</sub>), which could potentially prevent vasoconstriction caused by premature release of O<sub>2</sub> in arterioles. Xiong et al. also fabricated cross-linked hemoglobin and albumin particles with a 700 nm diameter to prevent migration through the

endothelium.<sup>36</sup> When they perfused isolated mice glomeruli with these microparticles *in vitro*, no significant vasoconstriction occurred throughout an 11 min interval. However, further studies are needed to confirm that these hemoglobin-based particles do not cause vasoconstriction *in vivo*.

With regards to decreasing oxidation of hemoglobin to metHb, Xiong et al. found that adding ascorbic acid and NaBH<sub>4</sub> – both reducing agents – decreased metHb content within their hemoglobin microparticles from 15–32% to 7%.<sup>37</sup> This coincided with a decreased phagocytosis rate (less than 5%) relative to the non-reduced groups when the hemoglobin microparticles were incubated with heparinized whole human blood for 30 min.<sup>37</sup> Given that oxidative stress was a primary cause for failure of first-generation HbOCs in clinical trials, treating HbOCs with reducing agents could potentially eliminate hemoglobin-induced oxidative stress and help progress this technology towards clinical translation.

**In vitro biomaterials applications**—Various HbOCs have been utilized as a media supplement *in vitro* to provide more physiologically relevant levels of O<sub>2</sub> and improve cell viability and function in 3D culture systems. For example, Chen et al. used purified bovine hemoglobin-supplemented medium in a hollow fiber, perfusion bioreactor to engineer liver tissue.<sup>38</sup> They demonstrated that hemoglobin-supplemented medium increased levels of aerobic respiration and drug metabolism in hepatocytes with respect to the control. However, there was also an upregulation of genes associated with ROS metabolism, which suggests that the hemoglobin oxidation was affecting cell behavior. To prevent oxidative stress, Centis et al. encapsulated cells in fibrin gels to minimize cell-HbOC contact.<sup>39</sup> HbOC-supplemented medium increased cell viability and downregulated expression of HIF-1 $\alpha$ , a gene associated with cellular response to hypoxia. Given these results, this system could be further adapted to study effects of varying O<sub>2</sub> concentration on stem cell differentiation within hydrogels to better inform techniques used *in vivo*.

Besides the technologies presented in these studies, no significant work has been published that apply HbOCs to TE. One reason for the lack of TE-related studies is that HbOCs have had lesser success in clinical trials than perfluorocarbons, another artificial blood substitute that has been widely studied.<sup>40</sup> However, with recent improvements that make them safer, HbOCs could potentially provide benefits over other O<sub>2</sub> delivery technologies. HbOCs only release O<sub>2</sub> in hypoxic environments, in which cellular oxygen demand is highest. This could be essential for engineering specific tissue types that are negatively affected by higher O<sub>2</sub> concentrations, but still need O<sub>2</sub> delivered during hypoxia. Moving forward, more studies that use new HbOCs technologies – as opposed to first generation HbOCs – are needed to evaluate their potential for translational TE applications.

### Perfluorocarbons (PFCs) technologies

PFCs consist of fluorinated carbon chains that exhibit various properties that make them highly suitable oxygen carrier for biological applications (Figure 1B). First, the strength of C-F bonds within PFCs makes them inert and thus biocompatible with living tissues.<sup>41</sup> PFCs are also hydro- and lipophobic and self-assemble in aqueous solution, which contributes to their structural stability in living tissues.<sup>42</sup> Lastly, PFCs have a low polarizability and are

miscible with non-polar gases such as O<sub>2</sub>, CO, CO<sub>2</sub>, and NO.<sup>42</sup> This property enables PFCs to dissolve O<sub>2</sub> by physically entrapping the molecules via van der Waals forces. The amount of dissolved O<sub>2</sub> within a given PFC is defined by Henry's law, in which the solubility of O<sub>2</sub> is linearly dependent upon the partial pressure of O<sub>2</sub> (pO<sub>2</sub>) within the environment (Figure 1C).<sup>43</sup> This allows PFCs to store and release O<sub>2</sub> based upon the metabolic demands and oxygen availability of a given tissue.

Several PFC emulsions have been clinically tested as artificial blood substitutes with some success. Of the emulsions that have been clinically tested, Oxygent (Alliance Pharmaceutical Corp.), an emulsion containing 58% perflubron, has shown the most promising results in terms of biocompatibility, oxygen carrying capacity, and emulsion stability in Phase I and II trials.<sup>44</sup> However, patients in phase III clinical trials experienced increased stroke risk and adverse neurological side effects.<sup>40,44</sup> Although, aggressive procedures performed in these trials left it unclear whether Oxygent was the cause of adverse clinical outcomes.<sup>40</sup> No PFCs are currently approved by the FDA, but they have overall shown greater clinical potential than other material-based O<sub>2</sub> delivery technologies.

**In vitro biomaterials applications**—Like HbOCs, PFCs have also been used as a media supplement *in vitro* to deliver O<sub>2</sub> to cells in 3D culture systems. For example, in experiments performed by Radisic et al., media supplemented with 11% v/v Oxygent was used to engineer cardiac muscle on a porous, poly(glycerol-sebacate) scaffold.<sup>45</sup> The authors found that supplementing the medium with Oxygent improved contractile function, higher cell viability, and increased expression of connexin-43 and cardiac troponin I. Other studies using similar bioreactor setups have also found that supplementing culture medium with PFC emulsions improved cell viability, differentiation, and function for tracheal and hepatic tissue constructs.<sup>46,47</sup> However, one of these studies found that adding PFC emulsions to their bioreactor setup decreased chondrogenesis in the cartilaginous layer of tracheal constructs. Thus, supplementing culture medium with PFC emulsions may only benefit specific cell types.<sup>46</sup>

Another *in vitro* application of PFCs has utilized the hydrophobicity and high density of PFCs to culture scaffolds between immiscible layers of aqueous medium and PFCs. This approach would allow the aqueous medium on top of the scaffold to provide nutrients to cells, while the PFC layer on bottom would deliver O<sub>2</sub>. Pilarek et al. used this setup to culture CP5 chondrocytes on electrospun polylactic scaffolds.<sup>48</sup> After 7 days of culture, they found that this layered-culture system yielded higher cell viability, proliferation, and ECM deposition on the scaffold in comparison to samples grown in culture medium alone. While this *in vitro* setup has yet to be used in other TE-specific studies, it could provide a platform for studying cell-biomaterial interactions within O<sub>2</sub> levels that are more physiologically relevant, and for investigating the effects of varying O<sub>2</sub> levels on stem cell differentiation.

**In vivo biomaterials applications**—PFCs have been incorporated into biomaterials for a variety of applications, including bone<sup>49,50</sup>, hepatic<sup>51,52</sup>, pancreatic<sup>53</sup>, and neural<sup>54,55</sup> TE. PFC-based biomaterials were initially fabricated by encapsulating cells and PFC emulsions into hydrogels. Fabrication of these biomaterials is performed by mixing PFC emulsions with a polymeric solution, adding cells to the solution, and crosslinking the



polymer in the solution to yield a gel consistency. As an example, Chin. et al. fabricated alginate hydrogel beads with perfluorooctylbromide (PFOB) emulsions in effort to increase cell viability and metabolic activity in tissue-engineered liver constructs.<sup>52</sup> They found that alginate beads with PFOB emulsions had higher cell viability, metabolic activity, and glucose and O<sub>2</sub> consumption in comparison to beads without PFOB in 7 days of normoxia. Another group has also shown that incorporating perfluorotributylamine (PFTBA) into alginate enhances human mesenchymal stem cell viability and osteogenic differentiation while decreasing chondrogenic differentiation and expression of hypoxic-related genes.<sup>50</sup> Moreover, they demonstrated that alginate and fibrin hydrogels with PFTBA emulsions promote more ectopic bone formation *in vivo* in comparison to hydrogels without PFTBA.<sup>49,50</sup> Fibrin hydrogels with PFTBA emulsions have also shown to enhance Schwann cell differentiation and migration, demonstrating the ability of oxygen delivery to promote tissue formation in a variety of applications.<sup>54</sup>

While promising results have been demonstrated for hydrogels supplemented with PFC emulsions, some drawbacks have been observed. Goh et al. showed that there was a steep decrease in  $\beta$ TC-tet insulinoma cell viability and metabolic activity when cultured under hypoxic (2% O<sub>2</sub>) conditions after 4 days, regardless of whether the beads were supplemented with PFTBA.<sup>53</sup> The authors attributed these results to the low O<sub>2</sub> carrying capacity of PFC emulsions, supporting their explanation with computer simulations that showed that PFTBA-supplemented beads results had similar dissolved O<sub>2</sub> concentrations to the control. They claimed that the concentration of PFTBA emulsions needed to significantly raise the O<sub>2</sub> would make the alginate beads mechanically unstable and cytotoxic due to increased levels of surfactant. Another study by White et al. showed that adding 10% PFOB to 1% alginate gels with 1% or 2% w/v Pluronic F68 surfactant significantly decreases fracture stress and protein transport in comparison to gels without PFOB.<sup>56</sup> These studies demonstrate challenges with PFC emulsion-based hydrogels in engineering tissues that require mechanical strength or protein transport to function.

To mitigate the issues from hydrogels with PFC emulsions, several groups have developed hydrogels functionalized with PFCs.<sup>55,57,58</sup> Li et al. fabricated a fluorinated methacrylamide chitosan hydrogel (MACF) with various aliphatic and aromatic PFCs to engineer neural tissue from neural stem/progenitor cells (NSPCs).<sup>55</sup> In 8 days of normoxic culture, they found that the NSPCs encapsulated within MACF hydrogels had higher cell viability and neural differentiation in comparison to the MAC control. Moreover, there was no statistical difference between the elastic modulus of the MAC control and MACF hydrogels. Another study by Palumbo et al. showed that functionalized hyaluronic acid (HA) hydrogels with 1,2,4-oxadiazole also resulted in higher cell viability after 7 days of hypoxic culture; although, viability still decreased over the course of the experiment.<sup>57</sup> Unlike hydrogels with PFC emulsions, these fluorinated hydrogels can also be tuned to release different levels of O<sub>2</sub>, which could be beneficial for guiding stem cell differentiation into targeted cell types.

Besides these hydrogels, Seifu et al. developed a solvent-casted, salt-leached poly(carbonate urethane) with fluorinated-zeolite microparticles to overcome issues with PFC emulsions.<sup>59</sup> Fluorinated-zeolite microparticles, which consist of a zeolite Y core coated with a monolayer of perfluorodecyltrethoxysilane, on the surface avoid cytotoxicity concerns since

they do not require a stabilizing surfactant as in PFC emulsions. With these particles incorporated into the porous scaffold, there was significantly higher proliferation and infiltration of smooth muscle cells into the scaffold after 7 days of normoxic culture. Given that porous, synthetic scaffolds have shown much promise in TE, incorporating PFC-based microparticles into these scaffolds may solve issues associated with cell viability and infiltration at the scaffold center.<sup>60</sup>

While PFC-based biomaterials have demonstrated an ability to increase cell viability, promote cell differentiation, and maintain cell metabolism for various tissue types, their inability to provide a sustained release of O<sub>2</sub> may be a potential barrier for *in vivo* success. Vascularization of 3–5 mm scaffold has been shown to take 1–3 weeks *in vivo* even when placed near highly vascularized areas, which means that O<sub>2</sub> supply in the construct is depleted for at least the first week post-implantation.<sup>15,16</sup> *In vitro*, PFC-supplemented biomaterials provide significant amounts of O<sub>2</sub> to cells for up to 4–8 days in normoxic and 3 days in hypoxic conditions (Figure 2).<sup>50,55,57,58</sup> Moreover, most O<sub>2</sub> release occurs within 24 hours after cell seeding (Figure 2).<sup>50,58</sup> Since minimal *in vivo* testing has been performed with PFC-based biomaterials, it is unclear whether PFCs would supply enough O<sub>2</sub> to sustain the TE scaffold before vascularization occurs.

To address this issue, methods to sustain the O<sub>2</sub> release of PFCs should be investigated to further their potential for clinical use. Techniques such as encapsulating PFCs within materials that are less O<sub>2</sub> permeable could help extend O<sub>2</sub> release. For example, microparticles encapsulating perfluorooctane in a within shell of polycaprolactone provided more O<sub>2</sub> release to cells in comparison to the control for at least 14 days in normoxic conditions.<sup>61</sup> Incorporating shelled-particles into tissue engineered constructs could potentially sustain O<sub>2</sub> release long enough to allow vascularization and robust tissue formation to occur *in vivo*.

## Peroxides

The most heavily investigated oxygen generating biomaterials involve the decomposition of hydrogen peroxide into molecular oxygen directly, in the case of hydrogen peroxide,<sup>62–65</sup> or through following dissolution of solid peroxides, in the cases of sodium percarbonate<sup>66–68</sup> and calcium peroxide.<sup>67,69,70</sup> Sodium percarbonate is a solid adduct of sodium carbonate and hydrogen peroxide that decomposes into ions and hydrogen peroxide in aqueous solution. Calcium peroxide is another solid molecule that releases hydrogen peroxide when exposed to water. In all cases, hydrogen peroxide is then degraded into oxygen and water. The chemical reactions of these species are presented in Figure 2.

For biomaterials applications, peroxides have been incorporated into bulk polymers and hydrogels as depicted in Figure 2. Specific examples are described in detail below.

The use of peroxides as an oxygen delivery technique has promise, because the materials generate oxygen instead of simply delivering it; however, much work was done to ensure that oxygen delivery could occur over a sustained time period. One group measured oxygen release after incorporating sodium percarbonate into PLGA films and found that sodium percarbonate was depleted after 70 hours *in vitro*.<sup>66</sup> The biomaterials protected



devascularized skin flaps from necrosis *in vivo* for 3 days, but as oxygen was depleted before vessels from the host could infiltrate the scaffold, no protective effect was observed at 7 day time point.<sup>66</sup> This study highlighted the potential for oxygen generating materials to prevent necrosis, but that effects would be transient if peroxide depletion occurred before the tissue was sufficiently vascularized. Though liquid hydrogen peroxide, sodium percarbonate, and calcium peroxide are all capable of producing oxygen, release rates differ depending upon the peroxide used. For example, oxygen generation from peroxide decomposition is much more rapid in the case of sodium carbonate compared to calcium peroxide.<sup>71</sup> If sustained release is the goal, it is likely that the slower release time of calcium peroxide could provide more sustained release than sodium percarbonate.

Subsequent studies of inorganic peroxides for oxygen generation used calcium peroxide, likely because of its longer release time. Of particular note, porous PLGA cylinders containing calcium peroxide sustained oxygen release for 10 days, which falls within the 1–2 week range needed for vascularization of a 1 mm defect (Figure 3).<sup>69</sup> This study did not test their materials *in vivo*, but noted that 3T3 fibroblasts cultured under hypoxic conditions (1% O<sub>2</sub>) with calcium peroxide scaffolds for 10 days were more metabolically active than cells cultured without calcium peroxide.

Another method, hydrophobic polymers, limit the amount of water that comes into contact with the peroxides and have been used to extend oxygen release times. Calcium peroxide was incorporated within polydimethylsiloxane (PDMS), a biostable, hydrophobic, oxygen permeable polymer. Oxygen release was relatively high for the first two weeks, with some release still occurring at 7 weeks.<sup>70</sup> The longer release rates resulted in improved measures of viability for pancreatic islets and  $\beta$  cells *in vitro*. The main drawback of this technology is that PDMS is not biodegradable and would either remain in the body indefinitely or need to be removed surgically.

The second challenge with using peroxide salts for oxygen generation was the release of cations into solution, which may negatively impact some cell types. For this reason, groups have also investigated whether hydrogen peroxide could be used for oxygen generating biomaterials. In a set of studies, Ng et al. developed a double emulsion solvent evaporation method for encapsulating hydrophilic low molecular weight drugs (such as hydrogen peroxide) within PLGA microparticles and Abdi et al. then tested these particles *in vitro* within a 3D alginate matrix containing catalase.<sup>63,64</sup> Viability experiments showed that culturing cells in hypoxic conditions (1% O<sub>2</sub>) resulted in only 60–65% viability, but incorporation of the oxygen generating microparticles resulted in nearly 100% viability. The main drawback of these materials is that oxygen generation lasts only 5 hours, which would likely be insufficient to improve cell viability in hypoxic conditions *in vivo*. Subsequent studies by Mallepally et al.<sup>62</sup> and Li et al.<sup>65</sup> extended oxygen generation from hydrogen peroxide to 24 hours by using poly(methyl methacrylate) as the encapsulating material and to 14 days by conjugating H<sub>2</sub>O<sub>2</sub> to a high molecular weight polymer which slowly diffuses through a PLGA shell, respectively.

A third challenge with peroxide-based oxygen generating systems is that they produce cytotoxic ROS as byproducts. The method used by many groups highlighted here to

overcome this concern is incorporation of catalase, an enzyme used in peroxisomes to convert hydrogen peroxide into oxygen and water without ROS production. One study that found burst release of calcium peroxide from PCL nanofibers caused cytotoxic morphological and proliferative changes in osteoblasts at day 1, but following a media change these effects were reversed.<sup>72</sup> This may mean that cell lines resistant to oxidative stress may be able to proliferate and differentiate as normal, but more studies should test how much hydrogen peroxide is released from biomaterials and whether those concentrations effect stem cells morphology, proliferation, and differentiation. Currently, there is still some controversy as to whether peroxide-based oxygen generating biomaterials without catalase would be a safe method for oxygen delivery *in vivo*, particularly since ROS are biological signaling molecules and effectors for the innate inflammatory response, which can lead to tissue injury.<sup>19</sup> In a normal inflammatory process, neutrophils and M1 macrophages produce ROS to elicit a multitude of responses to initiate inflammation including ROS-mediated killing of engulfed bacteria. Changes in endothelial cell structures that allow neutrophils and macrophages to migrate from vasculature into tissues such as decreased strength of occludins proteins in tight junctions, and increased expression of leukocyte-specific cell adhesion molecules on the endothelial cell membrane can also be ROS-induced.<sup>19</sup> Finally, hydrogen peroxide within the cell can increase expression of the pro-inflammatory cytokines such as IL-1 $\beta$ , IL-6, and TNF- $\alpha$ .<sup>19</sup> It is currently unclear whether the use of oxygen-delivering biomaterials will cause or exacerbate inflammation at the implant site and research in this area is of critical importance before these technologies can be translatable.

**In vivo biomaterials applications**—Groups have explored the use of oxygen generating peroxides to generate oxygen for particular TE applications including wound healing,<sup>67</sup> myocardial infarction,<sup>65</sup> pancreatic islets and  $\beta$  cells,<sup>70</sup> and adipose transplants<sup>73</sup>. Though the applications are different, biomaterial designs for incorporated peroxides have been very similar between groups: embedding either peroxide salts or liquid peroxide microspheres into synthetic polymers or alginate matrices.

For example, Chandra et al. developed a multi-layered oxygen generating biomaterial for wound healing using peroxide salts within a synthetic polymer.<sup>67</sup> The layer of the bandage in contact with skin is made of gelatin, to absorb fluid from the wound. This fluid will seep into the second layer, containing solid calcium peroxide and sodium percarbonate within polyvinyl alcohol, which will release oxygen in an aqueous environment. The third layer quenches hydrogen peroxide by including MgCl and the fourth layer is made of a synthetic polymer with low gas permeability. In a porcine model, groups with the bandages showed faster wound closure and a higher density of new blood vessels formed.

To treat myocardial infarction, Li et al. conjugated H<sub>2</sub>O<sub>2</sub> to a higher molecular weight molecule, PVP to slow peroxide release.<sup>65</sup> The PVP/H<sub>2</sub>O<sub>2</sub> conjugates were encapsulated within PLGA microsphere shell, which were subsequently loaded into a thermosensitive injectable hydrogel. Biomechanically, the hydrogels had a similar modulus (40 kPa) to gels shown to induce differentiation of cardiosphere-derived cells into cardiomyocytes. When tested without cells, materials kept oxygen tensions above 15% for 14 days. Peroxide

biomaterials improved cell viability and differentiation in hypoxia compared to cells grown without peroxide biomaterials.

Oxygen generating biomaterials using peroxides have overcome several challenges to develop materials that could potentially be used for *in vivo* tissue applications. Several groups have observed release times longer than the period necessary for vascular infiltration. Peroxide incorporation also does not affect mechanical integrity of scaffolds at concentrations necessary for oxygen delivery. However, the drawbacks to these technologies are that they may produce ROS in concentrations that are cytotoxic to cells or induce local inflammation, the solid peroxides release ions into solution, and the materials are less sensitive to local oxygen concentration than PFCs or HbOCs which could cause hyperoxia.

## Emerging Technologies

### Photosynthetic Algae

Given that existing O<sub>2</sub> delivery techniques have yet to produce promising results *in vivo*, recent technologies have been developed to improve clinical translation success of tissue engineered constructs. One technology utilizes the photosynthetic abilities of algae to supply a constant supply of O<sub>2</sub> within constructs for wound healing. In a study performed by Hopfner et al., 3T3 fibroblasts were co-cultured with photosynthetic *C. reinhardtii* algae and exposed to continuous light for 22 hours in hypoxic conditions (1% O<sub>2</sub>).<sup>74</sup> Fibroblasts co-cultured with algae had significantly lower expression of HIF-1 $\alpha$  relative to those cultured alone, which was correlated with significantly elevated levels of O<sub>2</sub> in co-culture medium. In a subsequent study, algae were genetically engineered to secrete vascular endothelial growth factor (VEGF) to promote vascularization as well as provide O<sub>2</sub> in tissue constructs.<sup>75</sup> When the algae-incorporating collagen gels were implanted subcutaneously into mice, scaffolds with genetically modified algae had longer vessel formation, more CD31 positive cells, and higher levels of VEGF after 7 days post implantation. To further evaluate the regenerative potential of these photosynthetic biomaterials, more work is needed to determine whether the algae induced an inflammatory or immune response *in vivo*. Moreover, these biomaterials require extended periods of light exposure in order to produce O<sub>2</sub>, so their application would be limited to skin and some subcutaneous tissues.

### Myoglobin-polymer-surfactant complex

Another technology recently reported by Armstrong et al. involved functionalizing stem cells with a myoglobin-polymer-surfactant complex, [Mb\_C][S], that would provide each cell with its own O<sub>2</sub>-delivering molecule.<sup>76</sup> To produce the protein-surfactant complex, they conjugated a cationized myoglobin protein with an anionic surfactant, yielding an amphiphilic molecule capable of anchoring to the cell membrane. They combined the [Mb\_C][S] with hMSCs and tested the ability of the hMSCs to form cartilage within non-woven polyglycolic acid (PGA) scaffolds. After culturing the modified hMSCs in the scaffolds for 35 days, they found modifying hMSCs with [Mb\_C][S] significantly increased the ratio of collagen II/I expression and reduced the size of the necrotic center from 42  $\pm$  24 to 7  $\pm$  6 percent. While this technique requires further evaluation and development, it could

provide an effective to alternative to current O<sub>2</sub>-delivering biomaterials and be used for a wide variety of TE applications.

### Microtanks

Another development has been the utilization of commercially available hollow spheres, termed microtanks, to supply oxygen for TE.<sup>77</sup> These polyacrylonitrile spheres have been incorporated into bulk PCL disks and then hyperbarically loaded with 100% oxygen. When incorporated into culture, oxygen diffuses out of the microtanks and into the culture medium. These materials showed release for approximately 24 hours, but release kinetics can be altered by the concentration of microtanks as well as the thickness and permeability of the microtank shell and the bulk polymer. When cultured with cells under anoxia for 6 days, the experimental groups showed similar proliferation and metabolic rates to those cultured in normoxia, showing promise for these materials in TE. Improvements in this area can be made by using a biodegradable material for the microtanks and extending release time.

### Endoperoxides

One drawback of peroxide based oxygen generating materials is the potential cytotoxicity of peroxide/catalase mixtures or uncontrolled release of sodium and calcium ions. To address this concern, Benz et al. incorporated endoperoxides into small organic molecules for oxygen release.<sup>78</sup> When in contact with water, these molecules release oxygen via a retro Diels-Alder reaction. The endoperoxides were added into solution at various concentrations, achieving oxygen release for 8–13 hours. It is likely that this release time would improve by covalent binding to a synthetic polymer. Cytotoxicity was mitigated by addition of vitamin C, which can quench singlet oxygen. Under anoxic conditions, 3T3 fibroblast and smooth muscle cell cytotoxicity was negligible when vitamin C was included. It would be enlightening to see these materials incorporated into biomaterials to test for effects on differentiation in the future.

### Microbubbles

Another interesting technology that has extensive use clinically, but has never been used for TE involves microbubbles. These consist of gaseous cores surrounded by thin shells that have been composed of lipids, polymers, surfactants, dextran, and chitosan.<sup>79</sup> Microbubbles have been used primarily as ultrasound contrast agents, but recently have also been used to deliver oxygen transiently to hypoxic tumor sites to improve the effectiveness of radiation therapy.<sup>80</sup> The unique characteristic of microbubbles is that they can be burst locally using ultrasound *in vivo*, releasing loaded oxygen to a particular area of interest (Figure 4). Though further work must be done to improve stability *in vivo*, these molecules may be useful for TE applications as well.

### Conclusion

O<sub>2</sub> delivery methods in TE are essential for tissue survival and function, especially in large-scale grafts where O<sub>2</sub> diffusion at the center is limited. While various methods have been investigated to deliver O<sub>2</sub> to TE scaffolds *in vivo*, no specific technologies have

demonstrated clear promise in translating TE therapies to the clinic. PFC-based biomaterials could be advantageous in directing stem cell differentiation of various cells types since their O<sub>2</sub> release is sensitive by cell demand, while peroxides release O<sub>2</sub> by a chemical reaction independent of the environmental O<sub>2</sub> concentration. Moreover, PFCs have fewer biocompatibility concerns than peroxides, which produce ROS as a by-product of their chemical reactions. However, peroxide-based biomaterials provide a more sustained release of O<sub>2</sub> than PFC-based biomaterial while maintaining their mechanical integrity.

Emerging technologies, such as photosynthetic biomaterials and cell priming with Mb-protein-surfactant complexes, could provide tunable O<sub>2</sub> delivery without compromising the mechanical integrity of a tissue construct. However, achieving FDA approval for these technologies could be difficult given the complex biological techniques they use. Additionally, photosynthetic biomaterials can only deliver O<sub>2</sub> when exposed to light, which would limit their application to skin and some subcutaneous tissues. Newly developed HbOCs also have potential to provide safe, controlled O<sub>2</sub> delivery in TE scaffolds, but they have yet to be incorporated into biomaterials.

In order to progress O<sub>2</sub> delivery technologies to the clinic, there are several avenues of investigation that could guide further development. For *in vitro* studies, consistent methods for measuring oxygen release should be established to allow scientists to discern which methods could be the most clinically relevant for particular TE applications. This would provide a direct means of comparing different O<sub>2</sub> delivery technologies prior to *in vivo* testing. Additionally, for HbOCs and peroxides, tests should be performed to measure reactive oxygen species generation from their materials to ensure cell health and viability. More studies should also be performed to evaluate the range of oxygen that should be delivered to a particular tissue to avoid damage from hypoxic or hyperoxic conditions and to maximize release of vasculogenic signals *in vivo*.

Alongside these *in vitro* studies, defining parameters, such as scaffold geometry and cell type, that affect the time for vascularization to occur *in vivo* will help determine O<sub>2</sub> demand of specific tissue types. Finally, more *in vivo* studies are needed to determine whether currently available materials, such as the ones discussed in this review, could supply sufficient oxygen to tissues as functional vasculature is developing. Such studies may be used to construct more targeted specifications for O<sub>2</sub>-delivering biomaterials and determine which technologies are most suitable for clinical translation.

## Acknowledgments

This work was supported by an NIH Biomedical Engineering Training Grant (ALF and ANR), NSF Graduate Research Fellowships (ALF and ANR), and an R03 grant from the National Institute of Biomedical Imaging and Bioengineering (WLG).

## References


1. Haykal S, Salna M, Waddell TK, Hofer SO. *Plast. Reconstr. Surg. Glob. Open.* 2014; 2:e178. [PubMed: 25426361]

2. Macchiarini P, Jungebluth P, Go T, Asnaghi MA, Rees LE, Cogan TA, Dodson A, Martorell J, Bellini S, Parnigotto PP, Dickinson SC, Hollander AP, Mantero S, Conconi MT, Birchall MA. *Lancet*. 2008; 372:2023–2030. [PubMed: 19022496]
3. Fulco I, Miot S, Haug MD, Barbero A, Wixmerten A, Feliciano S, Wolf F, Jundt G, Marsano A, Farhadi J, Heberer M, Jakob M, Schaefer DJ, Martin I. *Lancet (London, England)*. 2014; 384:337–346.
4. Atala A, Bauer SB, Soker S, Yoo JJ, Retik AB. *Lancet*. 2006; 367:1241–1246. [PubMed: 16631879]
5. Raya-Rivera AM, Esquiliano D, Fierro-Pastrana R, López-Bayghen E, Valencia P, Ordorica-Flores R, Soker S, Yoo JJ, Atala A. *Lancet*. 2014; 384:329–336. [PubMed: 24726478]
6. Boutilier RG, St-Pierre J. *Comp. Biochem. Physiol. Part A*. 2000; 126:481–490.
7. Zhu W, Chen J, Cong X, Hu S, Chen X. *Stem Cells*. 2006; 24:416–425. [PubMed: 16253984]
8. Mohyeldin A, Garzón-Muvdi T, Quiñones-Hinojosa A. *Cell Stem Cell*. 2010; 7:150–161. [PubMed: 20682444]
9. Papandreou I, Cairns RA, Fontana L, Lim AL, Denko NC. *Cell Metab*. 2006; 3:187–197. [PubMed: 16517406]
10. Malladi P, Xu Y, Chiou M, Giaccia AJ, Michael T, Malladi P, Xu Y, Chiou M, Giaccia AJ, Longaker MT. *Am. J. Physiol. Cell Physiol*. 2006; 94305:1139–1146.
11. Thomlinson RH, Gray LH. *Br. J. Cancer*. 1955; 9:539–549. [PubMed: 13304213]
12. Ishaug SL, Crane GM, Miller MJ, Yasko AW, Yaszemski MJ, Mikos AG. *J. Biomed. Mater. Res*. 1997; 36:17–28. [PubMed: 9212385]
13. Ishaug-Riley SL, Crane-Kruger GM, Yaszemski MJ, Mikos AG. *Biomaterials*. 1998; 19:1405–1412. [PubMed: 9758040]
14. Mooney DJ, Sano K, Kaufmann PM, Majahod K, Schloo B, Vacanti JP, Langer R. *J. Biomed. Mater. Res*. 1997; 37:413–420. [PubMed: 9368146]
15. Nomi M, Atala A, De Coppi P, Soker S. *Mol. Aspects Med*. 2002; 23:463–483. [PubMed: 12385748]
16. Mikos AG, Sarakinos G, Lyman MD, Ingber DE, Vacanti JP, Langer R. *Biotechnol. Bioeng*. 1993; 42:716–723. [PubMed: 18613104]
17. Zhou D, Shao L, Spitz DR. *Adv. Cancer Res*. 2014; 122:1–67. [PubMed: 24974178]
18. Atashi F, Modarressi A, Pepper MS. *Stem Cells Dev*. 2015; 24:1150–1163. [PubMed: 25603196]
19. Mittal M, Siddiqui MR, Tran K, Reddy SP, Malik AB. *Antioxid. Redox Signal*. 2014; 20:1126–1167. [PubMed: 23991888]
20. Lewis DM, Abaci HE, Xu Y, Gerecht S. *Biofabrication*. 2015; 7:45010.
21. Lam GC, V Sefton M. *Tissue Eng. Part A*. 2015; 21:803–816. [PubMed: 25379774]
22. Acott C. 1999
23. Clark JM. *Am. Rev. Respir. Dis*. 1974; 110:40–50. [PubMed: 4613232]
24. Thom SR. *J. Appl. Physiol*. 2009; 106:988–995. [PubMed: 18845776]
25. Ishii Y, Ushida T, Tateishi T, Shimajo H, Miyanaga Y. *J. Orthop. Res*. 2002; 20:353–356. [PubMed: 11918316]
26. Cherng J-H, Chang S-C, Chen S-G, Hsu M-L, Hong P-D, Teng S-C, Chan Y-H, Wang C-H, Chen T-M, Dai N-T. *Ann. Plast. Surg*. 2012; 69:650–655. [PubMed: 23154337]
27. Pedersen TO, Xing Z, Finne-Wistrand a, Hellem S, Mustafa K. *Int. J. Oral Maxillofac. Surg*. 2013; 42:907–914. [PubMed: 23403337]
28. Grassmann J, Schnependahl J, Hakimi A, Herten M, Betsch M, Lögters T, Thelen S, Sager M, Wild M, Windolf J, Jungbluth P, Hakimi M. *J. Orthop. Res*. 2015; 33:513–520. [PubMed: 25640997]
29. Tra WMW, Spiegelberg L, Tuk B, Hovius SER, Perez-Amadio S. *Tissue Eng. Part A*. 2014; 20:1523–1530. [PubMed: 24320751]
30. Hampson N, Atik D. *Undersea Hyperb. Med*. 2003; 30:147–153. [PubMed: 12964858]
31. Alayash AI. *Trends Biotechnol*. 2014; 32:177–185. [PubMed: 24630491]
32. Tao Z, Ghoroghchian PP. *Trends Biotechnol*. 2014; 32:466–473. [PubMed: 24929580]
33. Winslow RM. *J. Intern. Med*. 2003; 253:508–517. [PubMed: 12702028]





34. Buehler PW, D'Agnillo F, Schaer DJ. *Trends Mol. Med.* 2010; 16:447–457. [PubMed: 20708968]
35. Lai Y-T, Ohta S, Akamatsu K, Nakao S, Sakai Y, Ito T. *Biotechnol. Prog.* 2015:n/a–n/a.
36. Xiong Y, Liu ZZ, Georgieva R, Smuda K, Steffen A, Sendeski M, Voigt A, Patzak A, Bäumler H. *ACS Nano.* 2013; 7:7454–7461. [PubMed: 23915101]
37. Xiong Y, Ste A, Andreas K, Mu S, Sternberg N, Georgieva R. 2012
38. Chen G, Palmer AF. *Tissue Eng. Part A.* 2010; 16:3231–3240. [PubMed: 20528678]
39. Centis V, Proulx P, Vermette P. *Biochem. Eng. J.* 2011; 55:162–168.
40. Castro CI, Briceno JC. *Artif. Organs.* 2010; 34:no–no.
41. Riess JG, Krafft MP. *Biomaterials.* 1998; 19:1529–1539. [PubMed: 9794531]
42. Riess JG. *Artif. Cells. Blood Substit. Immobil. Biotechnol.* 2005; 33:47–63. [PubMed: 15768565]
43. Squires JE. *Science (80-.).* 2002; 295:1002–1005.
44. Cohn CS, Cushing MM. *Crit. Care Clin.* 2009; 25:399–414. [PubMed: 19341916]
45. Radisic M, Park H, Chen F, Salazar-Lazzaro JE, Wang Y, Dennis R, Langer R, Freed LE, Vunjak-Novakovic G. *Tissue Eng.* 2006; 12:2077–2091. [PubMed: 16968150]
46. Tan Q, El-Badry AM, Contaldo C, Steiner R, Hillinger S, Welti M, Hilbe M, Spahn DR, Jaussi R, Higuera G, van Blitterswijk CA, Luo Q, Weder W. *Tissue Eng. Part A.* 2009; 15:2471–2480. [PubMed: 19292679]
47. Shi G, Cogger RN. 2013
48. Pilarek M, Grabowska I, Senderek I, Wojasinski M, Janicka J, Janczyk-Ilach K, Ciach T. *Bioprocess Biosyst. Eng.* 2014; 37:1707–1715. [PubMed: 24532258]
49. Kimelman-Bleich N, Pelled G, Sheyn D, Kallai I, Zilberman Y, Mizrahi O, Tal Y, Tawackoli W, Gazit Z, Gazit D. *Biomaterials.* 2009; 30:4639–4648. [PubMed: 19540585]
50. Benjamin S, Sheyn D, Ben-David S, Oh A, Kallai I, Li N, Gazit D, Gazit Z. *Tissue Eng. Part A.* 2013; 19:748–758. [PubMed: 23215901]
51. Khattak SF, Chin K, Bhatia SR, Roberts SC. *Biotechnol. Bioeng.* 2007; 96:156–166. [PubMed: 16917927]
52. Chin K, Khattak SF, Bhatia SR, Roberts SC. *Biotechnol. Prog.* 2008; 24:358–366. [PubMed: 18293995]
53. Goh F, Gross JD, Simpson NE, Sambanis A. *J. Biotechnol.* 2010; 150:232–239. [PubMed: 20804794]
54. Ma T, Wang Y, Qi F, Zhu S, Huang L, Liu Z, Huang J, Luo Z. *Biomaterials.* 2013; 34:10016–10027. [PubMed: 24095255]
55. Li H, Wijekoon A, Leipzig ND. *Ann. Biomed. Eng.* 2014; 42:1456–1469. [PubMed: 24129754]
56. White JC, Stoppel WL, Roberts SC, Bhatia SR. *J. Biomed. Mater. Res. A.* 2013; 101:438–446. [PubMed: 22865503]
57. Palumbo FS, Di Stefano M, Palumbo Piccionello a, Fiorica C, Pitarresi G, Pibiri I, Buscemi S, Giammona G. *RSC Adv.* 2014; 4:22894.
58. Wijekoon A, Fountas-Davis N, Leipzig ND. *Acta Biomater.* 2013; 9:5653–5664. [PubMed: 23128156]
59. Seifu DG, Isimjan TT, Mequanint K. *Acta Biomater.* 2011; 7:3670–3678. [PubMed: 21704199]
60. O'Brien F. *Mater. Today.* 2011; 14:88–95.
61. Lee H-Y, Kim H-W, Lee JH, Oh SH. *Biomaterials.* 2015; 53:583–591. [PubMed: 25890754]
62. Mallepally RR, Parrish CC, Mc Hugh MAM, Ward KR. *Int. J. Pharm.* 2014; 475:130–137. [PubMed: 25173637]
63. Ng S-M, Choi J-Y, Han H-S, Huh J-S, Lim JO. *Int. J. Pharm.* 2010; 384:120–127. [PubMed: 19819316]
64. Abdi SIH, Ng SM, Lim JO. *Int. J. Pharm.* 2011; 409:203–205. [PubMed: 21356297]
65. Li Z, Guo X, Guan J. *Biomaterials.* 2012; 33:5914–5923. [PubMed: 22656447]
66. Harrison BS, Eberli D, Lee SJ, Atala A, Yoo JJ. *Biomaterials.* 2007; 28:4628–4634. [PubMed: 17681597]

67. Chandra PK, Ross CL, Smith LC, Jeong SS, Kim J, Yoo JJ, Harrison BS. *Wound Repair Regen.* 2015:n/a–n/a.
68. Ward CL, Corona BT, Yoo JJ, Harrison BS, Christ GJ. *PLoS One.* 2013; 8:e72485. [PubMed: 23991116]
69. Oh SH, Ward CL, Atala A, Yoo JJ, Harrison BS. *Biomaterials.* 2009; 30:757–762. [PubMed: 19019425]
70. Pedraza E, Coronel MM, Fraker CA, Ricordi C, Stabler CL. *Proc. Natl. Acad. Sci. U. S. A.* 2012; 109:4245–4250. [PubMed: 22371586]
71. Waite A, Bonner J, Autenrieth R. *Environ. Eng. Sci.* 1999; 16:187–199.
72. Wang J, Zhu Y, Bawa HK, Ng G, Wu Y, Libera M, van der Mei HC, Busscher HJ, Yu X. *ACS Appl. Mater. Interfaces.* 2011; 3:67–73. [PubMed: 21155527]
73. Jung D-W, Kim Y-H, Kim TG, Lee JH, Chung KJ, Lim JO, Choi JY. *Ann. Plast. Surg.* 2015; 75:463–470. [PubMed: 26207545]
74. Hopfner U, Schenck T-L, Chávez M-N, Machens H-G, Bohne A-V, Nickelsen J, Giunta R-E, Egaña J-T. *Acta Biomater.* 2014; 10:2712–2717. [PubMed: 24406198]
75. Chávez MN, Schenck TL, Hopfner U, Centeno-Cerdas C, Somlai-Schweiger I, Schwarz C, Machens H-G, Heikenwalder M, Bono MR, Allende ML, Nickelsen J, Egaña JT. *Biomaterials.* 2015; 75:25–36. [PubMed: 26474040]
76. Armstrong JPK, Shakur R, Horne JP, Dickinson SC, Armstrong CT, Lau K, Kadiwala J, Lowe R, Seddon A, Mann S, Anderson JLR, Perriman AW, Hollander AP. *Nat. Commun.* 2015; 6:7405. [PubMed: 26080734]
77. Cook, Ca; Hahn, KC.; Morrissette-McAlmon, JBF.; Grayson, WL. *Biomaterials.* 2015; 52:376–384. [PubMed: 25818444]
78. Benz S, Nötzli S, Siegel JS, Eberli D, Jessen HJ. *J. Med. Chem.* 2013; 56:10171–10182. [PubMed: 24299550]
79. Fix SM, Borden MA, Dayton PA. *J. Control. Release.* 2015; 209:139–149. [PubMed: 25913365]
80. Eisenbrey JR, Albala L, Kramer MR, Daroshefski N, Brown D, Liu J-B, Stanczak M, O’Kane P, Forsberg F, Wheatley MA. *Int. J. Pharm.* 2014; 478:361–367. [PubMed: 25448552]




**Figure 1.**

$O_2$  loading and release mechanisms of (A) HbOCs and (B) PFC-based oxygen carriers. (C) Relationship of  $O_2$  content as a function of  $pO_2$  in HbOCs and PFC based oxygen carriers, as reproduced from Ref. 28. Heme molecules in HbOCs chemically bind and unbind to  $O_2$  at a specific  $pO_2$  range, resulting in the sigmoidal relationship between  $pO_2$  and  $O_2$  content. In contrast, uptake and release of  $O_2$  from PFCs is dictated by Henry's Law, in which the amount of  $O_2$  dissolved in PFCs is linearly related to  $pO_2$ .

**A****B****Figure 2.**

O<sub>2</sub> release of (A) PFC-enriched fibrin gel in normoxic and hypoxic conditions, as adapted from [71]. Dissolved O<sub>2</sub> content within the culture medium was significantly higher than the control for up to 84 hours. (B) Oxygen release over time in 0.5% O<sub>2</sub> from PLGA cylinders with incorporated calcium peroxide without cells as reproduced, as adapted from [49].

**Sodium percarbonate:**

1.  $2[\text{Na}_2\text{CO}_3] \bullet 3[\text{H}_2\text{O}_2] \rightarrow 2\text{Na}^+ + 2\text{CO}_3^{2-} + 3\text{H}_2\text{O}_2$
2.  $2\text{H}_2\text{O}_2 \rightarrow \text{O}_2 + 2\text{H}_2\text{O}$

**Calcium peroxide:**


1.  $\text{CaO}_2 + 2\text{H}_2\text{O} \rightarrow \text{Ca}(\text{OH})_2 + \text{H}_2\text{O}_2$
2.  $2\text{H}_2\text{O}_2 \rightarrow \text{O}_2 + 2\text{H}_2\text{O}$

**Hydrogen Peroxide:**

1.  $2\text{H}_2\text{O}_2 \rightarrow \text{O}_2 + 2\text{H}_2\text{O}$

**Figure 3.**

Peroxide-based oxygen generating materials (P) for tissue engineering applications incorporate peroxide salts or liquid hydrogen peroxide within microparticles into bulk polymers or hydrogels. If solid peroxides are used, when water diffuses into the scaffold it causes the sodium percarbonate or calcium peroxide to dissociate into ions and hydrogen peroxide, as in the reactions on the right. Alternatively, liquid hydrogen peroxide can be encapsulated into microspheres and released from the material. In either case, hydrogen peroxide then decomposes into oxygen, which cells can uptake, and water.



**Figure 4.** Microbubbles filled with  $O_2$  or other therapeutic gases can be burst released locally *in vivo* by ultrasound waves, as depicted in this schematic.



**Table 1**Summary of current O<sub>2</sub> delivery technologies.

Method	Stem Cell and Biomaterials Applications	Pros	Cons
<b>Hyperbaric oxygen therapy</b>	<ul style="list-style-type: none"> <li>Applied <i>in vitro</i> to promote stem cell differentiation into cartilage, bone, and pancreatic <math>\beta</math> cells<sup>10,21,26-28</sup></li> </ul>	<ul style="list-style-type: none"> <li>Technically simple</li> <li>O<sub>2</sub> delivery may be sustained with recurring HBO<sub>2</sub> treatments</li> </ul>	<ul style="list-style-type: none"> <li>Requires daily treatments</li> <li>O<sub>2</sub> is flammable at high concentrations</li> <li>Can cause seizures, pulmonary damage, and reversible myopia when supplied systemically<sup>19</sup></li> <li>O<sub>2</sub> delivery is limited by diffusion</li> </ul>
	<ul style="list-style-type: none"> <li>Utilization <i>in vivo</i> to promote vascularization of TE bone scaffolds<sup>22,23</sup></li> </ul>		
<b>Perfluorocarbon technologies</b>	<ul style="list-style-type: none"> <li>Supplementation of media with PFC emulsions for 3D <i>in vitro</i> culture systems<sup>29-31</sup></li> </ul>	<ul style="list-style-type: none"> <li>O<sub>2</sub> release sensitive to pO<sub>2</sub> of surrounding environment</li> </ul>	<ul style="list-style-type: none"> <li>Surfactants used in PFC emulsions are cytotoxic at concentrations above 1% w/v in hydrogels<sup>40</sup></li> </ul>
	<ul style="list-style-type: none"> <li>Encapsulation of PFC emulsions in hydrogels for bone, liver, and pancreatic TE<sup>32-34</sup></li> </ul>	<ul style="list-style-type: none"> <li>Biologically inert<sup>37</sup></li> <li>More successful in clinical trials versus HbOCs<sup>38,39</sup></li> </ul>	<ul style="list-style-type: none"> <li>PFC emulsions have low oxygen carrying capacity<sup>34,38</sup></li> <li>Fast O<sub>2</sub> release profile</li> </ul>
	<ul style="list-style-type: none"> <li>Functionalization of natural hydrogels with PFCs for injectable TE therapies<sup>35</sup></li> </ul>		<ul style="list-style-type: none"> <li>PFC emulsions alter mechanical integrity of TE scaffolds<sup>41</sup></li> </ul>
	<ul style="list-style-type: none"> <li>Incorporation of fluorinated zeolite particles in porous, synthetic TE scaffolds for various applications<sup>36</sup></li> </ul>		
<b>Peroxide-based treatments</b>	<ul style="list-style-type: none"> <li>Incorporation of solid peroxides in synthetic scaffolds for dermal, pancreatic, skeletal muscle, and general TE applications<sup>42-47</sup></li> </ul>	<ul style="list-style-type: none"> <li>O<sub>2</sub> release up to 40 days<sup>46</sup> <i>in vitro</i></li> <li>Does not alter mechanical integrity of TE scaffolds<sup>48</sup></li> </ul>	<ul style="list-style-type: none"> <li>May produce cytotoxic ROS during degradation<sup>52</sup></li> <li>Solid peroxides release cations into solution</li> <li>O<sub>2</sub> release not sensitive to pO<sub>2</sub> of the environment</li> </ul>
	<ul style="list-style-type: none"> <li>Encapsulation of liquid peroxides into injectable alginate hydrogels for cardiac and</li> </ul>		

Method	Stem Cell and Biomaterials Applications	Pros	Cons
	adipose TE <sup>42,48-51</sup>		
<b>Hemoglobin-based oxygen carriers</b>	<ul style="list-style-type: none"> <li>Supplementation of culture medium in 3D fibrin gel system<sup>53</sup></li> <li>Supplementation of culture medium within perfusion bioreactors for liver TE<sup>54-56</sup></li> </ul>	<ul style="list-style-type: none"> <li>O<sub>2</sub> release sensitive to pO<sub>2</sub> of surrounding environment</li> <li>Sigmoidal oxygen release curve is more physiologically relevant</li> <li>O<sub>2</sub> release only occurs under hypoxic conditions</li> </ul>	<ul style="list-style-type: none"> <li>May produce cytotoxic ROS if oxidized<sup>57</sup></li> <li>Tetrameric and polymeric HbOCs cause vasoconstriction<sup>39</sup></li> <li>No <i>in vivo</i> applications for stem cell technologies has been investigated</li> </ul>

Author Manuscript

Author Manuscript

Author Manuscript

Author Manuscript