

Supporting Information

Design of HIV-1 Protease Inhibitors with C3-Substituted Hexahydrocyclopentafuranyl Urethane as P₂-Ligands: Synthesis, Biological Evaluation, and Protein-Ligand X-Ray Crystal Structure.

Arun K. Ghosh, Bruno D. Chapsal, Garth L. Parham, Melinda Steffey, Jonhson Agniswamy, Yuan-Fang Wang, Irene T. Weber, Masayuki Amano, and Hiroaki Mitsuya.

Table of Contents:

Table 1. HPLC Purity of Inhibitors 21-31	S2
Table 2. High and Low Resolution Mass Spectrometry Data for Inhibitors 21 to 31	S3
Table 3. Crystallographic Data Collection and Refinement Statistics	S4

HPLC Analytical Purity

Table 1. Analytical Purity of Inhibitors **21** to **31** determined by HPLC.

Inhibitor	Method A		Method B	
	R _t (min)	Purity (area %)	R _t (min)	Purity (area %)
21	12.87	95.1	15.3	95.8
22	11.54	99.1	15.03	99.3
23	9.17	95.1	12.25	95.2
24	8.82	97.2	12.96	96.4
25	13.64	97.9	16.31	97.9
26	10.45	99.9	14.54	99.9
27	8.25	98.1	11.75	98.3
28	12.92	96.8	15.97	99.9
29	14.80	95.2	17.30	95.0
30	15.04	97.7	17.55	95.7
31	8.97	97.0	12.8	99.2

HPLC conditions:

Method A = Agilent Eclipse XDB-C18 (4.6 x 150 mm, 5 μ m); t = 0-1 min (MeCN:H₂O:TFA 20:80:0.05), t = 1-20 min (*gradient to* MeCN:H₂O:TFA 90:10:0.05), t = 20-25 min (MeCN:H₂O:TFA 90:10:0.05); Flow = 1.5 mL/min; single detection wavelength λ = 215 nm, T = 25 °C, injection volume 30 μ L, 10 min equilibration time between run.

Method B = Agilent Eclipse XDB-C18 (4.6 x 150 mm, 5 μ m); t = 0-1 min (MeOH:H₂O:TFA 25:75:0.05), t = 1-20 min (*gradient to* MeOH:H₂O:TFA 95:5:0.05), t = 20-25 min (MeOH:H₂O:TFA 95:5:0.05); Flow = 1.5 mL/min; single detection wavelength λ = 215 nm, T = 25 °C, injection volume 30 μ L, 10 min equilibration time between run.

Mass Spectrometry Data

Table 2. High and Low Resolution Mass Spectrometry Data for Inhibitors **21** to **31**.

Inhibitor	Molecular Formula	HRMS Technique	Ion	Calculated	Found
21	C ₂₉ H ₃₈ N ₂ O ₈ S	ESI	[M+Na] ⁺	597.2247	597.2251
22	C ₂₉ H ₄₀ N ₂ O ₈ S	LRMS-ESI	[M+Na] ⁺	599.2	599.3
23	C ₂₈ H ₃₉ N ₃ O ₇ S	ESI	[M+Na] ⁺	584.2406	584.2410
24	C ₂₉ H ₄₀ N ₂ O ₈ S	ESI	[M+Na] ⁺	599.2403	599.2401
25	C ₃₀ H ₄₂ N ₂ O ₈ S	ESI	[M+H] ⁺	591.2740	591.2742
26	C ₂₉ H ₄₀ N ₂ O ₈ S	ESI	[M+H] ⁺	577.2584	577.2572
27	C ₂₈ H ₃₉ N ₃ O ₇ S	ESI	[M+Na] ⁺	584.2406	584.2398
28	C ₃₀ H ₄₂ N ₂ O ₈ S	ESI	[M+Na] ⁺	613.2560	613.2555
29	C ₂₈ H ₃₉ N ₃ O ₇ S	LRMS- ESI	[M+H] ⁺	575.3	575.1
30	C ₂₉ H ₄₀ N ₂ O ₈ S	LRMS- ESI	[M+H] ⁺	575.3	575.1
31	C ₃₁ H ₄₅ N ₃ O ₇ S	LRMS-ESI	[M+H] ⁺	604.8	604.3

Crystallographic Data Collection and Refinement Statistics

Table 3. Crystallographic Data Collection and Refinement Statistics

	PR-GRL-0489A
Space group	P2 ₁ 2 ₁ 2
Unit cell dimensions: (Å)	
A	58.39
B	86.55
C	45.85
Resolution range (Å)	50-1.45
Unique reflections	41,487
R _{merge} (%) overall (final shell)	7.2 (41.8)
I/σ(I) overall (final shell)	16.0 (2.0)
Completeness (%) overall (final shell)	98.4 (88.5)
Data range for refinement (Å)	10-1.45
R (%)	16.0
R _{free} (%)	21.9
No. of solvent atoms	142
RMS deviation from ideality	
Bonds (Å)	0.010
Angle distance (Å)	0.029
Average B-factors (Å ²)	
Main-chain atoms	17.4
Side-chain atoms	23.6
Inhibitor	14.1
Solvent	26.2