

Fluorination of naturally occurring *N*⁶-benzyladenosine remarkably increased its antiviral activity and selectivity

(Supplementary material)

Vladimir E. Oslovsky¹, Mikhail S. Drenichev¹, Liang Sun², Nikolay N. Kurochkin¹, Vladislav E. Kunetsky¹, Carmen Mirabelli², Johan Neyts², Pieter Leysen², Sergey N. Mikhailov¹ *

¹ *Engelhardt Institute of Molecular Biology, Russian Academy of Sciences, 119991, Vavilov Str. 32, Moscow, Russian Federation.*

² *KU Leuven - University of Leuven, Department of Microbiology and Immunology, Laboratory for Virology and Chemotherapy, Rega Institute for Medical Research, Minderbroedersstraat 10, 3000 Leuven, Belgium.*


* Corresponding author.

E-mail address: smikh@eimb.ru (S.N. Mikhailov).


¹H and ¹³C (with complete proton decoupling) NMR spectra were recorded on Bruker AMX 400 NMR instrument at 303 K relative to the residual solvent signals as internal standards (CDCl₃, ¹H: δ = 7.26, ¹³C: δ = 77.16; DMSO-*d*₆, ¹H: δ = 2.50, ¹³C: δ = 39.52; CD₃OD, ¹H: δ = 3.31, ¹³C: δ = 49.00). ¹H-NMR-spectra were recorded at 400 MHz and ¹³C-NMR-spectra at 100 MHz.

High-resolution mass spectra (HRMS) were registered on a Bruker Daltonics micrOTOF-Q II instrument using electrospray ionization (ESI). The measurements were done in a positive ion mode. Interface capillary voltage: 4500 V; mass range from m/z 50 to 3000; external calibration (Electrospray Calibrant Solution, Fluka); nebulizer pressure: 0.4 Bar; flow rate: 3 μL/min; dry gas: nitrogen (4L/min); interface temperature: 200°C.


Samples were injected in to the mass spectrometer chamber from the Agilent 1260 HPLC system equipped with Agilent Poroshell 120 EC-C18 (3.0 × 50 mm; 2,7 μm) column; flow rate 200 μL/min; samples were injected from the acetonitrile-water (1:1) solution and were eluted in a linear gradient of acetonitrile concentrations (50 → 100%).




Alteration of selectivity index of N^6 -benzyladenosine derivatives according to the modification on the phenyl ring



¹H-NMR-spectrum (400 MHz) of 2',3',5'-tri-O-isobutyrylinosine in CDCl₃ at 303 K






¹H-NMR-spectrum (400 MHz) of 6-chloro-2',3',5'-tri-O-isobutyryladenine (4) in CDCl₃ at 303 K




¹³C-NMR-spectrum (100 MHz) of 6-chloro-2',3',5'-tri-O-isobutyryladenine (**4**) in CDCl₃ at 303 K

Acquisition Parameter


Source Type	ESI	Ion Polarity	Positive	Set Nebulizer	0.4 Bar
Focus	Active	Set Capillary	4500 V	Set Dry Heater	180 °C
Scan Begin	50 m/z	Set End Plate Offset	-500 V	Set Dry Gas	6.0 l/min
Scan End	3000 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	0 nA	Set APCI Heater	0 °C




High-resolution mass spectrum (HRMS) of 6-chloro-2',3',5'-tri-O-isobutyryladenine (**4**)



$^1\text{H-NMR}$ -spectrum (400 MHz) of N^6 -(2-fluorobenzyl)-2',3',5'-tri-O-isobutyryladenine in $\text{DMSO-}d_6$ at 303 K







¹H-NMR-spectrum (400 MHz) of *N*⁶-(2-fluorobenzyl)-adenosine (**5**) in DMSO-*d*₆ at 303 K




¹³C-NMR-spectrum (100 MHz) of *N*⁶-(2-fluorobenzyl)-adenosine (**5**) in DMSO-*d*₆ at 303 K

Acquisition Parameter


Source Type	ESI	Ion Polarity	Positive	Set Nebulizer	0.4 Bar
Focus	Active	Set Capillary	4500 V	Set Dry Heater	200 °C
Scan Begin	50 m/z	Set End Plate Offset	-500 V	Set Dry Gas	4.0 l/min
Scan End	3000 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	0 nA	Set APCI Heater	0 °C




High-resolution mass spectrum (HRMS) of *N*⁶-(2-fluorobenzyl)-adenosine (**5**)



¹H-NMR-spectrum (400 MHz) of *N*⁶-(3-fluorobenzyl)-2',3',5'-tri-*O*-isobutyryladenine in DMSO-*d*₆ at 303 K






$^1\text{H-NMR}$ -spectrum (400 MHz) of N^6 -(3-fluorobenzyl)adenosine (6) in $\text{DMSO-}d_6$ at 303 K




^{13}C -NMR-spectrum (100 MHz) of N^6 -(3-fluorobenzyl)-adenosine (**6**) in $\text{DMSO-}d_6$ at 303 K

Acquisition Parameter


Source Type	ESI	Ion Polarity	Positive	Set Nebulizer	0.4 Bar
Focus	Active	Set Capillary	4500 V	Set Dry Heater	200 °C
Scan Begin	50 m/z	Set End Plate Offset	-500 V	Set Dry Gas	4.0 l/min
Scan End	3000 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	0 nA	Set APCI Heater	0 °C




High-resolution mass spectrum (HRMS) of *N*⁶-(3-fluorobenzyl)-adenosine (**6**)



¹H-NMR-spectrum (400 MHz) of *N*⁶-(4-fluorobenzyl)-2',3',5'-tri-*O*-isobutyryladenine in CDCl₃ at 303 K






$^1\text{H-NMR}$ -spectrum (400 MHz) of N^6 -(4-fluorobenzyl)-adenosine (7) in $\text{DMSO-}d_6$ at 303 K




^{13}C -NMR-spectrum (100 MHz) of N^6 -(4-fluorobenzyl)-adenosine (7) in $\text{DMSO-}d_6$ at 303 K

Acquisition Parameter


Source Type	ESI	Ion Polarity	Positive	Set Nebulizer	0.4 Bar
Focus	Active	Set Capillary	4500 V	Set Dry Heater	200 °C
Scan Begin	50 m/z	Set End Plate Offset	-500 V	Set Dry Gas	4.0 l/min
Scan End	3000 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	0 nA	Set APCI Heater	0 °C




High-resolution mass spectrum (HRMS) of *N*⁶-(4-fluorobenzyl)-adenosine (**7**)



¹H-NMR-spectrum (400 MHz) of *N*⁶-(2,6-difluorobenzyl)-2',3',5'-tri-*O*-isobutyryladenine in CDCl₃ at 303 K






$^1\text{H-NMR}$ -spectrum (400 MHz) of N^6 -(2,6-difluorobenzyl)-adenosine (**8**) in $\text{DMSO-}d_6$ at 303 K




^{13}C -NMR-spectrum (100 MHz) of N^6 -(2,6-difluorobenzyl)-adenosine (**8**) in $\text{DMSO-}d_6$ at 303 K

Acquisition Parameter


Source Type	ESI	Ion Polarity	Positive	Set Nebulizer	0.4 Bar
Focus	Active	Set Capillary	4500 V	Set Dry Heater	200 °C
Scan Begin	50 m/z	Set End Plate Offset	-500 V	Set Dry Gas	4.0 l/min
Scan End	3000 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	0 nA	Set APCI Heater	0 °C




High-resolution mass spectrum (HRMS) of *N*⁶-(2,6-difluorobenzyl)-adenosine (**8**)



¹H-NMR-spectrum (400 MHz) of *N*⁶-(2-trifluoromethylbenzyl)-2',3',5'-tri-*O*-isobutyryladenine in CDCl₃ at 303 K






¹H-NMR-spectrum (400 MHz) of *N*⁶-(2-trifluoromethylbenzyl)-adenosine (9) in DMSO-*d*₆ at 303 K




^{13}C -NMR-spectrum (100 MHz) of N^6 -(2-trifluoromethylbenzyl)-adenosine (9) in $\text{DMSO-}d_6$ at 303 K

Acquisition Parameter


Source Type	ESI	Ion Polarity	Positive	Set Nebulizer	0.4 Bar
Focus	Active	Set Capillary	4500 V	Set Dry Heater	200 °C
Scan Begin	50 m/z	Set End Plate Offset	-500 V	Set Dry Gas	4.0 l/min
Scan End	3000 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	0 nA	Set APCI Heater	0 °C




High-resolution mass spectrum (HRMS) of *N*⁶-(2-trifluoromethylbenzyl)-adenosine (**9**)



¹H-NMR-spectrum (400 MHz) of *N*⁶-(3-trifluoromethylbenzyl)-2',3',5'-tri-*O*-isobutyryladenine in CDCl₃ at 303 K




¹H-NMR-spectrum (400 MHz) of *N*⁶-(3-trifluoromethylbenzyl)adenosine (**10**) in DMSO-*d*₆ at 303 K





^{13}C -NMR-spectrum (100 MHz) of N^6 -(3-trifluoromethylbenzyl)-adenosine (**10**) in $\text{DMSO-}d_6$ at 303 K

Acquisition Parameter


Source Type	ESI	Ion Polarity	Positive	Set Nebulizer	0.4 Bar
Focus	Active	Set Capillary	4500 V	Set Dry Heater	200 °C
Scan Begin	50 m/z	Set End Plate Offset	-500 V	Set Dry Gas	4.0 l/min
Scan End	3000 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	0 nA	Set APCI Heater	0 °C




----- EIC 425.0000-427.0000 +All MS




High-resolution mass spectrum (HRMS) of *N*⁶-(3-trifluoromethylbenzyl)-adenosine (**10**)



¹H-NMR-spectrum (400 MHz) of *N*⁶-(4-trifluoromethylbenzyl)-2',3',5'-tri-*O*-isobutyroyladenosine in CDCl₃ at 303 K






¹H-NMR-spectrum (400 MHz) of *N*⁶-(4-trifluoromethylbenzyl)adenosine (**11**) in DMSO-*d*₆ at 303 K



^{13}C -NMR-spectrum (100 MHz) of N^6 -(4-trifluoromethylbenzyl)adenosine (**11**) in $\text{DMSO-}d_6$ at 303 K

Acquisition Parameter

Source Type	ESI	Ion Polarity	Positive	Set Nebulizer	0.4 Bar
Focus	Active	Set Capillary	4500 V	Set Dry Heater	200 °C
Scan Begin	50 m/z	Set End Plate Offset	-500 V	Set Dry Gas	4.0 l/min
Scan End	3000 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	0 nA	Set APCI Heater	0 °C



High-resolution mass spectrum (HRMS) of *N*⁶-(4-trifluoromethylbenzyl)-adenosine (**11**)