

1 **Bioprinted Osteon-like Scaffolds Enhance in Vivo Neovascularization**

2 Charlotte Piard, Hannah Baker, Timur Kamalitinov, and John Fisher*

3

4 Fischell Department of Bioengineering, University of Maryland

5 3121 A. James Clark Hall, College Park, MD 20742, United States

6

7 Center for Engineering Complex Tissues, University of Maryland

8 3121 A. James Clark Hall, College Park, MD 20742, United States

9

10 **Short Title:** Biomimetic Scaffolds Enhance Neovascularization

11

12

13 **Key Words:** osteon, bone tissue engineering, bioprinting, neovascularization, biomimetic, fibrin

14

15 **Submitted To:** Biofabrication

16

17 ***Corresponding Author(s):** John P. Fisher

18 Fischell Family Distinguished Professor & Department Chair

19 Fischell Department of Bioengineering

20 University of Maryland

21 4102A Clark Hall

22 8278 Paint Branch Drive

23 College Park, MD 20742


24 Phone: 301.314.2188

25 Email: jpfisher@umd.edu


26

499


500



Supplemental Figure I: Qualitative assessment of the gelatin content of the 3D printed scaffolds directly after printing (left) and 24h after incubation at 37°C (right). Picro-Sirius Red stain was used, collagen or gelatin fibers are stained red.





501 **Supplemental Figure II:** Computational modeling of flow in 200µm conical and cylindrical needles at 3.5 bar. Heat maps of the simulated fluid flow induced shear stresses for both needle types.



502

Supplemental Figure III: Fibrin bioink printing accuracy. (a) Extruded fiber diameter as a function of extrusion pressure, plotting speed, and cell density for variable needle inner diameter (n=9). The baseline line represents the targeted fiber diameter (i.e. needle inner diameter). (b) Rheological evaluation of fibrin bioink seeded with variable density of L929s. The printing shear rate was calculated for every printing condition, the printing shear rate range is represented in black. (c) Bioplotter image of extruded fibers used to measure extruded fiber diameter.



503

504

Supplemental Figure IV: Von Kossa staining. Micrographs of embedded, sectioned and stained samples (rMSCs only, rMSCs/RAECs control or rMSCs/RAECs 3DP) using Von Kossa, 7 or 14 days implantation *in vivo*. Calcium deposits are stained brown to dark depending on UV exposure. 0.1% Nuclear Fast Red Solution was used as a counterstain, staining nuclei pink. Von Kossa staining showed increased mineralization between day 7 and day 14 in all groups, with the most increase shown in the rMSCs/RAECs control and rMSCs/RAECs printed groups.