

General Methodology for HPTLC

Version: **02** Effective Date: 05.05.2006

Revision History

Version 01: replaces all earlier versions Version 02: minor revision and update

Related documents

GDL 50.000.01 Use of CAMAG equipment and software

GDL 50.002.01 Record keeping

GDL 60.000.01 Housekeeping rules and schedule

SOP 50.001.02 Labeling

I. PURPOSE

This SOP provides general guidance for analysis by HPTLC.

II. APPLICATION

This SOP applies to all work regarding HPTLC analysis unless the resulting chromatograms or the applied method require adjustments.

III. PROCEDURE

General

- 1. Prior to using an instrument, log-in the corresponding instrument log according to GDL 50.000.01 Use of CAMAG equipment and software.
- 2. Observe safety and housekeeping rules according to GDL 60.000.01 Housekeeping rules and schedule and SOP 60.000.02 Chemical Hygiene Plan.
- 3. For use of instrument refer to GDL 50.000.01 Use of CAMAG equipment and software.
- 4. Record any performed work in appropriate worksheets as specified in GDL 50.002.01 Record keeping. Include temperature and humidity at least once a day in any active worksheets.

A) Plate material

Handle plates with extreme caution to avoid any damage to the layer. Store plates in the original package with the lid closed. Remove plate from storage only immediately prior to use.

Plates are generally handled only at the upper edge to avoid contamination.

Unless otherwise necessary Merck HPTLC plates silica gel 60 F 254 in the format 10x10 cm or 20x10 cm are used. For most work plates are used without pre-treatment unless chromatography produces impurity fronts due to contamination of the plate. For reproducibility studies and quantitative analyses plates are pre-washed as follows.

1. Mark the direction of development with a pencil at the upper edge of the plate.

l of 4	Page	Effective: 2006-05-18	Version: 01	y: ER/2006-05-18	8 Rele	y: VW/2006-05-18	Prepared b	
--------	------	-----------------------	-------------	------------------	--------	------------------	------------	--

- 2. Develop plate with 20 mL methanol per trough in a 20 x 10 cm Twin Trough Chamber (TTC) to the upper edge. Up to two 20 x 10 cm or four 10 x 10 cm plates can be developed back to back in each trough of the TTC.
- 3. Remove the plate and dry for 20 minutes in a clean drying oven at 120°C.
- 4. Equilibrate plate with lab atmosphere (temperature, relative humidity) in a suitable container providing protection from dust and fumes.

B) Sample application

Unless otherwise necessary apply samples using the spray-on technique with ATS 4 or Linomat 5. In case of spot application by contact use the Nanomat or the ATS 4 and dissolve the sample in the solvent of lowest suitable solvent strength.

Use the following application parameters:

Parameter	HPTLC
Distance from lower edge of plate for use in TTC	8 mm
Distance from lower edge of plate for use in HDC	5 mm
x-position of first track	15 mm
Minimum space between bands/spots	2 mm
Maximum diameter of application spot	5 mm
Band length	8 mm
Maximum number of tracks on a 10 x 10 cm plate	7
Maximum number of tracks on a 20 x 10 cm plate	16

C) Preparation and storage of developing solvents

Developing solvents consisting of more than 1 component are prepared by measuring the required volume (respectively weight) of each component separately and transferring them into a solvent bottle of appropriate size. The bottle is closed with a lid and shaken to ensure proper mixing of the content.

Volumes smaller than 1 mL are measured with a suitable micropipette. Volumes up to 20 mL are measured with a graduated volumetric pipette of suitable size. Volumes larger than 20 mL are measured with a graduated cylinder of appropriate size.

To minimize volume errors developing solvents are prepared in a volume that is sufficient for one working day.

D) Development

Plates are developed in a saturated Twin Trough Chamber according to the following procedure:

- 1. Prepare the appropriate volume (10 mL for 10x10 cm, 20 mL for 20x10 cm TTC) of developing solvent.
- 2. Open chamber and place a correctly sized (10x10 cm; 20x10 cm) piece of filter paper in the rear trough.
- 3. Pour solvent into chamber so that the filter paper is thoroughly wetted and adheres to rear wall of TTC.
- 4. Tilt chamber to the side (about 45°) so that the solvent volume in both troughs equalizes.
- 5. Set chamber on bench, replace the lid and let chamber equilibrate for 20 minutes.
- 6. Mark the desired developing distance (70 mm from lower edge of plate) with a pencil on the right edge of the plate.
- 7. Slide off the lid to the side.
- 8. Insert the plate into the front trough. The layer should face the filter paper and the back of the plate is resting against front wall of TTC.
- 9. Replace lid.
- 10. Develop plate to the mark.
- 11. Open lid, remove plate.
- 12. Dry the plate (vertically in direction of chromatography) 5 minutes in a stream of cold air.

Prepared by: VW/2006-05-18	Released by: ER/2006-05-18	Version: 01	Effective: 2006-05-18	Page 2 of 4

13. After each development remaining mobile phase and filter paper are discarded. Prior to being prepared for the next run the chamber is dried and, if necessary, also cleaned. Alternatively the ADC 2 can be used for development. Unless otherwise specified the standard method S1 is applied.

E) Derivatization

Transfer of reagent for derivatization of samples on a HPTLC plate may be accomplished by spraying or dipping. Dipping is the preferred method and should be used whenever possible. Spraying is done in the TLC spray cabinet. If derivatization includes heating the plate heater is used. Always refer to the HPTLC method for details of the derivatization procedure.

Dipping (Chromatogram Immersion Device)

- 1. Charge tank of immersion device with 200 mL of reagent.
- 2. Place plate in holder of immersion device, set parameters according to method and press start.
- 3. Let excess reagent drip off plate, wipe off back of the plate with paper towel. Remove plate from plate holder.
- 4. Dry plate with cold air (vertically in direction of chromatography).

Spraying (Glass sprayer)

- 1. Charge the bottle of the sprayer with up to 50 mL of reagent.
- 2. Place plate in spray cabinet against a filter paper or a paper towel.
- 3. Spray plate with horizontal and vertical motion until it is homogeneously covered with reagent.
- 4. Dry plate with cold air.

Heating (Plate Heater)

- 1. Turn on plate heater and select temperature.
- 2. Wait until the temperature is stable.
- 3. Place plate onto plate heater.
- 4. After the time specified by the method remove hot plate from heater.

F) Documentation of plates (DigiStore)

Each developed plate is documented with an electronic documentation system under UV 254 nm, UV 366 nm and white light.

If a type of light does not produce usable information that fact must be documented. If a plate is derivatized images are taken prior and after derivatization.

All images are labeled and listed in the project work sheet.

G) Labeling

Plates

Each plate is given an individual identification number (ID), which will be written in pencil in the top right corner. The ID includes project number, dash, year (YY), month (MM), day (DD), dash, and a consecutive number each day.

Example: The first plate developed for Project P91 on January 10. 2002 is labeled P91-020110-01. The sixth plate developed for this project on the same day will have the ID P91-020110-06.

Images

Electronic images are saved as part of the winCats file corresponding to each plate. When exporting images as cpf-file or in other formats they are labeled individually with a file name corresponding to the plate ID followed by the description of light used for capturing. Example:

Prepared by: VW/2006-05-18	Released by: ER/2006-05-18	Version: 01	Effective: 2006-05-18	Page 3 of 4
1 Tepated by. VVV/2000 03 To	ricicuscu by. Livizuou us iu	V CI 31011. U I	LIICCIIVC. 2000 03 10	1 age 5 of 4

The image of the first plate of January 10. 2002 for Project P91 taken under UV 254 nm is saved as P91-020110-01-254. The image of a derivatized plate will additionally be labeled with a letter abbreviating the reagent name. Example: P91-020110-01-A366 is the image of the first plate on January 10. 2002 for Project P91 after derivatization with anisaldehyde under UV 366 nm.

The following abbreviations are used:

254 short-wave UV light, reflection 366 long-waver UV light, reflection W white light (reflectance) WT: white light (transmittance)

WRT: white light (reflectance / transmittance)

A: anisaldehyde reagent
S: Sulfuric acid reagent
NP: Natural products reagent

NPP: Natural products reagent followed by polyethylene glycol

Other letters to indicate other specific reagents as specified on the work sheet

H) Quantitative Evaluation

Generally quantitative evaluation is performed with the TLC Scanner 3 using winCATS software. The analysis files are labeled to reflect the plate 1D and any additional descriptive information if multiple evaluation under different conditions is performed.

I) Documentation of work

All work performed is documented in a project worksheet.

