**Supporting Information**

# Simple, Rapid, Sensitive, and Versatile SWNT-Paper Sensor for Environmental Toxin Detection Competitive with ELISA

Libing Wang,[1#] Wei Chen,[1, 2#] Dinghua Xu,[1#] Bong Sup Shim,[2] Yingyue Zhu,[1] Fengxia Sun,[1] Liqiang Liu,[1] Chifang Peng,[1] Zhengyu Jin,[1] Chuanlai Xu,[1, 2*] Nicholas A. Kotov[2*]

[1]School of Food Science and Technology, State Key Lab of the Food Science & Technology, Jiangnan University, Wuxi, Jiangsu Province, 214122，China;

[2]Department of Chemical Engineering, Department of Materials Science and Engineering, Department of Biomedical Engineering, University of Michigan，Ann Arbor, Michigan 48109, USA.




**Figure S1**. Optical photographs of the MWNT and SWNT coated paper electrodes.

*To Whom correspondence should be addressed. E-mail: xcl@jiangnan.edu.cn; kotov@umich.edu

# These three authors contribute equally to this paper.




**Figure S2**. The conductivity of SWNT-impregnated filter paper




**Figure S3.** The SEM images of (a) the face and (b) the edge of the 13 deposition cycles paper electrode.




**Figure S4**. Amperometric i-*t* traces for sensing of the target samples of MC-LR




**Figure S5**. Amperometric i-*t* traces for sensing of the control samples of ochratoxin.




**Figure S6**. The sensing results for the control samples of ochratoxin.

**The detailed process of the ELISA is as follows:**

1. Coat each well in a 96-well plate (Costar #9018) with 100 µL of a coating antigen solution.
2. Cover and rock overnight in an incubator at 4°C.
3. Wash 3 times with PBS-Tween 20 in vacuum-apparatus and pat dry.
4. The plate was blocked with 100µL (0.5%, w/v) OVA solution in PBS solution for 2 h at 37 °C.
5. Wash 3times with PBS-Tween 20.
6. Add 100 µL/well MC-LR at different dilutions or samples with 100µL/well pAb then incubate for 0.5 hour at 37 °C.
7. Wash 3times with PBS-Tween 20 and pat dry.
8. Dilute horseradish peroxidase-conjugated goat anti-rabbit IgG 1 : 3000 in PBS-Tween 20 for 0.5 hour and incubate as before.
9. Wash 6times as before and pat dry.
10. Prepare color substrate (TMB) and add 100 µL/well for 15 min in dark at room temperature.
11. $H_2SO_4$ (2 mol/L) was added to stop the reaction and record the absorption in a micro plate reader at 450nm.